

FERSA SOLUTIONS

MERCEDES BENZ

DIFFERENTIAL \ GEARBOX



The contents of this publication are the copyright of Fersa Bearings and may not be reproduced (even extracts) unless prior written permission is granted. Every care has been taken to ensure the accuracy of the information contained in this publication but no liability for any loss or damage whether direct, indirect or consequential arising out of the use of the information contained herein.

Despite our best efforts to ensure the accuracy of the information contained in this document, errors or omissions cannot be completely ruled out. We disclaim any and all responsibility for such unintentional errors or omissions.

O conteúdo desta publicação é propriedade da Fersa Bearings e não pode ser reproduzido (mesmo que parcialmente) sem autorização prévia por escrito. Foram tomadas todas as medidas para se garantir a exatidão das informações contidas nesta publicação, mas não nos consideramos responsáveis por qualquer perda ou dano, tanto diretos como indiretos ou consequentes resultantes do uso das informações contidas neste documento.

Apesar do nosso esforço para garantirmos a exatidão dos dados deste documento, declinamos qualquer responsabilidade por eventuais erros ou omissões.

El contenido de esta publicación es propiedad de Fersa Bearings y no puede reproducirse (incluso parcialmente) sin autorización previa por escrito. Todos los datos se han tomado para garantizar la exactitud de la información contenida en esta publicación, pero no se hace responsable por cualquier pérdida o daños, ya sean directos, indirectos o consecuentes resultantes del uso de la información contenida en este documento.

A pesar de nuestro esfuerzo para asegurar la exactitud de los datos de este documento, declinamos toda responsabilidad sobre posibles errores u omisiones.

Le contenu de cette publication est soumis aux droits d'auteur de Fersa Bearings et ne peuvent être reproduits (ni même en extraits) sans avoir préalablement obtenu une autorisation écrite. Le plus grand soin a été pris pour garantir l'exactitude des informations contenues dans la publication. Néanmoins, aucune responsabilité ne peut être engagée pour la perte ou les dégâts, qu'ils soient directement ou indirectement liés ou encore conséquents à l'usage des informations contenues.

Malgré nos efforts pour garantir l'exactitude des informations contenues dans ce document, nous ne sommes pas en mesure d'exclure toute possibilité d'erreur ou d'omission. Nous rejetons toute responsabilité pour de telles erreurs ou omissions involontaires.

Die Inhalte dieses Dokuments unterliegen dem Urheberrecht von Fersa Bearings und dürfen weder ganz noch teilweise ohne vorherige schriftliche Genehmigung vervielfältigt werden. Bei der Zusammenstellung der Informationen dieses Dokuments wurde äußerste Sorgfalt angewandt, nichtsdestotrotz übernehmen wir keine Haftung für mittelbare, unmittelbare Verluste oder Schäden bzw. Folgeschäden, die aufgrund der Nutzung der hier enthaltenen Informationen entstehen.

Obwohl jede Anstrengung unternommen wurde, um die Korrektheit der Informationen dieses Dokuments zu gewährleisten, können Fehler oder Auslassungen nicht vollständig ausgeschlossen werden. In diesem Sinne schließen wir jegliche Haftung für derartige unbeabsichtigte Fehler und Auslassungen aus.

Авторское право на содержание этой публикации принадлежит компании Fersa Bearings, и ее воспроизведение (даже частичное) не разрешается без получения письменного разрешения Fersa Bearings. Для обеспечения точности информации, содержащейся в настоящей публикации, были предприняты все возможные меры, однако автор не несет ответственности за какие-либо потери или ущерб (прямой, побочный или косвенный), возникший вследствие использования такой информации.

Несмотря на все усилия, направленные на обеспечение точности информации, которая содержится в настоящем документе, ошибки или упущения не могут быть полностью исключены. Автор отказывается от какой-либо и всей ответственности в связи с такими непреднамеренными ошибками или упущениями.

Treść niniejszej publikacji stanowi własność firmy Fersa Bearings i nie może być powielana (nawet częściowo) bez uzyskania uprzedniej pisemnej zgody. Dochowano należytej staranności, aby zagwarantować prawidłowość informacji zawartych w niniejszej publikacji, jednak firma nie ponosi w żadnym wypadku odpowiedzialności za jakiegokolwiek straty lub szkody bezpośrednio, pośrednio czy wynikowe związane z wykorzystaniem tych informacji. Pomimo wszelkich starań dołożonych w celu zapewnienia dokładności informacji zawartych w niniejszym dokumencie, nie można w zupełności wykluczyć błędów lub przeoczeń. Zrzekamy się wszelkiej odpowiedzialności za takie niezamierzone błędy lub przeoczenia.

تحتفظ فيرسا بيرنجز بحقوق طبع ونشر محتويات هذا الدليل ولا يجوز إعادة نشرها (حتى المقتبسات) ما لم يتم منح إذن كتابي مسبق، ويتم اتخاذ كل الإجراءات الرعاية لضمان دقة المعلومات المُضمّنة في هذه النشرة ولكن لا تتحمل الشركة مسؤولية أي فقد أو خسارة سواء أكان مباشر أو غير مباشر، أو تبعية ناتج عن استخدام هذه المعلومات للخصم من هنا.

وعلى الرغم من بذلنا قصارى جهدنا لضمان دقة المعلومات المُضمّنة في هذا المستند، إلا أنه لا يمكن استبعاد الأخطاء أو الحذف تمامًا. نحن نتنصل عن أي وكافة المسؤوليات لهذه الأخطاء أو عمليات الحذف غير المقصودة.

FERSA SOLUTIONS

MERCEDES BENZ





ABOUT US

FERSA BEARINGS IS A SPANISH MULTINATIONAL COMPANY DEDICATED TO THE DESIGN, DEVELOPMENT, MANUFACTURING AND DISTRIBUTION OF THE COMPLETE SOLUTIONS FOR HIGH PERFORMANCE BEARINGS

COMMERCIAL VEHICLE EXPERTS

The most complete range for major heavy vehicle applications.

As experts in bearings, we can offer specific bearing designs according to their final application: gearbox, differential and wheel ends.

We manufacture bearings for American, Asian and European vehicles.

INDEX

INTRODUCCIÓN \Pág. 4

Introdução / Introducción / Introduction / Einleitung / Введение / Wstęp / المؤشر

1\

DIFFERENTIAL \Pág. 10

Diferencial \ Diferencial \ Différentiel Differential \ Unterschied
Дифференциал \ Mechanizm różnicowy \ القرص التفاضلي

2\

GEARBOX \Pág. 78

Caixa de Câmbio \ Caja de Cambios \ Boîte de vitesse / Getriebe
\Коробка передач \ Skrzynia biegów \ علبة التروس

3\

OEM Cross References \Pág. 126

OEM Cruzamento de Referência \ OEM Cruce de Referencias Références OEM croisées \
OEM-Quervergleiche \ Перевод на маркировку производителя \ Odnosiniki OEM \
مراجع متبادلة مُصنع المعدات الأصلية



FERSA SOLUTION

THE "FERSA SOLUTION" IS OUR FULL SERVICE APPROACH FOR BEARINGS FOR SPECIFIC APPLICATIONS SUCH AS WHEEL-ENDS, DIFFERENTIALS AND GEARBOXES FOR MOST COMMERCIAL VEHICLES

Fersa bearings are manufactured to OEM specifications; starting with the specifications of the raw material to the heat treatment processes, as well as optimized design features.



SPECIAL HEAT TREATMENT FOR BEARINGS


Optimized material composition for enhanced service life.

All Fersa bearings undergo a special type of Through Hardening heat treatment. The hardening process includes austenitization and quenching in a carbon neutral atmosphere. This provides an elevated tensile strength -throughout the part- after quenching, which is then tempered to increase the ductility and toughness.

Fersa's added value offer is...

Increased bearing service life and delaying the maintenance of the vehicle.





OPTIMIZED PROFILES FOR EVERY APPLICATION

OEMs and Tier1 manufacturers know that bearings are a vital element of the drivetrain system. It needs to perform flawlessly under the most critical working conditions. Fersa bearings are designed for heavy duty applications, thus have to withstand very demanding loads. All the bearings that Fersa manufactures, be it for: wheel hub units, wheel-ends, differentials, as well as transmissions feature specific internal geometry, as complex profiling and low roughness.

Fersa's added value offer is...

Extending bearing wear resistance.

REDUCED SPACER RANGE FOR PINION APPLICATIONS

Fersa bearings for pinion applications are manufactured according to the toughest OEM specifications, with tighter width tolerances in the back face.

Fersa's added value offer is...

Reducing the number of attempts for proper spacer selection during assembly and ensuring an optimum (tighter) pinion preload setting. The final process assembly time is reduced, cost savings are considerably increased.





Position

Posición
Posição
Position
Position
Położen
Позиция
عضول

Fersa Reference

Referencia Fersa
Referência Fersa
Référence Fersa
Fersa Ref.
Referencyjny Fersa
Номер от Fersa
امريف عجرم

OEM Reference

Referencia OEM
Referência OE
OEM Référence
OEM Ref.
Numer referencyjny OEM
Номер от производителя
فصل الة تادعما وعضرم عجرم

Brand

Marca, Marca, Marque,
Marke, Marka, **Марка**,
فوجراجتلا قول عا

POSITION

Fersa

OEM

VOLVO

Model

Modelo, Modelo, Modèle,
Model, Model, **Модель**,
موجول

DR80

Ratio 3,76/1, 4,12/1, 4,55/1, 5,41/1, 1,09/1, 1,19/1

Bevel pinion, front

HM 91

128/HM 911210

18

633+184115

Bevel pinion, pilot

Series / Ratio - Axle serie

183703

Bevel pinion, rear

H 91

3843/H 91

184635

Differential, left

687/672

181279 / 184637

Differential, right

687/6

181279 / 184637

Reduction shaft, right

Series / Przetozenie - Серия оси

183831 / 184639



Axle Model

Modelo de eje
Modelo de Eixo
Modèle d'essieu
Achsmoell
Model osi
Модель моста
روجما عجون

Axle Position

Tipo de eje
Tipo de eixo
Position de l'essieu
Achsposition
Położenie osi
Позиция моста
روجما عضرم

Axle Information

Información del Eje
Informação de Eixo
Informations de l'essieu
Achsinformation
Położenie osi
Информация о мосте
روجما تاجول عم

Bearing Position

Posición del Rodamiento
Posição do Rolamento
Position do Rolamento
Lagerposition
Położenie łożyska
Позиция подшипника
لوجما عضرم

Brand

Marca, Marca, Marque,
Marke, Marka, **Марка**,
فوجراجتلا قول عا



N° chassis //
Axle load //
Wheel type



MERCEDES BENZ

Model

Modelo, Modelo, Modèle,
Model, Model, **Модель**,
موجول

ATEGO

814, 814 L, 815, 815 L, 817, 817 L

VL 2/22 DC-4,1	FA	SA 5043	SA 5043	32306 F	33208 F
	FA	SA 5043	Construction		
	FA	SA 5043	Construcción, Construção, Construction, Konstruktion	33207 F	39590/39520
	FA	SA 5043	Budowa, Конструкция, لكدفملا	20	
HL 4/40 DC-7	RA		33017 F	33208 F	

N° OEM

EN Search according to OEM Number:

- 1 In the OEM reference List table (page 58) look for the corresponding Fersa reference.
- 2 Find the Fersa reference in the catalog. Please be sure to verify the application referenced.

ES Método de búsqueda por N° OEM

- 1 Busque el número de referencia OEM en la tabla Listado de referencia OEM (pag. 58).
- 2 Busque la referencia Fersa en el catalogo y verifique la aplicación.

PT Método de busca da por N° OEM:

- 1 Busque o número de referencia OEM na tabela Lista de referência OEM (pág. 58).
- 2 Busque a referência Fersa no catálogo, e verifique a aplicação.

FR Recherchez la pièce à l'aide du numéro OEM:

- 1 Dans le tableau de la liste des références OEM (page 58), recherchez la référence Fersa correspondante.
- 2 Trouvez la référence Fersa dans le catalogue. Assurez-vous de bien vérifier l'application référencée.

DE Suche anhand der OEM-Nummer:

- 1 Suchen Sie in der Liste der OEM-Ref.-Nr. (Seite 58) nach der entsprechenden Fersa-Ref.-Nr.
- 2 Suchen Sie die Fersa-Ref.-Nr. im Katalog. Bitte prüfen Sie die Anwendung anhand der Ref.-Nr.

PL Wyszukiwanie według numeru OEM:

- 1 Znajdź odpowiedni numer Fersa w tabeli zawierającej wykaz numerów referencyjnych OEM (strona 58).
- 2 Znajdź w katalogu numer referencyjny Fersa. Pamiętaj o sprawdzeniu odnośnego zastosowania.













RU Поиск по номеру производителя:

- 1 В таблице номеров производителей (стр. 58) найдите соответствующий номер Fersa.
- 2 Найдите номер Fersa в каталоге. Не забудьте проверить применение согласно номеру.

AR مُؤَلِّصُ الرُّبَالِ خَالِدُ المَعْمَلِ وَعَرَضُهُ مَوْجِلُ أَوْجِبُ شَرِيحَا













- 1 في جدول قائمة مرجع مصنع المعدات الأصلية (الصفحة) ابحث عن مرجع فيرسا المتوافق.
- 2 ابحث عن مرجع فيرسا في الكatalog. رجاءً تأكد من أن تتدفق من التطبيق الوارد في المرجع.

Symbols & Nomenclatures

	EN	ES	PT	FR
	Differential	Diferencial	Diferencial	Différentiel
	Gearbox	Caja de cambios	Caixa de câmbio	Boîte de vitesses
	Wheel end	Rueda	Roda	Roue
	Trailer	Trailer	Reboque	Remorque
	Truck	Camión	Caminhão	Camion
	Bus	Bus	Ônibus	Bus
	OEM cross references	OEM cruce de referencias	OEM Referências cruzadas	Références OEM croisées
*	Availability to be advised	Se confirmará disponibilidad	Disponibilidade a confirmar	Disponibilité à notifier
	Axle position	Posición del eje	Posição do eixo	Position de l'essieu
	Information	Información	Informação	Informations
	WHU (Wheel Hub Unit)	WHU (Unidad de buje de rueda)	WHU (Cubo de roda unitizado)	WHU (unité de roulement de roue)
	Inboard	Interior	Interior	Embarqué
	Outboard	Exterior	Exterior	Débarqué

Z	Shield on one side	Tapa en una cara	Protetor em uma face	Écran sur un côté
ZZ	Shield on both sides	Tapas en las dos caras	Protetor nas duas faces	Écrans sur les deux côtés
RS	Rubbing seal on one side	Tapa retén en una cara	Protetor nas duas faces	Joint à frottement sur un côté
2RS	Rubbing seals on both sides	Tapa retén en las dos caras	Retentor nas duas faces	Joints à frottement sur les deux côtés
M	Machined brass cage	Jaula de latón	Gaiola de latão	Cage en laiton usinée
N	Snap ring groove in outer ring	Ranura y anillo elástico en aro exterior	Canal e trava no aro externo	Rainure pour segment d'arrêt sur la bague extérieure
NR	Snap ring groove and snap ring in outer ring	Ranura, anillo elástico y arandela de seguridad en aro exterior	Canal com trava de segurança no aro exterior	Rainure pour segment d'arrêt et segment d'arrêt sur la bague extérieure
C3	Internal clearance greater than normal	Juego radial mayor que el normal	Folga radial maior que o normal	Jeu interne supérieur à la normale

FA	Front axle	Eje delantero	Eixo traseiro	Essieux avant
LA	Leading axle	Eje motriz	Eixo motriz	Essieu poussé
RA	Rear axle	Eje trasero	Eixo dianteiro	Essieu arrière
TA	Trailing axle	Eje de arrastre	Eixo de arraste	Essieu traîné
TRA	Trailer axle	Eje de trailer	Eixo de reboque	Essieu de remorque

	DE	PL	RU	AR
	Differential	Mechanizm różnicowy	Дифференциал	قرص تفاضلي
	Getriebe	Skrzynia biegów	Коробка передач	عجلة التروس
	Rad	Koło	Колесо	عجلة
	Anhänger	Przyczepa	Прицеп	مقطورة
	LKW	Ciężarówka	Грузовик	شاحنة
	Bus	Autobus	Автобус	حافلة
	OEM-Quervergleiche	Odnosińki OEM	Перевод на маркировку производителя	مراجع متبادلة لمصنع المعدات الأصلية
*	Verfügbarkeit muss bestätigt werden	Informacje dotyczące dostępności poda producent	Наличие уточняется	الإتاحة للاستشارة
	Achspannung	Położenie osi	Позиция моста	موضع المحور
	Information	Informacje	Информация	المعلومات
	WHU (Radnabeneinheit)	WHU (zestaw piast koła)	Ступица	WHU (وحد محول العجلة)
	Innen	Wewnętrzny	Внутри	داخلي
	Außen	Zewnętrzny	Снаружи	خارجي

Z	Deckel auf einer Seite	Ośłona z jednej strony	Защитная шайба с одной стороны	درع في جانب واحد
ZZ	Deckel auf beiden Seiten	Ośłony po obu stronach	Защитные шайбы с обеих сторон	درعان على كلا الجانبين
RS	Schleifende Dichtung auf einer Seite	Uszczelnienie cierne po jednej stronie	Резиновое уплотнение с одной стороны	مانع تسريب احتكاك على جانب واحد
2RS	Schleifende Dichtungen auf beidem Seiten	Uszczelnienia cierne po obu stronach	Резиновое уплотнение с обеих сторон	مانعي تسريب احتكاك على كلا الجانبين
M	Messingkäfig	Rowek na pierścieniu zewnętrznym	Механически обработанный латунный сепаратор	قفص نحاس الي
N	Sprengringnut im Außenring	Rowek smarowy na pierścieniu zewnętrznym	Канавка под стопорное кольцо на наружном кольце	محاداة تجويف حلقة الإطباق في الحلقة الخارجية
NR	Sprengringnut und Sprengring im Außenring	Rowek i zabezpieczający pierścień sprężynujący na pierścieniu zewnętrznym	Канавка со стопорным кольцом на наружном кольце	محاداة حلقة الإطباق وحلقة الإطباق في الحلقة الخارجية
C3	Radialspiel größer als normal	Luz wewnętrzny większy niż normalny	Внутренний зазор, превышающий стандартный	الخُلوص الداخلي أكبر من المعدل الطبيعي

FA	Vorderachse	Oś przednia	Передний мост	المحور الأمامي
LA	Vorlaufachse	Oś prowadząca	Ведущий мост	محور القيادة الأمامي
RA	Hinterachse	Oś tylna	Задний мост	المحور الخلفي
TA	Hinterachse	Oś tylna	Поддерживающий мост	محور السحب الخلفي
TRA	Anhängerachse	Oś przyczepy	Мост прицепа	محور المقطورة

1 \

DIFFERENTIAL

MODEL	Pág\
608	12
1113 / 1214 / 1218 / 1414 / 1418 / 1618	12
1519 Reduzido	12
1924 A 1945 / AXOR 2044S / 2544S / 2644S / 3340 / 3340K / 3340S / 3344 / 3344K	12
2635 / 3638	12
AL 3/6 D-6	12
AL 3/6-6	13
AL 3/8 DS-4,7	14
AL 3/9 D-6,8	14
AL 7/1 D-7	14
AL 7/1 DS-7	15
AL 7/5 D-7	15
AL 7/8 D-8	15
AXOR 1933 / 2035 / 2040 / 2044 / 2533	16
HD 4/02 DG-10	16
HD 4/02 DG-10 Brazil	16
HD 4/02 GD-10	16
HD 4/03 D-10	16
HD 4/03 D-10 Brazil	17
HD 4/21 DG10	17
HD 4/21 G	17
HD 4/21 G-10	17
HD 4/21 G-10 Brazil	17
HD 4/21 GS-10 Brazil	18
HD 4/22	18
HD 4/22 D-10	18
HD 4/22 DG-10	18
HD 4/22-10	18
HD 4/22-10 Brazil	19
HD 6/3 D-10	19
HD 6/3 DG-10	19
HD 7/2 DG-10	19
HD 7/2 DLG-10	20
HD 7/2 DSG-10	20
HD 7/5 DG-10	20
HD 7/09 DG-10	21
HD 7/9	21
HD 7/11 DG-9	21
HD 7/14	21
HD 7/014 DG-16	21
HD 7/014 DGS-16	21
HD 7/014 DGS-16 Turkey	22

MODEL	Pág\
HD 7/16	22
HD 7/016 DG-13	22
HD 7/016 DSG-13	22
HD 7/19 DG-13	23
HD 7/19 DG-13 Turkey	23
HD 7/19 DGS-13	23
HD 7/19 DGS-13 Turkey	24
HD 7/19 DSG-13	24
HD 7/55	24
HD 7/55 DGS-13	24
HD 7/56	24
HD 7/56 DGS-13	24
HD 7/57	25
HD 7/58	25
HH 4/04 D-12	25
HH 4/05 D-10 Brazil	25
HH 4/07 DL-10 Brazil	25
HH 4/12 D-10	26
HH 4/12-10 Brazil	26
HH 4/12 D-10 Brazil	26
HH 4/19 D-10	27
HL 1/2-3,3	27
HL 1/3-4,5	27
HL 1/8-4,7	27
HL 1/9-5,6	27
HL 2/2 L-4,8	28
HL 2/2-4,8	28
HL 2/3-5,7	28
HL 2/4 L-6,4	28
HL 2/4-6,4	28
HL 2/5-4,5	28
HL 2/5-4,5 Brazil	29
HL 2/7-7,7	29
HL 2/9-4,7	29
HL 2/9-4,7 Turkey	29
HL 2/11 D-5,8	30
HL 2/12 D-4,5	30
HL 2/13 D-6,4	30
HL 2/14 D-6,9	30
HL 2/15 S-5,8	30
HL 2/15-5,8	30
HL 2/15 5,9 Brazil	31
HL 2/16-4,7 Brazil	31
HL 2/17-5,9 Brazil	31
HL 2/30	31
HL 2/31	31

MODEL	Pág\
HL 2/43	31
HL 2/44	31
HL 2/46	32
HL 2/47	28
HL 4/01-10	32
HL 4/01 D-10	32
HL 4/01 D-10 Brazil	34
HL 4/01 DL-10	34
HL 4/01 DL-10	34
HL 4/01 DL-11,5	36
HL 4/01 L-10	36
HL 4/05 D-9,2	36
HL 4/06 D-12	36
HL 4/06 DL-12	37
HL 4/06 DL-12	37
HL 4/07 D-9,4	38
HL 4/08 D-10,6	38
HL 4/09 D-9,2	39
HL 4/12 D-10 Brazil	39
HL 4/14-8,8 Brazil	39
HL 4/16 L-7,7	39
HL 4/16-7,7	39
HL 4/17 D-9,2	40
HL 4/17 L-9,2	40
HL 4/17 S-9,2	40
HL 4/1-7,6	41
HL 4/4-8,8	41
HL 4/7,6 Brazil	42
HL 4/8-6,3	42
HL 4/8-6,30	42
HL 4/8-10	43
HL 4/8 D-10	43
HL 4/8 L-10	43
HL 4/17-9,2	44
HL 4/23-7,7	44
HL 4/23L-7,7	44
HL 4/25 D-7,6 Brazil	44
HL 4/25-7,6 Brazil	45
HL 4/26 D-9,2 Brazil	45
HL 4/27 D-10 Brazil	46
HL 4/28 D-7,8	47
HL 4/29 D-9,2	47
HL 4/30 D-6,4	47
HL 4/30 DS-6,4	48
HL 4/31 DS-7,0	48
HL 4/32 D-10,6	48
HL 4/35 D-6,4	48

MODEL	Pág\
HL 4/35 D-7,7	48
HL 4/35 D-7,8	49
HL 4/35 D-9,2	49
HL 4/035 D-9,2	49
HL 4/035 D-10,6	49
HL 4/35 D-10,6	49
HL 4/36 D-7,7	49
HL 4/038 D-10	49
HL 4/038 D-12	49
HL 4/038 D-9,4	50
HL 4/039 D-10	50
HL 4/039 D-12	50
HL 4/039 DL-12	50
HL 4/40	50
HL 4/60 D-10	50
HL 4/60 D-10 Brazil	51
HL 4/60 D-7,6	51
HL 4/60-10 Brazil	51
HL 5/1 S-10	51
HL 5/1 Z-10	51
HL 5/2-10	51
HL 5/2-10 Brazil	52
HL 5/2 D-10 Brazil	52
HL 5/2 DZ-10 Brazil	52
HL 5/2 S-6,5	52
HL 5/2 S-10	52
HL 5/2 Z-10	52
HL 5/2 ZL-10	53
HL 5/2 ZS-10	53
HL 5/2 ZS-10 Brazil	53
HL 6/1	53
HL 6/3	
HL 7/1-10	53
HL 7/1 D-10	54
HL 7/1 DL-10	55
HL 7/1 L-10	55
HL 7/1 S-10	56
HL 7/02 DL-10	56
HL 7/3 D-10	56
HL 7/3 DL-10	57
HL 7/3 DS-10	57
HL 7/4 D-10	57

MODEL	Pág\
HL 7/07 D-10	58
HL 7/07 D-11,5	59
HL 7/07 DL-10	60
HL 7/07 DL-11,5	60
HL 7/07 DS-10	61
HL 7/010	61
HL 7/10 D-9	61
HL 7/10 D-13	61
HL 7/013 D-16	62
HL 7/013 DS-16 Turkey	62
HL 7/15 D-13	62
HL 7/015 D-13	62
HL 7/015 D-13 Turkey	64
HL 7/015 DL-13	64
HL 7/015 DS-13	65
HL 7/18 D-13	65
HL 7/18 D-13 Turkey	66
HL 7/18 DS-13	66
HL 7/18 DS-13 Turkey	66
HL 7/021 D-10	67
HL 7/021 DL-10	67
HL 7/021 DS-10	67
HL 7/24 DS-9	68
HL 7/024 D-12,3	68
HL 7/024 DL-12,3	68
HL 7/26 D-11,5	68
HL 7/26 D-12,3	69
HL 7/26 DL-12,3	69
HL 7/055 DCS-13	69
HL 7/50	69
HL 7/52 DGS-11,5	69
HL 7/55	69
HL 7/56	69
HL 8/1 DCS-13	69
HL 0/01	70
HL 0/02	70
HL 0/14	70
HL 0/15	70
HL 0/2-2,2	70
HL 0/3-3,3	70
HL 0/6-3,9	70
HO 4/01 D-10 Brazil	70

MODEL	Pág\
HO 4/01 D-10 Turkey	71
HO 4/01 DL-10	71
HO 4/01 DL-10 Brazil	71
HO 4/01 DL-10 Turkey	72
HO 4/01 D-11,5	72
HO 4/01 DL-11,5	72
HO 4/01 DL-11,5	72
HO 4/02 CL-11,5	72
HO 4/08 DCL-11,5	73
HO 4/10 DL-10	73
HO 4/10 L-10	73
HO 4/18 DL-7,7	73
HO 4/18 L-7,7	73
HO 4/2-7,6 Turkey	73
HO 5/4 Z-10	74
HO 5/8 DL-10	74
HO 5/8 DZ-10	74
HO 5/8L-10	74
HO 6/1	75
HO 6/2	75
HO 6/3	75
HO 6/5	75
HO 6/6	75
HO 7/01 DL-10	75
HO 7/01 DLS-10	75
HO 7/02 DLM-10	75
HO 7/8 DL-10	76
HO 7/9 DL-10	76
HO 7/10 DL-11,5	75
HO 8/1 DCL-13	76
HO 8/1 DCLS-13	76
LK 1622 4x2 / 1632 / 1636 / 1722 / 1725	76

POSITION	Fersa	OEM
----------	-------	-----

MERCEDES BENZ

608		
Bevel pinion front	F 15280	002 981 8805
Bevel pinion rear	F 15280	002 981 8805
Bevel pinion pilot	*	001 981 0301
Differential right	*	003 981 4905
Differential left	*	003 981 4905

1113 / 1214 / 1218 / 1414 / 1418 / 1618		
Bevel pinion front	HM 911244/HM 911216	001 981 9805
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19012	345 981 7301
Differential right	33114 F	344 981 7205
Differential left	33114 F	344 981 7205

1519 Reduzido		
Bevel pinion front	F 15082	001 981 9905
Bevel pinion rear	F 15083	003 981 1905
Bevel pinion pilot	F 19015	006 981 1901
Differential right	32020 XF	001 981 6405
Differential left	32020 XF	001 981 6405

1924 A 1945 / AXOR 2044S / 2544S / 2644S / 3340 / 3340K / 3340S / 3344 / 3344K		
Bevel pinion front	32314 BF	003 981 2905
Bevel pinion rear	31313 F	003 981 0605
Differential right	33115 F	003 981 3005
Differential left	33115 F	003 981 3005

2635 / 3638		
Bevel pinion front	32314 BF	003 981 2905
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33115 F	003 981 3005
Differential left	33115 F	003 981 3005
Input shaft front	6313 C3	000625036313
Output shaft rear	6216 c3	000625036216

AL 3/6 D-6		731.649
Bevel pinion front (Up to Axle 016456)	F 15280	002 981 8705
Bevel pinion front (From Axle 016457)	*	008 981 1605
Bevel pinion rear (Up to Axle 016456)	F 15280	002 981 8705
Bevel pinion rear (From Axle 016457)	*	008 981 1605
Differential right (Up to Axle 387424)	*	001 981 4905
Differential right (From Axle 387425)	JM 714249/JM 714210	008 981 5305
Differential left (Up to Axle 387424)	*	001 981 4905
Differential left (From Axle 387425)	JM 714249/JM 714210	008 981 5305

AL 3/6 D-6		731.602
Bevel pinion front (Up to Axle 016456)	F 15280	002 981 8705
Bevel pinion front (Up to Axle 016456)	F 15280	002 981 8805
Bevel pinion front (From Axle 016457)	*	008 981 1505
Bevel pinion front (From Axle 016457)	*	008 981 1605
Bevel pinion rear (Up to Axle 016456)	F 15280	002 981 8705
Bevel pinion rear (Up to Axle 016456)	F 15280	002 981 8805
Bevel pinion rear (From Axle 016457)	*	008 981 1505
Bevel pinion rear (From Axle 016457)	*	008 981 1605
Bevel pinion pilot	*	003 981 2901

POSITION	Fersa	OEM
AL 3/6 D-6		731.602
Differential right (Up to Axle 387424)	*	001 981 4905
Differential right (From Axle 387425)	JM 714249/JM 714210	008 981 5305
Differential left (Up to Axle 387424)	*	001 981 4905
Differential left (From Axle 387425)	JM 714249/JM 714210	008 981 5305

AL 3/6 D-6		31.636-637-638-639-640-643-645-646-647-648
Bevel pinion front (Up to Axle 016456)	F 15280	002 981 8705
Bevel pinion front (From Axle 016457)	*	008 981 1605
Bevel pinion rear (Up to Axle 016456)	F 15280	002 981 8705
Bevel pinion rear (From Axle 016457)	*	008 981 1605
Bevel pinion pilot	*	003 981 2901
Differential right (Up to Axle 387424)	*	001 981 4905
Differential right (From Axle 387425)	JM 714249/JM 714210	008 981 5305
Differential left (Up to Axle 387424)	*	001 981 4905
Differential left (From Axle 387425)	JM 714249/JM 714210	008 981 5305

AL 3/6-6		731.600-632
Bevel pinion front (Up to Axle 016456)	F 15280	002 981 8705
Bevel pinion front (Up to Axle 016456)	F 15280	002 981 8805
Bevel pinion front (From Axle 016457)	*	008 981 1505
Bevel pinion front (From Axle 016457)	*	008 981 1605
Bevel pinion rear (Up to Axle 016456)	F 15280	002 981 8705
Bevel pinion rear (Up to Axle 016456)	F 15280	002 981 8805
Bevel pinion rear (From Axle 016457)	*	008 981 1505
Bevel pinion rear (From Axle 016457)	*	008 981 1605
Bevel pinion pilot	*	003 981 2901
Differential right (Up to Axle 387424)	*	001 981 4905
Differential right (From Axle 387425)	JM 714249/JM 714210	008 981 5305
Differential left (Up to Axle 387424)	*	001 981 4905
Differential left (From Axle 387425)	JM 714249/JM 714210	008 981 5305

AL 3/6-6		731.600-633
Bevel pinion front (Up to Axle 016456)	F 15280	002 981 8705
Bevel pinion front (Up to Axle 016456)	F 15280	002 981 8805
Bevel pinion front (From Axle 016457)	*	008 981 1505
Bevel pinion front (From Axle 016457)	*	008 981 1605
Bevel pinion rear (Up to Axle 016456)	F 15280	002 981 8705
Bevel pinion rear (Up to Axle 016456)	F 15280	002 981 8805
Bevel pinion rear (From Axle 016457)	*	008 981 1505
Bevel pinion rear (From Axle 016457)	*	008 981 1605
Bevel pinion pilot	*	003 981 2901
Differential right (Up to Axle 387424)	*	001 981 4905
Differential right (From Axle 387425)	JM 714249/JM 714210	008 981 5305
Differential left (Up to Axle 387424)	*	001 981 4905
Differential left (From Axle 387425)	JM 714249/JM 714210	008 981 5305

AL 3/6-6		731.634-635
Bevel pinion front (Up to Axle 016456)	F 15280	002 981 8705
Bevel pinion front (From Axle 016457)	*	008 981 1605
Bevel pinion rear (Up to Axle 016456)	F 15280	002 981 8705
Bevel pinion rear (From Axle 016457)	*	008 981 1605
Bevel pinion pilot	*	003 981 2901
Differential right (Up to Axle 387424)	*	001 981 4905
Differential right (From Axle 387425)	JM 714249/JM 714210	008 981 5305
Differential left (Up to Axle 387424)	*	001 981 4905
Differential left (From Axle 387425)	JM 714249/JM 714210	008 981 5305

1 \ Differential

POSITION	Fersa	OEM
AL 3/8 DS-4,7		<i>731.343</i>
Bevel pinion front	*	000 981 0027
Bevel pinion rear	*	5412100309
Bevel pinion pilot	*	312 981 0601
Differential right	JM 714249/JM 714210	008 981 5305
Differential left	JM 714249/JM 714210	008 981 5305
Bevel pinion front	*	000 981 0027
Bevel pinion rear	*	5412100309
Bevel pinion pilot	*	312 981 0601
Differential right	JM 714249/JM 714210	008 981 5305
Differential left	JM 714249/JM 714210	008 981 5305

AL 3/9 D-6,8		<i>731.620-622-625-626</i>
Bevel pinion front (Up to Axle 016337)	F 15280	002 981 8705
Bevel pinion front (Up to Axle 016337)	F 15280	002 981 8805
Bevel pinion front (From Axle 016338)	*	008 981 1505
Bevel pinion front (From Axle 016338)	*	008 981 1605
Bevel pinion rear (Up to Axle 016337)	F 15280	002 981 8705
Bevel pinion rear (Up to Axle 016337)	F 15280	002 981 8805
Bevel pinion rear (From Axle 016338)	*	008 981 1505
Bevel pinion rear (From Axle 016338)	*	008 981 1605
Bevel pinion pilot	*	003 981 2901
Differential right (Up to Axle 387424)	*	001 981 4905
Differential right (From Axle 387425)	JM 714249/JM 714210	008 981 5305
Differential left (Up to Axle 387424)	*	001 981 4905
Differential left (From Axle 387425)	JM 714249/JM 714210	008 981 5305

AL 3/9 D-6,8		<i>731.621-603-623-624</i>
Bevel pinion front (Up to Axle 016456)	F 15280	002 981 8705
Bevel pinion front (Up to Axle 016456)	F 15280	002 981 8805
Bevel pinion front (From Axle 016457)	*	008 981 1505
Bevel pinion front (From Axle 016457)	*	008 981 1605
Bevel pinion rear (Up to Axle 016456)	F 15280	002 981 8705
Bevel pinion rear (Up to Axle 016456)	F 15280	002 981 8805
Bevel pinion rear (From Axle 016457)	*	008 981 1505
Bevel pinion rear (From Axle 016457)	*	008 981 1605
Bevel pinion pilot	*	003 981 2901
Differential right (Up to Axle 387424)	*	001 981 4905
Differential right (From Axle 387425)	JM 714249/JM 714210	008 981 5305
Differential left (Up to Axle 387424)	*	001 981 4905
Differential left (From Axle 387425)	JM 714249/JM 714210	008 981 5305

AL 7/1 D-7		<i>731.055-056-057</i>
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Outboard (Hub reduction)	*	720032019
Inboard (Hub reduction)	F 15272	004 981 2005

AL 7/1 D-7		<i>731.013-038-039</i>
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Outboard (Hub reduction)	33019 F	002 981 9005
Inboard (Hub reduction)	F 15272	004 981 2005

POSITION	Fersa	OEM
AL 7/1 D-7		731.031-032-033-035-036-037
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Outboard (Hub reduction)	*	720032019
Inboard (Hub reduction)	F 15272	004 981 2005

AL 7/1 D-7		731.000-002-004-005-006-007-008-009-012
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Outboard (Hub reduction)	*	720032019
Inboard (Hub reduction)	F 15272	004 981 2005

AL 7/1 D-7		731.044-045-048-049-050-051-052-053-054
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Outboard (Hub reduction)	*	720032019
Inboard (Hub reduction)	F 15272	004 981 2005

AL 7/1 DS-7		731.059-060
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Outboard (Hub reduction)	33019 F	002 981 9005
Inboard (Hub reduction)	F 15272	004 981 2005

AL 7/5 D-7		731.014
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Outboard (Hub reduction)	33019 F	002 981 9005
Inboard (Hub reduction)	F 15272	004 981 2005

AL 7/5 D-7		731.001-010-011
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Outboard (Hub reduction)	33019 F	002 981 9005
Inboard (Hub reduction)	F 15272	004 981 2005

AL 7/8 D-8		731.041-042
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Outboard (Hub reduction)	33019 F	002 981 9005
Inboard (Hub reduction)	F 15272	004 981 2005

POSITION	Fersa	OEM
AL 7/8 D-8		731.043-046-047
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Outboard (Hub reduction)	33019 F	002 981 9005
Inboard (Hub reduction)	F 15272	004 981 2005
AXOR 1933 / 2035 / 2040 / 2044 / 2533		
Bevel pinion front	F 15253	014 981 2105
Bevel pinion rear	F 15254	014 981 5005
Differential right	32020 XF	001 981 6405
Differential left	32024 XF	014 981 4405
HD 4/02 DG-10		745.736-738-739-741
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Input shaft front	*	625920067
Output shaft front	NJ 1014 F	007 981 0201
Output shaft rear	6211 C3	002 981 8125
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905
HD 4/02 DG-10 Brazil		745.525-596
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Input shaft front	*	000625036312
Output shaft front	NJ 1014 F	007 981 0201
Output shaft rear	*	000625036211
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905
HD 4/02 GD-10		745.700-702-730-732
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Input shaft front	*	625920067
Output shaft front	NJ 1014 F	007 981 0201
Output shaft rear	6211 C3	002 981 8125
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905
HD 4/03 D-10		745.701-703-731-733-737-740-742-881
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

POSITION	Fersa	OEM
HD 4/03 D-10 Brazil		<i>745.521-526-594-595-597</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HD 4/21 DG10		<i>744.803-807-809-830-832-834-842-845-854-856-858-860-862-863-868-870-876</i>
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	33114 F	002 981 9705
Differential left	33114 F	002 981 9705
Input shaft front	*	000625036312
Output shaft front	*	000625036014
Output shaft rear	*	000625036211
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HD 4/21 G		<i>744.803-807-809-830-832-834-842-845-854-856-858-860-862-863-868-870-876</i>
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	33114 F	002 981 9705
Differential left	33114 F	002 981 9705
Input shaft front	*	625920067
Output shaft front	*	003 981 4825
Output shaft rear	6211 C3	002 981 8125

HD 4/21 G-10		<i>744.803-830-834-842-845-854-856</i>
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	33114 F	002 981 9705
Differential left	33114 F	002 981 9705
Input shaft front	*	625920067
Output shaft front	*	003 981 4825
Output shaft rear	6211 C3	002 981 8125
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HD 4/21 G-10 Brazil		<i>743.102-130-198</i>
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	*	
Differential left	*	
Input shaft front	*	000625036312
Output shaft front	*	000625036014
Output shaft rear	*	000625036211
Inboard	598/593 X	003 981 1405
Outboard	33114 F	003 981 6605

1 \ Differential

POSITION	Fersa	OEM
HD 4/21 GS-10 Brazil		743.196
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	*	
Differential left	*	
Input shaft front	*	000625036312
Output shaft front	*	000625036014
Output shaft rear	*	000625036211
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HD 4/22		
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	*	
Differential right	33114 F	002 981 9705
Differential left	33114 F	002 981 9705

HD 4/22 D-10		744.808-810-859-861-871-877
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	33114 F	002 981 9705
Differential left	33114 F	002 981 9705
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HD 4/22 DG-10		744.869
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	33114 F	002 981 9705
Differential left	33114 F	002 981 9705
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HD 4/22-10		744.832
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	33114 F	002 981 9705
Differential left	33114 F	002 981 9705
Input shaft front	*	625920067
Output shaft front	*	003 981 4825
Output shaft rear	6211 C3	002 981 8125
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HD 4/22-10		744.804-831-833-835-855-857
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	33114 F	002 981 9705
Differential left	33114 F	002 981 9705
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

POSITION	Fersa	OEM
HD 4/22-10 Brazil		743.103-131-134-199
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	*	
Differential left	*	
Input shaft front	*	
Output shaft front	*	
Output shaft rear	*	
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HD 6/3 D-10		745.502-503
Bevel pinion front	*	
Bevel pinion rear	*	
Differential right	32216 F	000 981 7205
Differential left	30216 F	001 981 8505
	*	5412410215
	*	000 981 4301
Inboard	*	720032218
Outboard	32219 F	000 981 2105

HD 6/3 DG-10		745.500-501
Bevel pinion front	*	
Bevel pinion rear	*	
Differential right	32216 F	000 981 7205
Differential left	30216 F	001 981 8505
Input shaft front	*	000625046212
	*	5412410215
	*	000 981 4301
Inboard	*	720032218
Outboard	32219 F	000 981 2105

HD 7/2 DG-10		740.000-003
Bevel pinion front	32311 F	003 981 8005
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Input shaft front	*	625920067
Output shaft front	6214 C3	003 981 4925
Output shaft rear	6211 C3	002 981 8125

HD 7/2 DG-10		740.045
Bevel pinion front	32311 F	003 981 8005
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Input shaft front	*	625920067
Output shaft front	6214 C3	003 981 4925
Output shaft rear	6211 C3	002 981 8125

HD 7/2 DG-10		740.060-063-064
Bevel pinion front	32311 F	003 981 8005
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Input shaft front	*	625920067
Output shaft front	6214 C3	003 981 4925
Output shaft rear	6211 C3	002 981 8125

1 \ Differential

POSITION	Fersa	OEM
HD 7/2 DG-10		740.072-074
Bevel pinion front	32311 F	003 981 8005
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Input shaft front	*	625920067
Output shaft front	6214 C3	003 981 4925
Output shaft rear	6211 C3	002 981 8125

HD 7/2 DLG-10		740.006-007
Bevel pinion front	32311 F	003 981 8005
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Input shaft front	*	625920067
Output shaft front	6214 C3	003 981 4925
Output shaft rear	6211 C3	002 981 8125

HD 7/2 DSG-10		740.030
Bevel pinion front	32311 F	003 981 8005
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Input shaft front	*	625920067
Output shaft front	6214 C3	003 981 4925
Output shaft rear	6211 C3	002 981 8125

HD 7/2 DSG-10		740.033-034
Bevel pinion front	32311 F	003 981 8005
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Input shaft front	*	625920067
Output shaft front	6214 C3	003 981 4925
Output shaft rear	6211 C3	002 981 8125

HD 7/5 DG-10		740.009
Bevel pinion front	32311 F	003 981 8005
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Input shaft front	*	625920067
Output shaft front	6214 C3	003 981 4925
Output shaft rear	6211 C3	002 981 8125

HD 7/5 DG-10		740.061-062
Bevel pinion front	32311 F	003 981 8005
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Input shaft front	*	625920067
Output shaft front	6214 C3	003 981 4925
Output shaft rear	6211 C3	002 981 8125

POSITION	Fersa	OEM
HD 7/09 DG-10		<i>740.500</i>
Bevel pinion front	32313 BF	005 981 0505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205
Input shaft front	*	625920066
Output shaft front (Old Type)	*	000625036216
Output shaft front (New type)	*	000000 000759
Output shaft rear	6212 C3	005 981 5925

HD 7/9		<i>From 740.500 to 740.550</i>
Bevel pinion front	32313 BF	003 981 7005
Bevel pinion rear	32314 BF	003 981 3105
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205
Input shaft front	*	625920066
Output shaft front	*	759
Output shaft rear	6212 C3	005 981 5925

HD 7/11 DG-9		<i>740.001-004</i>
Bevel pinion front	32311 F	003 981 8005
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Input shaft front	*	625920067
Output shaft front	6214 C3	003 981 4925
Output shaft rear	6211 C3	002 981 8125

HD 7/14		<i>From 740.500 to 740.550</i>
Bevel pinion front	32313 BF	003 981 7005
Bevel pinion rear	32314 BF	003 981 3105
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205
Input shaft front	*	625920066
Output shaft front	*	759
Output shaft rear	6212 C3	005 981 5925

HD 7/014 DG-16		<i>740.539-544</i>
Bevel pinion front	32313 BF	005 981 0505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205
Input shaft front	*	625920066
Output shaft front (Old Type)	*	000625036216
Output shaft front (New type)	*	759
Output shaft rear	6212 C3	005 981 5925

HD 7/014 DGS-16		<i>740.501</i>
Bevel pinion front	32313 BF	005 981 0505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205
Input shaft front	*	625920066
Output shaft front (Old Type)	*	000625036216
Output shaft front (New type)	*	759
Output shaft rear	6212 C3	005 981 5925

1 \ Differential

POSITION	Fersa	OEM
HD 7/014 DGS-16		<i>740.549</i>
Bevel pinion front	32313 BF	005 981 0505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205
Input shaft front	*	625920066
Output shaft front (Old Type)	*	000625036216
Output shaft front (New type)	*	759
Output shaft rear	6212 C3	005 981 5925

HD 7/014 DGS-16 Turkey		
Bevel pinion	32313 BF	005 981 0505
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205
Input shaft front	*	000625036313
Output shaft front (Old Type)	*	000625036216
Output shaft front (New type)	*	759
Output shaft rear	6212 C3	005 981 5925

HD 7/16		<i>From 740.500 to 740.550</i>
Bevel pinion front	32313 BF	003 981 7005
Bevel pinion rear	32314 BF	003 981 3105
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205
Input shaft front	*	625920066
Output shaft front	*	759
Output shaft rear	6212 C3	005 981 5925

HD 7/016 DG-13		<i>740.502-530-531-536-537-538-540</i>
Bevel pinion front	32313 BF	005 981 0505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205
Input shaft front	*	625920066
Output shaft front (Old Type)	*	000625036216
Output shaft front (New type)	*	759
Output shaft rear	6212 C3	005 981 5925

HD 7/016 DG-13		<i>740.545-546-547-548</i>
Bevel pinion front	32313 BF	005 981 0505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205
Input shaft front	*	625920066
Output shaft front (Old Type)	*	000625036216
Output shaft front (New type)	*	759
Output shaft rear	6212 C3	005 981 5925

HD 7/016 DSG-13		<i>740.532</i>
Bevel pinion front	32313 BF	005 981 0505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205
Input shaft front	*	625920066
Output shaft front (Old Type)	*	000625036216
Output shaft front (New type)	*	759
Output shaft rear	6212 C3	005 981 5925

POSITION	Fersa	OEM
HD 7/19 DG-13		<i>740.002-005-008-031</i>
Bevel pinion front	32311 F	003 981 8005
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Input shaft front	*	625920067
Output shaft front	6214 C3	003 981 4925
Output shaft rear	6211 C3	002 981 8125

HD 7/19 DG-13		<i>740.035-036-037-039-040-041-042-043</i>
Bevel pinion front	32311 F	003 981 8005
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Input shaft front	*	625920067
Output shaft front	6214 C3	003 981 4925
Output shaft rear	6211 C3	002 981 8125

HD 7/19 DG-13		<i>740.065-066-067-068-069-070-071</i>
Bevel pinion front	32311 F	003 981 8005
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Input shaft front	*	625920067
Output shaft front	6214 C3	003 981 4925
Output shaft rear	6211 C3	002 981 8125

HD 7/19 DG-13 Turkey		<i>746.450-461</i>
Bevel pinion	32311 F	003 981 8005
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Input shaft front	*	000625036312
Output shaft front	6214 C3	003 981 4925
Output shaft rear	6211 C3	002 981 8125

HD 7/19 DGS-13		<i>740.046</i>
Bevel pinion front	32311 F	003 981 8005
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Input shaft front	*	625920067
Output shaft front	6214 C3	003 981 4925
Output shaft rear	6211 C3	002 981 8125

HD 7/19 DGS-13		<i>740.073-079</i>
Bevel pinion front	32311 F	003 981 8005
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Input shaft front	*	625920067
Output shaft front	6214 C3	003 981 4925
Output shaft rear	6211 C3	002 981 8125

1 \ Differential

POSITION	Fersa	OEM
HD 7/19 DGS-13 Turkey		746.451-453-460-462
Bevel pinion	32311 F	003 981 8005
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Input shaft front	*	000625036312
Output shaft front	6214 C3	003 981 4925

HD 7/19 DSG-13		740.032
Bevel pinion front	32311 F	003 981 8005
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
Input shaft front	*	625920067
Output shaft front	6214 C3	003 981 4925
Output shaft rear	6211 C3	002 981 8125

HD 7/55		740.893-895-897-898 / 748.263-273-275
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 3105
Differential right	32020 XF	017 981 7905
Differential left	*	006 981 7605
Input shaft front	31313 F	942 981 0405
Output shaft front	32215 F	942 981 0205
Output shaft rear	6212 C3	005 981 5925

HD 7/55 DGS-13		
Bevel pinion front	32311 BF	944 350 0149
Bevel pinion rear	32313 BF	942 981 0505
Differential right	32017 XF	017 981 8205
Differential left	*	006 981 7605
Input shaft front	31313 F	942 981 0405
Output shaft front	30215 F	944 350 0049
Output shaft intermediate	*	944 981 0025
Output shaft rear	*	944 981 0025

HD 7/56		740.893-895-897-898 / 748.263-273-275
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 3105
Differential right	32020 XF	017 981 7905
Differential left	*	006 981 7605
Input shaft front	31313 F	942 981 0405
Output shaft front	32215 F	942 981 0205
Output shaft rear	6212 C3	005 981 5925

HD 7/56 DGS-13		
Bevel pinion front	32311 BF	944 350 0149
Bevel pinion rear	32313 BF	942 981 0505
Differential right	32017 XF	017 981 8205
Differential left	*	006 981 7605
Input shaft front	31313 F	942 981 0405
Output shaft front	30215 F	944 350 0049
Output shaft intermediate	*	944 981 0025
Output shaft rear	*	944 981 0025

POSITION	Fersa	OEM
HD 7/57 740.893-895-897-898 / 748.263-273-275		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 3105
Differential right	32020 XF	017 981 7905
Differential left	*	006 981 7605
Input shaft front	31313 F	942 981 0405
Output shaft front	32215 F	942 981 0205
Output shaft rear	6212 C3	005 981 5925

HD 7/58 740.893-895-897-898 / 748.263-273-275		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 3105
Differential right	32020 XF	017 981 7905
Differential left	*	006 981 7605
Input shaft front	31313 F	942 981 0405
Output shaft front	32215 F	942 981 0205
Output shaft rear	6212 C3	005 981 5925

HH 4/04 D-12 745.664		
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HH 4/04 D-12 745.616		
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HH 4/05 D-10 Brazil 746.870		
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HH 4/07 DL-10 Brazil 745.982		
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

1 \ Differential

POSITION	Fersa	OEM
HH 4/12 D-10		<i>743.084-085</i>
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HH 4/ 12 D-10 Brazil		<i>743.040-042</i>
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HH 4/12 D-10 Brazil		<i>743.065-070</i>
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HH 4/12 D-10 Brazil		<i>743.024-028-029</i>
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HH 4/12 D-10 Brazil		<i>743.002-017-025-034-035</i>
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HH 4/12-10 Brazil		<i>743.001-007</i>
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	*	
Differential left	*	
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

POSITION	Fersa	OEM
HH 4/19 D-10		
Bevel pinion front	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Bevel pinion rear	HM 911244/HM 911216	000 981 4005
Differential left	47487/47420	002 981 1605
Differential right	47487/47420	002 981 1605

HH 4/19 D-10		744.507
Bevel pinion front	F 15158	007 981 8905
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 1/2-3,3		741.001-030-031
Bevel pinion front	*	002 981 9405
Bevel pinion rear	*	002 981 9405
Bevel pinion pilot	*	003 981 2801
Differential right	32210 F	001 981 8905
Differential left	32210 F	001 981 8905
Inboard	*	000 981 8605
Outboard	32210 F	001 981 8905

HL 1/3-4,5		741.200
Bevel pinion front	*	001 981 9405
Bevel pinion rear	*	324 981 0001
Differential right	28985/28920	001 981 6005
Differential left	28985/28920	001 981 6005
Inboard	3984/3920	001 981 0405
Outboard	33895/33820	002 981 0505

HL 1/3-4,5		741.200-201-202-203
Bevel pinion front	*	002 981 9405
Bevel pinion rear	*	003 981 2801
Differential right	28985/28920	001 981 6005
Differential left	28985/28920	001 981 6005
Inboard	3984/3920	001 981 0405
Outboard	33895/33820	002 981 0505

HL 1/8-4,7		741.560-570
Bevel pinion front	*	007 981 6905
Bevel pinion rear	*	003 981 2801
Differential right	32210 F	001 981 8905
Differential left	32210 F	001 981 8905
Inboard	32014 XF	005 981 9505
Outboard	32011 XF	006 981 5605

HL 1/9-5,6		741.580
Bevel pinion front	*	007 981 6905
Bevel pinion rear	*	003 981 2801
Differential right	32210 F	001 981 8905
Differential left	32210 F	001 981 8905
Inboard	33015 F	002 981 9505
Outboard	33011 F	003 981 4305

1 \ Differential

POSITION	Fersa	OEM
HL 2/2 L-4,8		<i>742.002</i>
Bevel pinion front	*	001 981 9405
Bevel pinion rear	*	001 981 9405
Bevel pinion pilot	*	003 981 2901
Differential right	28985/28920	001 981 6005
Differential left	28985/28920	001 981 6005
Inboard	3984/3920	001 981 0405
Outboard	33895/33820	002 981 0505

HL 2/2-4,8		<i>742.001</i>
Bevel pinion front	*	001 981 9405
Bevel pinion rear	*	001 981 9405
Bevel pinion pilot	*	003 981 2901
Differential right	28985/28920	001 981 6005
Differential left	28985/28920	001 981 6005
Inboard	3984/3920	001 981 0405
Outboard	33895/33820	002 981 0505

HL 2/3-5,7		<i>742.100</i>
Bevel pinion front	F 15280	002 981 8805
Bevel pinion rear	F 15280	002 981 8805
Bevel pinion pilot	*	003 981 2901
Differential right	28985/28920	001 981 6005
Differential left	28985/28920	001 981 6005
Inboard	47490/47420	000 980 7402
Outboard	33111 F	006 981 8205

HL 2/4 L-6,4		<i>742.202-204-230</i>
Bevel pinion front	F 15280	002 981 8805
Bevel pinion rear	F 15280	002 981 8805
Bevel pinion pilot	*	003 981 2901
Differential right	F 15258	008 981 9405
Differential left	F 15258	008 981 9405
Inboard	JM 714249/JM 714210	008 981 5305
Outboard	F 15258	008 981 9405

HL 2/4-6,4		<i>742.201-203</i>
Bevel pinion front	F 15280	002 981 8805
Bevel pinion rear	F 15280	002 981 8805
Bevel pinion pilot	*	003 981 2901
Differential right	F 15258	008 981 9405
Differential left	F 15258	008 981 9405
Inboard	JM 714249/JM 714210	008 981 5305
Outboard	F 15258	008 981 9405

HL 2/47		
Bevel pinion front	F 15270	014 981 7605
Bevel pinion rear	F 15270	014 981 7605
Differential right	32020 XF	017 981 7905
Differential left	32014 XF	017 981 8005

HL 2/5-4,5		<i>741.300-301-302-304-330-331-332-333-335-337</i>
Bevel pinion front	*	001 981 9405
Bevel pinion rear	*	324 981 0001
Differential right	28985/28920	001 981 6005
Differential left	28985/28920	001 981 6005
Inboard	3984/3920	001 981 0405
Outboard	33895/33820	002 981 0505

POSITION	Fersa	OEM
HL 2/5-4,5 Brazil		743.400-401-431
Bevel pinion	F 15280	002 981 8705
Bevel pinion pilot	*	003 981 2901
Differential right	F 15258	002 981 8005
Differential left	F 15258	002 981 8005
Inboard	3984/3920	001 981 0405
Outboard	33895/33820	002 981 0505

HL 2/7-7,7		742.300
Bevel pinion front	F 15280	002 981 8805
Bevel pinion rear	F 15280	002 981 8805
Bevel pinion pilot	*	003 981 2901
Differential right	F 15258	008 981 9405
Differential left	F 15258	008 981 9405
Inboard	580/572	004 981 4605
Outboard	*	000 981 4605

HL 2/9-4,7		741.303-334-336
Bevel pinion front	*	001 981 9405
Bevel pinion rear	*	324 981 0001
Differential right	28985/28920	001 981 6005
Differential left	28985/28920	001 981 6005
Inboard	3984/3920	001 981 0405
Outboard	33895/33820	002 981 0505

HL 2/9-4,7 Turkey		741.702
Bevel pinion front	*	001 981 9405
Bevel pinion rear	*	001 981 9405
Bevel pinion pilot	*	003 981 2901
Differential right	28985/28920	001 981 6005
Differential left	28985/28920	001 981 6005
Inboard	3984/3920	001 981 0405
Outboard	33895/33820	002 981 0505

HL 2/11 D-5,8		742.441-442-444-445-446
Bevel pinion front	F 15280	002 981 8805
Bevel pinion rear	F 15280	002 981 8805
Bevel pinion pilot	*	003 981 2901
Differential right	F 15258	008 981 9405
Differential left	F 15258	008 981 9405

HL 2/11 D-5,8		742.443
Bevel pinion front	*	008 981 1605
Bevel pinion rear	*	008 981 1605
Bevel pinion pilot	*	003 981 2901
Differential right	F 15258	008 981 9405
Differential left	F 15258	008 981 9405

HL 2/11 D-5,8		742.420-421-430-432-433-434-435-436-437-438-439
Bevel pinion front	F 15280	002 981 8805
Bevel pinion rear	F 15280	002 981 8805
Bevel pinion pilot	*	003 981 2901
Differential right	F 15258	008 981 9405
Differential left	F 15258	008 981 9405
Inboard	33015 F	002 981 9505
Outboard	33011 F	003 981 4305

1 \ Differential

POSITION	Fersa	OEM
HL 2/11 D-5,8		742.440
Bevel pinion front	*	008 981 1605
Bevel pinion rear	*	008 981 1605
Bevel pinion pilot	*	003 981 2901
Differential right	F 15258	008 981 9405
Differential left	F 15258	008 981 9405
Inboard	33015 F	002 981 9505
Outboard	33011 F	003 981 4305
HL 2/12 D-4,5		742.400-410-411-412-413-414
Bevel pinion front	*	001 981 9405
Bevel pinion rear	*	001 981 9405
Bevel pinion pilot	*	003 981 2901
Differential right	28985/28920	001 981 6005
Differential left	28985/28920	001 981 6005
Inboard	32014 XF	005 981 9505
Outboard	32011 XF	006 981 5605
HL 2/13 D-6,4		742.450-460-461
Bevel pinion	F 15280	002 981 8805
Bevel pinion pilot	*	003 981 2901
Differential right	F 15258	008 981 9405
Differential left	F 15258	008 981 9405
Inboard	JM 714249/JM 714210	008 981 5305
Outboard	F 15258	008 981 9405
HL 2/13 D-6,4		742.462
Bevel pinion	*	008 981 1605
Bevel pinion pilot	*	003 981 2901
Differential right	32014 XF	005 981 9505
Differential left	32014 XF	005 981 9505
Inboard	32016 XF	007 981 9305
Outboard	*	008 981 8305
HL 2/14 D-6,9		742.463-464-465
Bevel pinion	F 15280	002 981 8805
Bevel pinion pilot	*	003 981 2901
Differential right	F 15258	008 981 9405
Differential left	F 15258	008 981 9405
Inboard	*	720032016
Outboard	*	008 981 8305
HL 2/15 S-5,8		742.487
Bevel pinion	*	008 981 1605
Bevel pinion pilot	*	003 981 2901
Differential right	F 15258	008 981 9405
Differential left	F 15258	008 981 9405
Inboard	33015 F	002 981 9505
Outboard	33011 F	003 981 4305
HL 2/15-5,8		742.483-484-485-486
Bevel pinion	*	008 981 1605
Bevel pinion pilot	*	003 981 2901
Differential right	F 15258	008 981 9405
Differential left	F 15258	008 981 9405
Inboard	33015 F	002 981 9505
Outboard	33011 F	003 981 4305

POSITION	Fersa	OEM
HL 2/15-5,8		742.470-471-480-481-482
Bevel pinion	*	008 981 1605
Bevel pinion pilot	*	003 981 2901
Differential right	F 15258	008 981 9405
Differential left	F 15258	008 981 9405
Inboard	33015 F	002 981 9505
Outboard	33011 F	003 981 4305

HL 2/155,9 Brazil		743.413
Bevel pinion	F 15280	002 981 8705
Bevel pinion pilot	*	003 981 2901
Differential right	F 15258	002 981 8005
Differential left	F 15258	002 981 8005
Inboard	33015 F	002 981 9505
Outboard	33011 F	003 981 4305

HL 2/16-4,7 Brazil		743.410-433
Bevel pinion	F 15280	002 981 8705
Bevel pinion pilot	*	003 981 2901
Differential right	F 15258	002 981 8005
Differential left	F 15258	002 981 8005
Inboard	3984/3920	001 981 0405
Outboard	33895/33820	002 981 0505

HL 2/17-5,9 Brazil		743.411-432
Bevel pinion	F 15280	002 981 8705
Bevel pinion pilot	*	003 981 2901
Differential right	F 15258	002 981 8005
Differential left	F 15258	002 981 8005
Inboard	33015 F	002 981 9505
Outboard	33011 F	003 981 4305

HL 2/30		
Bevel pinion front	F 15270	014 981 7605
Bevel pinion rear	F 15270	014 981 7605
Differential right	32020 XF	017 981 7905
Differential left	32014 XF	017 981 8005

HL 2/31		
Bevel pinion front	F 15270	014 981 7605
Bevel pinion rear	F 15270	014 981 7605
Differential right	32020 XF	017 981 7905
Differential left	32014 XF	017 981 8005

HL 2/43		
Bevel pinion front	F 15270	014 981 7605
Bevel pinion rear	F 15270	014 981 7605
Differential right	32020 XF	017 981 7905
Differential left	32014 XF	017 981 8005

HL 2/44		
Bevel pinion front	F 15270	014 981 7605
Bevel pinion rear	F 15270	014 981 7605
Differential right	32020 XF	017 981 7905
Differential left	32014 XF	017 981 8005

POSITION	Fersa	OEM
HL 2/46		
Bevel pinion front	F 15270	014 981 7605
Bevel pinion rear	F 15270	014 981 7605
Differential right	32020 XF	017 981 7905
Differential left	32014 XF	017 981 8005

HL 4/01-10		745.600-604
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905
Bevel pinion front	F 15183	006 981 1705

HL 4/01-10		745.630-631-632
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/01-10		745.633-634-635
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/01 D-10		745.663-667-668-669-670-672-674-676
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/01 D-10		745.648-650-654-655-656-657-659-660
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

POSITION	Fersa	OEM
HL 4/01 D-10		<i>745.750-752-754-756</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

POSITION	Fersa	OEM
HL 4/01 D-10		<i>745.760-761-765</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

POSITION	Fersa	OEM
HL 4/01 D-10		<i>745.677-678-679</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

POSITION	Fersa	OEM
HL 4/01 D-10		<i>745.620-622</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

POSITION	Fersa	OEM
HL 4/01 D-10		<i>745.601-606-611</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

POSITION	Fersa	OEM
HL 4/01 D-10		<i>745.636-637-638-642-643-645</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

1 \ Differential

POSITION	Fersa	OEM
HL 4/01 D-10 Brazil		<i>745.950-952-953-954</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/01 D-10 Brazil		<i>745.510-512-516</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/01 D-10 Brazil		<i>746.580-581-583-584-585-598-860-861</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/01 DL-10		<i>745.639-644-646</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/01 DL-10		<i>745.848</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/01 DL-10		<i>745.671-673</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

POSITION	Fersa	OEM
HL 4/01 DL-10		745.661
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

POSITION	Fersa	OEM
HL 4/01 DL-10		745.762
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

POSITION	Fersa	OEM
HL 4/01 DL-10		745.680
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

POSITION	Fersa	OEM
HL 4/01 DL-10		745.613-614-624
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

POSITION	Fersa	OEM
HL 4/01 DL-10		745.603-607
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

POSITION	Fersa	OEM
HL 4/01 DL-10		745.758
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

1 \ Differential

POSITION	Fersa	OEM
HL 4/01 DL-11,5		<i>745.805</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/01 L-10		<i>745.602-605</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/05 D-9,2		<i>745.810-820-822-824-825-826-827</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/06 D-12		<i>745.649-653</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/06 D-12		<i>745.681-682-683-684-685-688-689</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/06 D-12		<i>745.608-610</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

POSITION	Fersa	OEM
HL 4/06 D-12		<i>745.755-757</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

POSITION	Fersa	OEM
HL 4/06 D-12		<i>745.763-772-773-766-767</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

POSITION	Fersa	OEM
HL 4/06 D-12		<i>745.621-623</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

POSITION	Fersa	OEM
HL 4/06 DL-12		<i>745.759</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

POSITION	Fersa	OEM
HL 4/06 DL-12		<i>745.764-774-768-769-770-771</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

POSITION	Fersa	OEM
HL 4/06 DL-12		<i>745.686-687</i>
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

1 \ Differential

POSITION	Fersa	OEM
HL 4/06 DL-12		745.625
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/06 DL-12		745.609
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/07 D-9,4		745.666-675
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/07 D-9,4		745.647
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/07 D-9,4		745.751-753
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/08 D-10,6		745.811-830-831-832
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

POSITION	Fersa	OEM
HL 4/09 D-9,2		745.812
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/12 D-10 Brazil		743.080
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 4/14-8,8 BRAZIL		743.012
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	*	
Differential left	*	
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 4/16 L-7,7		
Bevel pinion front	HM 911244/HM 911216	000 981 4005
Bevel pinion pilot	F 19043	002 981 9501
Bevel pinion rear	F 15158	007 981 8905
Differential left	47487/47420	002 981 1605
Differential right	47487/47420	002 981 1605

HL 4/16 L-7,7		744.309
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	580/572	004 981 4605
Outboard	*	000 981 4605

HL 4/16-7,7		
Bevel pinion front	HM 911244/HM 911216	000 981 4005
Bevel pinion pilot	F 19043	002 981 9501
Bevel pinion rear	F 15158	007 981 8905
Differential left	47487/47420	002 981 1605
Differential right	47487/47420	002 981 1605

HL 4/16-7,7		744.300-301-302-330-331-332
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	580/572	004 981 4605
Outboard	*	000 981 4605

1 \ Differential

POSITION	Fersa	OEM
HL 4/16-7,7		744.333-341-342-344-345-346
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	580/572	004 981 4605
Outboard	*	000 981 4605

HL 4/17 D-9,2		
Bevel pinion front	HM 911244/HM 911216	000 981 4005
Bevel pinion pilot	F 19043	002 981 9501
Bevel pinion rear	F 15158	007 981 8905
Differential left	47487/47420	002 981 1605
Differential right	47487/47420	002 981 1605

HL 4/17 D-9,2		744.442-443
Bevel pinion front	F 15158	007 981 8905
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	32217 F	002 981 1705
Outboard	32214 F	002 981 5605

HL 4/17 D-9,2		744.413-414
Bevel pinion front	F 15158	007 981 8905
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	32217 F	002 981 1705
Outboard	32214 F	002 981 5605

HL 4/17 L-9,2		
Bevel pinion front	HM 911244/HM 911216	000 981 4005
Bevel pinion pilot	F 19043	002 981 9501
Bevel pinion rear	F 15158	007 981 8905
Differential left	47487/47420	002 981 1605
Differential right	47487/47420	002 981 1605

HL 4/17 L-9,2		744.412
Bevel pinion front	F 15158	007 981 8905
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	32217 F	002 981 1705
Outboard	32214 F	002 981 5605

HL 4/17 S-9,2		
Bevel pinion front	HM 911244/HM 911216	000 981 4005
Bevel pinion pilot	F 19043	002 981 9501
Bevel pinion rear	F 15158	007 981 8905
Differential left	47487/47420	002 981 1605
Differential right	47487/47420	002 981 1605

POSITION	Fersa	OEM
HL 4/17 S-9,2		744.435
Bevel pinion front	F 15158	007 981 8905
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	32217 F	002 981 1705
Outboard	32214 F	002 981 5605

HL 4/17 S-9,2		744.402
Bevel pinion front	F 15158	007 981 8905
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	32217 F	002 981 1705
Outboard	32214 F	002 981 5605

HL 4/1-7,6		
Bevel pinion front	HM 911244/HM 911216	000 981 4005
Bevel pinion pilot	F 19043	002 981 9501
Bevel pinion rear	F 15158	007 981 8905
Differential left	47487/47420	002 981 1605
Differential right	47487/47420	002 981 1605

HL 4/1-7,6		744.303-304-305
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	32216 F	000 981 7205
Outboard	*	000 981 4605

HL 4/1-7,6		744.334-336-337-338
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	32216 F	000 981 7205
Outboard	*	000 981 4605

HL 4/4-8,8		
Bevel pinion front	HM 911244/HM 911216	000 981 4005
Bevel pinion pilot	F 19043	002 981 9501
Bevel pinion rear	F 15158	007 981 8905
Differential left	47487/47420	002 981 1605
Differential right	47487/47420	002 981 1605

HL 4/4-8,8		744.339-340
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	32216 F	000 981 7205
Outboard	32214 F	002 981 5605

1 \ Differential

POSITION	Fersa	OEM
HL 4/4-8,8		744.432-433-436-437
Bevel pinion front	F 15158	007 981 8905
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	32217 F	002 981 1705
Outboard	32214 F	002 981 5605

HL 4/4-8,8		744.408-409
Bevel pinion front	F 15158	007 981 8905
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	32217 F	002 981 1705
Outboard	32214 F	002 981 5605

HL 4/7,6 Brazil		743.302-331-332-333
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	32216 F	000 981 7205
Outboard	*	000 981 4605

HL 4/7,6 Brazil		743.393-394-395-396-397-398-399
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	32216 F	000 981 7205
Outboard	*	000 981 4605

HL 4/8-6,3		
Bevel pinion front	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Bevel pinion rear	HM 911244/HM 911216	000 981 4005
Differential left	47487/47420	002 981 1605
Differential right	47487/47420	002 981 1605

HL 4/8-6,30		744.506
Bevel pinion front	F 15158	007 981 8905
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

POSITION	Fersa	OEM
HL 4/8-10		744.508-532
Bevel pinion front	F 15158	007 981 8905
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 4/8-10		
Bevel pinion front	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Bevel pinion rear	HM 911244/HM 911216	000 981 4005
Differential left	47487/47420	002 981 1605
Differential right	47487/47420	002 981 1605

HL 4/8-10		
744.434-438-500-501-502		
Bevel pinion front	F 15158	007 981 8905
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 4/8 D-10		
Bevel pinion front	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Bevel pinion rear	HM 911244/HM 911216	000 981 4005
Differential left	47487/47420	002 981 1605
Differential right	47487/47420	002 981 1605

HL 4/8 D-10		
744.505-531		
Bevel pinion front	F 15158	007 981 8905
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 4/8 L-10		
Bevel pinion front	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Bevel pinion rear	HM 911244/HM 911216	000 981 4005
Differential left	47487/47420	002 981 1605
Differential right	47487/47420	002 981 1605

HL 4/8 L-10		
744.504-530		
Bevel pinion front	F 15158	007 981 8905
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

1 \ Differential

POSITION	Fersa	OEM
HL 4/17-9,2		744.400-401-405-407-430-431
Bevel pinion front	F 15158	007 981 8905
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	32217 F	002 981 1705
Outboard	32214 F	002 981 5605

HL 4/17-9,2		
Bevel pinion front	HM 911244/HM 911216	000 981 4005
Bevel pinion pilot	F 19043	002 981 9501
Bevel pinion rear	F 15158	007 981 8905
Differential left	47487/47420	002 981 1605
Differential right	47487/47420	002 981 1605

HL 4/23 L-7,7		744.311
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	580/572	004 981 4605
Outboard	*	000 981 4605

HL 4/23-7,7		744.310
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	580/572	004 981 4605
Outboard	*	000 981 4605

HL 4/23-7,7		
Bevel pinion front	HM 911244/HM 911216	000 981 4005
Bevel pinion pilot	F 19043	002 981 9501
Bevel pinion rear	F 15158	007 981 8905
Differential left	47487/47420	002 981 1605
Differential right	47487/47420	002 981 1605

HL 4/25 D-7,6 Brazil		743.336
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard (Up to Axle 589554)	32216 F	000 981 7205
Outboard (Up to Axle 589554)	*	000 981 4605
Inboard (From Axle 589555)	33215 F	002 981 8605
Outboard (From Axle 589555)	33019 F	002 981 9005

POSITION	Fersa	OEM
HL 4/25 D-7,6 Brazil		<i>743.338-339-340-342</i>
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	32216 F	000 981 7205
Outboard	*	000 981 4605

HL 4/25 D-7,6 Brazil		<i>743.300</i>
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard (Only valid for LK 1113 (BM 344019))	32216 F	000 981 7205
Inboard (Only valid for OF 1113 (BM 344058))	33215 F	002 981 8605
Outboard (Only valid for LK 1113 (BM 344019))	*	000 981 4605
Outboard (Only valid for OF 1113 (BM 344058))	33019 F	002 981 9005

HL 4/25 D-7,6 Brazil		<i>743.301-305-306-307-334</i>
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	32216 F	000 981 7205
Outboard	*	000 981 4605

HL 4/25-7,6 Brazil		<i>743.304</i>
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	32216 F	000 981 7205
Outboard	*	000 981 4605

HL 4/25-7,6 Brazil		<i>743.335</i>
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	32216 F	000 981 7205
Outboard	*	000 981 4605

HL 4/26 D-9,2 Brazil		<i>743.064-066-071-077</i>
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

1 \ Differential

POSITION	Fersa	OEM
HL 4/26 D-9,2 Brazil		<i>743.023-057-058-061-062</i>
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 4/26 D-9,2 Brazil		<i>743.003-004-014-021-030</i>
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 4/26 D-9,2 Brazil		<i>743.037-038-041-043-044-045-046-047</i>
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 4/27 D-10 Brazil		<i>743.005-015</i>
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 4/27 D-10 Brazil		<i>743.099</i>
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 4/27 D-10 Brazil		<i>743.072-075</i>
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

POSITION	Fersa	OEM
HL 4/27 D-10 Brazil		743.022-026-059-060
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 4/27 D-10 Brazil		743.039-048-056
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 4/28 D-7,8		744.913-914-915-916-917-918-919
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	580/572	004 981 4605
Outboard	*	000 981 4605

HL 4/28 D-7,8		744.900-902-903-904-905-906-907-908-909-910-911-912
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	580/572	004 981 4605
Outboard	*	000 981 4605

HL 4/29 D-9,2		744.920-930-932-938
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 4/30 D-6,4		744.952-953-957-958-959-978-979
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	*	720032016
Outboard	*	000 981 4605

1 \ Differential

POSITION	Fersa	OEM
HL 4/30 DS-6,4		744.950-954-955
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	*	720032016
Outboard	*	000 981 4605

HL 4/31 DS-7,0		744.936-937-939-940-942
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 4/32 D-10,6		744.921-949-947-948
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33117 F	005 981 9905
Outboard	32214 F	002 981 5605

HL 4/35 D-10,6		744.965
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33020 F	005 981 8505
Outboard	33215 F	002 981 8605

HL 4/35 D-6,4		744.960
Bevel pinion front	*	011 981 3305
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	*	720032016
Outboard	*	000 981 4605

HL 4/35 D-7,7		744.961
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	32018 XF	004 981 4305

POSITION	Fersa	OEM
HL 4/35 D-7,8		744.963
Bevel pinion front	*	011 981 3305
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	580/572	004 981 4605
Outboard	*	000 981 4605

HL 4/35 D-9,2		744.964
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	32214 F	002 981 5605

HL 4/035 D-10,6		745.791-799
Bevel pinion	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/035 D-9,2		745.790
Bevel pinion	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33019 F	002 981 9005
Outboard	33116 F	012 981 4005

HL 4/36 D-7,7		744.962
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	32018 XF	004 981 4305

HL 4/038 D-10		745.780
Bevel pinion	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/038 D-12		745.781
Bevel pinion	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

1 \ Differential

POSITION	Fersa	OEM
HL 4/038 D-9,4		745.786
Bevel pinion	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/039 D-10		745.782-784
Bevel pinion	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/039 D-12		745.783-785
Bevel pinion	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/039 DL-12		745.787
Bevel pinion	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HL 4/40		771.000-001-005-003
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	F 15159	006 981 3505
Differential right	32018 XF	006 981 0005
Differential left	32018 XF	006 981 0005

HL 4/40		770.001-002-003
Bevel pinion front	*	011 981 3405
Bevel pinion rear	F 15158	007 981 8905
Differential right (With differential lock)	*	004 981 2905
Differential left (With differential lock)	*	004 981 2905
Differential right (Without differential lock)	47487/47420	002 981 1605
Differential left (Without differential lock)	47487/47420	002 981 1605

HL 4/60 D-10		743.083-098
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

POSITION	Fersa	OEM
HL 4/60 D-10 Brazil		743.076-081
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 4/60 D-7,6		743.343-344
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	32216 F	000 981 7205
Outboard	*	000 981 4605

HL 4/60-10 Brazil		743.082
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 5/1 S-10		745.100
Bevel pinion front	F 15082	001 981 9905
Bevel pinion rear	F 15083	003 981 1205
Bevel pinion pilot	F 19015	003 981 1701
Differential right	32020 XF	001 981 7205
Differential left	32020 XF	001 981 7205
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 5/1 Z-10		745.101-109-139-142
Bevel pinion front	F 15082	001 981 9905
Bevel pinion rear	F 15083	003 981 1205
Bevel pinion pilot	F 19015	003 981 1701
Differential right	32020 XF	001 981 7205
Differential left	32020 XF	001 981 7205
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 5/2-10		745.104-105-106-107-112-114
Bevel pinion front	F 15082	001 981 9905
Bevel pinion rear	F 15083	003 981 1205
Bevel pinion pilot	F 19015	003 981 1701
Differential right	32020 XF	001 981 7205
Differential left	32020 XF	001 981 7205
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

1 \ Differential

POSITION	Fersa	OEM
HL 5/2-10 Brazil		745.036-037
Bevel pinion front	F 15082	001 981 9905
Bevel pinion rear	F 15083	003 981 1205
Bevel pinion pilot	F 19015	003 981 1701
Differential right	32020 XF	001 981 7205
Differential left	32020 XF	001 981 7205
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 5/2 D-10 Brazil		745.005-034-035
Bevel pinion front	F 15082	001 981 9905
Bevel pinion rear	F 15083	003 981 1205
Bevel pinion pilot	F 19015	003 981 1701
Differential right	32020 XF	001 981 7205
Differential left	32020 XF	001 981 7205
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 5/2 DZ-10 Brazil		745.007-008-011-012-033-038-043
Bevel pinion front	F 15082	001 981 9905
Bevel pinion rear	F 15083	003 981 1205
Bevel pinion pilot	F 19015	003 981 1701
Differential right	32020 XF	001 981 7205
Differential left	32020 XF	001 981 7205
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 5/2 S-6,5		745.113
Bevel pinion front	F 15082	001 981 9905
Bevel pinion rear	F 15083	003 981 1205
Bevel pinion pilot	F 19015	003 981 1701
Differential right	32020 XF	001 981 7205
Differential left	32020 XF	001 981 7205
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 5/2 S-10		745.148
Bevel pinion front	F 15082	001 981 9905
Bevel pinion rear	F 15083	003 981 1205
Bevel pinion pilot	F 19015	003 981 1701
Differential right	32020 XF	001 981 7205
Differential left	32020 XF	001 981 7205
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 5/2 Z-10		745.108-111-143-144-145-147
Bevel pinion front	F 15082	001 981 9905
Bevel pinion rear	F 15083	003 981 1205
Bevel pinion pilot	F 19015	003 981 1701
Differential right	32020 XF	001 981 7205
Differential left	32020 XF	001 981 7205
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

POSITION	Fersa	OEM
HL 5/2 ZL-10		745.110
Bevel pinion front	F 15082	001 981 9905
Bevel pinion rear	F 15083	003 981 1205
Bevel pinion pilot	F 19015	003 981 1701
Differential right	32020 XF	001 981 7205
Differential left	32020 XF	001 981 7205
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 5/2 ZS-10		745.131-149
Bevel pinion front	F 15082	001 981 9905
Bevel pinion rear	F 15083	003 981 1205
Bevel pinion pilot	F 19015	003 981 1701
Differential right	32020 XF	001 981 7205
Differential left	32020 XF	001 981 7205
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 5/2 ZS-10 Brazil		745.004
Bevel pinion front	F 15082	001 981 9905
Bevel pinion rear	F 15083	003 981 1205
Bevel pinion pilot	F 19015	003 981 1701
Differential right	32020 XF	001 981 7205
Differential left	32020 XF	001 981 7205
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HL 6/1		
Bevel pinion front	F 15253	014 981 2005
Bevel pinion rear	F 15254	014 981 4905
Differential right	32024 XF	014 981 5405
Differential left	32020 XF	017 981 7905
Bevel pinion front	F 15253	014 981 2005
Bevel pinion rear	F 15254	014 981 4905
Differential right	32024 XF	014 981 5405
Differential left	32020 XF	017 981 7905

HL 7/1-10		
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential left	33113 F	003 981 4105
Differential right	33113 F	003 981 4105

HL 7/1-10		740.115-116
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/1-10		740.149-140-142-144-146
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

1 \ Differential

POSITION	Fersa	OEM
HL 7/1-10		740.102-103
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/1-10		740.151-152-155-157-159-160-161-162-163
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/1-10		740.164-165-166-167-169-171-174-175
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/1-10		740.180
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/1 D-10		
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential left	33113 F	003 981 4105
Differential right	33113 F	003 981 4105

HL 7/1 D-10		740.190-191-192-196
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/1 D-10		740.104
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/1 D-10		748.934-935
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/1 D-10		740.185-186-187-189
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

POSITION	Fersa	OEM
HL 7/1 D-10		748.900-901-910-924
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/1 DL-10		
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential left	33113 F	003 981 4105
Differential right	33113 F	003 981 4105

HL 7/1 DL-10		740.901
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/1 DL-10		740.188
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/1 DL-10		748.908-909
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/1 DL-10		740.197-198
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/1 L-10		
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential left	33113 F	003 981 4105
Differential right	33113 F	003 981 4105

HL 7/1 L-10		740.117
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/1 L-10		740.106
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

1 \ Differential

POSITION	Fersa	OEM
HL 7/1 L-10		740.168-170-172
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/1 S-10		
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential left	33113 F	003 981 4105
Differential right	33113 F	003 981 4105

HL 7/1 S-10		740.141-143-145
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/1 S-10		740.150-153-154
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/02 DL-10		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 3105
Differential left	33115 F	003 981 3205
Differential right	33115 F	003 981 3205

HL 7/02 DL-10		740.386
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/3 D-10		
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential left	33113 F	003 981 4105
Differential right	33113 F	003 981 4105

HL 7/3 D-10		740.903-904-906-909-910-912-915
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/3 D-10		740.195
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

POSITION	Fersa	OEM
HL 7/3 D-10		740.113
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/3 D-10		740.136-147
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/3 D-10		740.932-936
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/3 D-10		740.100-101-110
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/3 DL-10		
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential left	33113 F	003 981 4105
Differential right	33113 F	003 981 4105

HL 7/3 DL-10		740.111-112
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/3 DS-10		
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential left	33113 F	003 981 4105
Differential right	33113 F	003 981 4105

HL 7/3 DS-10		740.130-131-132-133
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/4 D-10		
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential left	33113 F	003 981 4105
Differential right	33113 F	003 981 4105

1 \ Differential

POSITION	Fersa	OEM
HL 7/4 D-10		740.119
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
HL 7/4 D-10		740.905-914
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
HL 7/4 D-10		748.991-993-995-997-999
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
HL 7/07 D-10		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 3105
Differential left	33115 F	003 981 3205
Differential right	33115 F	003 981 3205
HL 7/07 D-10		740.337-340-345
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205
HL 7/07 D-10		740.331
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205
HL 7/07 D-10		740.346-348-354-364-365
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205
HL 7/07 D-10		748.438-442-443-449
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205
HL 7/07 D-10		748.400-430-431-437
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

POSITION	Fersa	OEM
HL 7/07 D-10		<i>748.450</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/07 D-10		<i>740.366-376</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/07 D-10		<i>740.301-302-304-308</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/07 D-11,5		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 3105
Differential left	33115 F	003 981 3205
Differential right	33115 F	003 981 3205

HL 7/07 D-11,5		<i>748.463-469</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/07 D-11,5		<i>740.956-957-960</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/07 D-11,5		<i>740.964-974</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/07 D-11,5		<i>740.320</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/07 D-11,5		<i>748.456-457</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

1 \ Differential

POSITION	Fersa	OEM
HL 7/07 DL-10		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 3105
Differential left	33115 F	003 981 3205
Differential right	33115 F	003 981 3205

HL 7/07 DL-10		<i>740.342</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/07 DL-10		<i>748.451-455</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/07 DL-10		<i>748.439-441-444-445</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/07 DL-10		<i>748.432-433</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/07 DL-10		<i>740.369-374-375</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/07 DL-10		<i>740.311-312</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/07 DL-11,5		<i>748.464-465-470</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/07 DL-11,5		<i>740.322</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

POSITION	Fersa	OEM
HL 7/07 DL-11,5		<i>748.458-459</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/07 DL-11,5		<i>748.401</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/07 DS-10		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 3105
Differential left	33115 F	003 981 3205
Differential right	33115 F	003 981 3205

HL 7/07 DS-10		<i>740.333</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/07 DS-10		<i>740.330-332</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/010		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 3105
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/10 D-9		
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential left	33113 F	003 981 4105
Differential right	33113 F	003 981 4105

HL 7/10 D-9		<i>serie 740.105</i>
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/10 D-13		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 3105
Differential left	33115 F	003 981 3205
Differential right	33115 F	003 981 3205

1 \ Differential

POSITION	Fersa	OEM
HL 7/10 D-13		740.321
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/013 D-16		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 3105
Differential left	33115 F	003 981 3205
Differential right	33115 F	003 981 3205

HL 7/013 D-16		740.397
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/013 D-16		740.954
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/013 D-16		740.305
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/013 DS-16 Turkey		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/15 D-13		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 3105
Differential left	33115 F	003 981 3205
Differential right	33115 F	003 981 3205

HL 7/015 D-13		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 3105
Differential left	33115 F	003 981 3205
Differential right	33115 F	003 981 3205

HL 7/015 D-13		748.466-467-468-471
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

POSITION	Fersa	OEM
HL 7/015 D-13		<i>740.955-958-959-961-962-963</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/015 D-13		<i>740.336-338-339-341</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/015 D-13		<i>740.965-966-968-969</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/015 D-13		<i>740.350</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/015 D-13		<i>748.452-453-460-461</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/015 D-13		<i>748.446-447</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/015 D-13		<i>748.402-434-435</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/015 D-13		<i>740.367-368-370-371-372-380-381</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/015 D-13		<i>740.306-307-309-310</i>
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

1 \ Differential

POSITION	Fersa	OEM
HL 7/015 D-13		740.384-385-387-388-394-395-398
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/015 D-13 Turkey		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/015 DL-13		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 3105
Differential left	33115 F	003 981 3205
Differential right	33115 F	003 981 3205

HL 7/015 DL-13		748.462
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/015 DL-13		740.323
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/015 DL-13		740.347-351
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/015 DL-13		748.454
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/015 DL-13		748.440-448
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/015 DL-13		748.403-436
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

POSITION	Fersa	OEM
HL 7/015 DL-13		740.313
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/015 DL-13		740.382
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/015 DS-13		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 3105
Differential left	33115 F	003 981 3205
Differential right	33115 F	003 981 3205

HL 7/015 DS-13		740.334-335-343
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/18 D-13		
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential left	33113 F	003 981 4105
Differential right	33113 F	003 981 4105

HL 7/18 D-13		740.908-911
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/18 D-13		740.114-134
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/18 D-13		740.138-139-148
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/18 D-13		740.928-929-931-935
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

1 \ Differential

POSITION	Fersa	OEM
HL 7/18 D-13		740.107-109
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/18 D-13		740.176
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/18 D-13		740.177-178-179-181-182-183-184
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/18 D-13 Turkey		
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/18 DS-13		
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential left	33113 F	003 981 4105
Differential right	33113 F	003 981 4105

HL 7/18 DS-13		740.934-942
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/18 DS-13		740.135
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/18 DS-13 Turkey		
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HL 7/021 D-10		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 3105
Differential left	33115 F	003 981 3205
Differential right	33115 F	003 981 3205

POSITION	Fersa	OEM
HL 7/021 D-10		740.383-393
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/021 D-10		740.952-953
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/021 D-10		740.314-318-324
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/021 D-10		740.356-357
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/07 DL-10		740.352-353
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/021 DL-10		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 3105
Differential left	33115 F	003 981 3205
Differential right	33115 F	003 981 3205

HL 7/021 DL-10		740.392-396
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/021 DL-10		740.319
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205

HL 7/021 DS-10		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 3105
Differential left	33115 F	003 981 3205
Differential right	33115 F	003 981 3205

1 \ Differential

POSITION	Fersa	OEM
HL 7/021 DS-10		740.325
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205
HL 7/24 DS-9		740.118
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
HL 7/24 DS-9		740.939-944
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
HL 7/024 D-12,3		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205
HL 7/024 D-12,3		748.904-905
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205
HL 7/024 DL-12,3		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205
HL 7/26 D-11,5		748.923
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
HL 7/26 D-12,3		748.936-937
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
HL 7/26 D-12,3		748.902-903-911-925
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

POSITION	Fersa	OEM
HL 7/26 DL-12,3		748.907-912-926
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105
HL 7/055 DCS-13		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	32017 XF	005 981 1505
Differential left	32017 XF	005 981 1505
HL 7/50		748.262-268-272-274-276-701-706-708
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 3105
Differential right	32017 XF	017 981 8205
Differential left	32020 XF	017 981 7905
HL 7/52 DGS-11,5		
Bevel pinion front	F 15253	014 981 2005
Bevel pinion rear	F 15257	014 981 2205
Differential right	32028 XF	009 981 7905
Differential left	F 15208	011 981 3605
HL 7/55		748.260-269-270-706
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	003 981 7005
Differential right	*	006 981 7605
Differential left	32017 XF	017 981 8205
HL 7/55		748.262-268-272-274-276-701-706-708
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 3105
Differential right	32017 XF	017 981 8205
Differential left	32020 XF	017 981 7905
HL 7/56		748.260-269-270-706
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	003 981 7005
Differential right	*	006 981 7605
Differential left	32017 XF	017 981 8205
HL 7/56		748.262-268-272-274-276-701-706-708
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 3105
Differential right	32017 XF	017 981 8205
Differential left	32020 XF	017 981 7905
HL 8/1 DCS-13		
Bevel pinion front	F 15253	014 981 2005
Bevel pinion rear	F 15257	014 981 2205
Differential right	32028 XF	009 981 7905
Differential left	F 15208	011 981 3605
Inboard	33022 F	004 981 0905
Outboard	*	

1 \ Differential

POSITION	Fersa	OEM
HL O/01		
Bevel pinion front	M 88043/M 88010	007 981 5305
Bevel pinion rear	HM 803146/HM 803110	005 981 2405
Differential right	*	001 980 6802
Differential left	*	001 980 6802
HL O/02		
Bevel pinion front	M 88043/M 88010	007 981 5305
Bevel pinion rear	HM 803146/HM 803110	005 981 2405
Differential right	*	001 980 6802
Differential left	*	001 980 6802
HL O/14		
Bevel pinion front	M 88043/M 88010	007 981 5305
Bevel pinion rear	HM 803146/HM 803110	005 981 2405
Differential right	*	001 980 6802
Differential left	*	001 980 6802
HL O/15		
Bevel pinion front	M 88043/M 88010	007 981 5305
Bevel pinion rear	HM 803146/HM 803110	005 981 2405
Differential right	*	001 980 6802
Differential left	*	001 980 6802
HL O/2-2,2		
Bevel pinion front	*	001 980 8902
Bevel pinion rear	HM 803146/HM 803110	001 980 6902
Differential right	LM 806649/LM 806610	000 980 1902
Differential left	LM 806649/LM 806610	000 980 1902
HL O/3-3,3		
Bevel pinion front	*	001 980 8902
Bevel pinion rear	HM 803146/HM 803110	001 980 6902
Differential right	LM 806649/LM 806610	000 980 1902
Differential left	LM 806649/LM 806610	000 980 1902
Inboard	32011 XF	006 981 5605
Outboard	32210 F	001 981 8905
HL O/6-3,9		
Bevel pinion front	M 88043/M 88010	007 981 5305
Bevel pinion rear	*	007 981 4005
Differential right	LM 806649/LM 806610	000 980 1902
Differential left	LM 806649/LM 806610	000 980 1902
Inboard	32011 XF	006 981 5605
Outboard	32210 F	001 981 8905
HO 4/01 D-10 Brazil		745.531-537-538
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

POSITION	Fersa	OEM
HO 4/01 D-10 Turkey		746.420-421-426-427
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HO 4/01 DL-10		745.874-875-877
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HO 4/01 DL-10		745.876
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HO 4/01 DL-10		745.800-801-807-808-809-840-841-842-843
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HO 4/01 DL-10		745.844-845-846-847-849
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HO 4/01 DL-10 Brazil		745.530-536-539-980-981
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

1 \ Differential

POSITION	Fersa	OEM
HO 4/01 DL-10 Turkey		746.422-423-424-428-429
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HO 4/01 D-11,5		
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	*	
Differential right	32018 XF	006 981 0005
Differential left	32018 XF	006 981 0005

HO 4/01 DL-11,5		745.870-871
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HO 4/01 DL-11,5		745.802-806
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HO 4/01 DL-11,5		745.872
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HO 4/02 CL-11,5		745.850-860-861-863-864
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

POSITION	Fersa	OEM
HO 4/02 CL-11,5		745.862
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	F 15159	006 981 3505
Bevel pinion pilot	F 19013	007 981 7901
Differential right	32018 XF	004 981 4305
Differential left	32018 XF	004 981 4305
Inboard	33020 F	005 981 8505
Outboard	33117 F	005 981 9905

HO 4/08 DCL-11,5		
Bevel pinion front	F 15255	014 981 7805
Bevel pinion rear	F 15256	014 981 7905
Differential right	32022 XF	002 981 5005
Differential left	32017 XF	005 981 1405

HO 4/10 DL-10		
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HO 4/10 L-10		
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HO 4/18 DL-7,7		
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	*	000 981 4605
Outboard	32216 F	000 981 7205

HO 4/18 L-7,7		
Bevel pinion front	HM 911244/HM 911216	002 981 1105
Bevel pinion rear	F 15158	007 981 8905
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	*	000 981 4605
Outboard	32216 F	000 981 7205

HO 4/2-7,6 Turkey		
Bevel pinion	HM 911244/HM 911216	002 981 1105
Bevel pinion pilot	F 19043	002 981 9501
Differential right	47487/47420	002 981 2605
Differential left	47487/47420	002 981 2605
Inboard	32216 F	000 981 7205
Outboard	*	000 981 4605

1 \ Differential

POSITION	Fersa	OEM
HO 5/4 Z-10		
Bevel pinion front	F 15082	001 981 9905
Bevel pinion rear	F 15083	003 981 1205
Bevel pinion pilot	F 19015	003 981 1701
Differential right	32020 XF	001 981 7205
Differential left	32020 XF	001 981 7205
Inboard	580/572	000 981 7905
Outboard	32215 F	000 981 8405

HO 5/8 DL-10		745.200
Bevel pinion front	F 15082	001 981 9905
Bevel pinion rear	F 15083	003 981 1205
Bevel pinion pilot	F 19015	003 981 1701
Differential right	32020 XF	001 981 7205
Differential left	32020 XF	001 981 7205
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HO 5/8 DL-10		745.207 / 745.230
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	*	006 981 1805
Bevel pinion pilot	F 19015	003 981 1701
Differential right	32020 XF	001 981 7205
Differential left	32020 XF	001 981 7205
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HO 5/8 DZ-10		746.411 / 746.414 / 746.415
Bevel pinion front	F 15082	001 981 9905
Bevel pinion rear	F 15083	003 981 1205
Bevel pinion pilot	F 19015	003 981 1701
Differential right	32020 XF	001 981 7205
Differential left	32020 XF	001 981 7205
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HO 5/8 DZ-10		746.412
Bevel pinion front	F 15183	006 981 1705
Bevel pinion rear	*	006 981 1805
Bevel pinion pilot	F 19015	003 981 1701
Differential right	32020 XF	001 981 7205
Differential left	32020 XF	001 981 7205
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

HO 5/8 L-10		
Bevel pinion front	F 15082	001 981 9905
Bevel pinion rear	F 15083	003 981 1205
Bevel pinion pilot	F 19015	003 981 1701
Differential right	32020 XF	001 981 7205
Differential left	32020 XF	001 981 7205
Inboard	33019 F	002 981 9005
Outboard	33215 F	002 981 8605

POSITION	Fersa	OEM
HO 6/1		
Bevel pinion front	F 15253	014 981 2005
Bevel pinion rear	F 15254	014 981 4905
Differential right	32024 XF	014 981 5405
Differential left	32020 XF	017 981 7905
HO 6/2		
Bevel pinion front	F 15253	014 981 2005
Bevel pinion rear	F 15254	014 981 4905
Differential right	32024 XF	014 981 5405
Differential left	32020 XF	017 981 7905
HO 6/3		
Bevel pinion front	F 15253	014 981 2005
Bevel pinion rear	F 15254	014 981 4905
Differential right	32024 XF	014 981 5405
Differential left	32020 XF	017 981 7905
HO 6/5		
Bevel pinion front	F 15253	014 981 2005
Bevel pinion rear	F 15254	014 981 4905
Differential right	32024 XF	014 981 5405
Differential left	32020 XF	017 981 7905
HO 6/6		
Bevel pinion front	F 15253	014 981 2005
Bevel pinion rear	F 15254	014 981 4905
Differential right	32024 XF	014 981 5405
Differential left	32020 XF	017 981 7905
HO 7/01 DL-10		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205
HO 7/01 DLS-10		
Bevel pinion front	31313 F	002 981 4505
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205
HO 7/02 DLM-10		
Bevel pinion front	F 15273	007 981 6305
Bevel pinion rear	32314 BF	003 981 2905
Differential right	33115 F	003 981 3205
Differential left	33115 F	003 981 3205
HO 7/10 DL-11,5		
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105


POSITION	Fersa	OEM
HO 7/8 DL-10		
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HO 7/9 DL-10		
Bevel pinion front	HM 807048/HM 807010	005 981 4605
Bevel pinion rear	32313 BF	005 981 0505
Differential right	33113 F	003 981 4105
Differential left	33113 F	003 981 4105

HO 8/1 DCL-13		
Bevel pinion front	F 15253	014 981 2005
Bevel pinion rear	F 15257	014 981 2205
Differential right	32028 XF	009 981 7905
Differential left	F 15208	011 981 3605
Inboard	33022 F	004 981 0905
Outboard	*	

HO 8/1 DCLS-13		
Bevel pinion front	F 15253	014 981 2005
Bevel pinion rear	F 15257	014 981 2205
Differential right	32028 XF	009 981 7905
Differential left	F 15208	011 981 3605
Inboard	33022 F	004 981 0905
Outboard	*	

LK 1622 4x2 /1632 / 1636 / 1722 / 1725		
Bevel pinion rear	F 15256	014 981 7905
Bevel pinion front	F 15255	014 981 7805
Differential right	32022 XF	002 981 5005
Differential left	32017 XF	005 981 1405





A series of horizontal dotted lines spanning the width of the page, intended for writing or drawing.

GEARBOX



MODEL	Pág\
EATON	
FS 5306 A	80
FS 6206 A	80
FS 6306 A	80
FSO 4405	80

MERCEDES BENZ	
G3-36	81
G3-40	81
G3/45-6/8,5	81
G3-50 ASP/MOD	81
G3/50-5/8,5	82
G3/55-6/8,5	82
G3-60,1 BUS	82
G3/60-5/7,5	82
G3/61-5/6,1	83
G3/65	83
G3/90	83
G4/65-6/9,0	83
G6-60	84
G32	84
G60-6	84
G85-6	84
G85-6/6,7-0,73	85
G100-12	85
G125-16/14,0-1,0	85
G131-9/14,0-1,0	86
G135-16/11,9-0,88	86
G155-9/15,9-1,0	86
G155-16/11,9-0,88	87
G155-16/14,0-1,0	87
G180-16/11,9/EPS	87
G180-16/14,0/EPS	88
G200-16/11,9/EPS	88
G210-16/14,2-0,83	88
G211-12	89
G211-16/17,3-1,00	89
G221-9/10,19-1,0	90
G230-12	90
G230-16/14,2-0,83	90
G231-16	91
G240-16/11,7-0,69	91
G241-16/17,03-1,00	91
G260-16/9,75-0,57	92
G280-16/11,72-0,69	92
G281-12/14,93-1,00	93

MODEL	Pág\
G330	93
G330-12/11,63-0,77	93
GO4/160-6/8,2	94
GO110-6	94
GO170-6/8,2-1,0	94
GO190-6/8,2-1,0	94
GO210-6/6,5-0,8	95
GO210-8/11,8-1,0	95
GO230-6/6,5-0,8	95
GO230-12/14,93-1,0	95
GO240-6/6,5-0,8	96
GV4/65-6/12,0	96

ZF	
4K-120 GP	96
4K-121 GP	96
4S-120 GP	97
5K-90 GP	97
5K-91 GP	97
5S-90 GP	98
5S-92 GP	98
5K-90 GPA	98
5K-91 GPA	99
5S-90 GPA	99
AK6-80	99
AK6-80	100
AK6-80+GV80	100
AK6-90+GV90	100
AK6-90	101
GV 80	101
GV 90	101
5K-110 GPA	102
5S-110 GPA	102
5K-110 GP	102
5S-110 GP	103
5K-110 GPA+GV90/1	103
5S-110 GPA+GV90/1	104
5K-110 GP+GV90/1	104
5S-110 GP+GV90/1	106
5S-111 GP	107
5S-111 GPA	108
5S-111 GP+GV90/1	108
6S-850	108
8S-1350	109
9S-75	109

MODEL	Pág\
16S-112	109
16K-130	110
16K-160	110
16K-190	111
16S-130	111
16S-160	112
16S-190	114
16S-220	114
16S-1300	115
16S-1600	115
16S-1650	115
16S-1900	116
S5-35/2	118
S5-420	119
S5-680	119
S5-820	120
S6-80	120
S6-80+GV80	121
S6-85	122
S6-90	122
S6-90	123
S6-90+GV90	124
S6-680	125
S680+GV	125
S6-1550	125



POSITION	Fersa	OEM
----------	-------	-----

EATON

FS 5306 A

Main shaft	F 17044 K	017 981 3610
Main shaft	F 17043 K	017 981 3510
Main shaft	F 17046 K	017 981 3810
Main shaft	F 17045 K	017 981 3710
Reverse shaft	*	017 981 3910
Counter shaft front	25590/25522	001 981 8280/012 981 0805
Counter shaft rear	3782/3720	001 981 8380
Output shaft	45285 A/45220	001 981 8180/013 981 0105
Main shaft rear	31594/31520	012 981 0605
Input shaft front	39590/39520	001 981 8080/012 981 0705

FS 6206 A

Main shaft	F 17044 K	017 981 3610
Main shaft	F 17043 K	017 981 3510
Main shaft	F 17046 K	017 981 3810
Main shaft	F 17045 K	017 981 3710
Reverse shaft	*	017 981 3910
Counter shaft front	25590/25522	001 981 8280/012 981 0805
Counter shaft rear	3782/3720	001 981 8380
Output shaft	45285 A/45220	001 981 8180/013 981 0105
Main shaft	31594/31520	012 981 0605
Input shaft front	39590/39520	001 981 8080/012 981 0705

FS 6306 A

Main shaft	F 17044 K	017 981 3610
Main shaft	F 17043 K	017 981 3510
Main shaft	F 17046 K	017 981 3810
Main shaft	F 17045 K	017 981 3710
Reverse shaft	*	017 981 3910
Counter shaft front	25590/25522	001 981 8280/012 981 0805
Counter shaft rear	3782/3720	001 981 8380
	45285 A/45220	001 981 8180/013 981 0105
	31594/31520	012 981 0605
Input shaft front	39590/39520	001 981 8080/012 981 0705

FSO 4405

Input shaft front	M 802048/11	016 981 8305/002 981 3180
Main shaft	*	003 981 0618
	*	003 981 0818
	*	003 981 0918
Output shaft	25581/25520	016 981 8505/002 981 3380
Counter shaft rear	2689/2631	016 981 8605
Counter shaft front	25877/25821	016 981 8705/002 981 3480
	*	009 981 4525

POSITION	Fersa	OEM
----------	-------	-----

MERCEDES BENZ

G3-36

Main shaft	*	345 981 7212
Main shaft	*	345 981 7312
Counter shaft front	30308 F	001 981 3105
Counter shaft rear	30308 F	001 981 3105
Main shaft front	QJ 309 FM	345 981 7127
Main shaft rear (From 68 to 73)	*	000 981 4312
Main shaft rear	*	345 981 7012
Main shaft intermediate	F 19044	344 981 7001
Input shaft front	QJ 209 FM	345 981 7027
Input shaft rear	NU 209 FN	344 981 7101

G3-40

Main shaft	*	345 981 7212
Main shaft	*	345 981 7312
Counter shaft front	30308 F	001 981 3105
Counter shaft rear	30308 F	001 981 3105
Main shaft front	QJ 309 FM	345 981 7127
Main shaft rear	*	345 981 0012
Main shaft intermediate	F 19044	344 981 7001
Input shaft front	QJ 209 FM	345 981 7027
Input shaft	NU 209 FN	344 981 7101

G3/45-6/8,5

Main shaft front (Up to Gearbox 048890)	F 19047	007 981 2501
Main shaft front (From gearbox 048891)	*	006 981 7025
Main shaft	*	001 981 9512
Main shaft	*	012 981 4710
Main shaft	*	012 981 6210
Main shaft	*	012 981 6810
Main shaft	*	012 981 6810
Main shaft	*	012 981 5110
Main shaft	*	012 981 5310
Main shaft rear (Up to Gearbox 048890)	F 19046	007 981 4701
Main shaft rear (From gearbox 048891)	*	006 981 6425
Counter shaft front	30308 F	001 981 3105
Counter shaft rear	30308 F	001 981 3105
Reverse shaft (Old Type)	*	001 981 8312
Reverse shaft (New type)	*	021 981 4210
Main shaft front (Up to Gearbox 048890)	F 19047	007 981 2501
Main shaft front (Front gearbox 048891)	*	006 981 7025

G3-50 ASP/MOD

Reverse shaft	*	001 981 9312
Main shaft	*	001 981 4012
Main shaft	*	001 981 4612
Main shaft	*	001 981 4412
Counter shaft front	30308 F	001 981 3105
Counter shaft rear	30308 F	001 981 3105
Main shaft front	QJ 309 FM	345 981 7127
Main shaft rear	*	001 981 9512
Main shaft intermediate	F 19044	344 981 7001
Input shaft front	QJ 212 FM	345 981 7627
Input shaft rear	F 19011	345 981 8101
Main shaft	*	001 981 4112

POSITION	Fersa	OEM
MERCEDES BENZ		
G3/50-5/8,5		
Input shaft front	*	no info
Input shaft front	NU 209 FMN	001 981 1701
Main shaft front	*	001 981 0712
Main shaft	*	327 981 0112
Main shaft	*	001 981 4612
Main shaft	*	001 981 4012
Main shaft	*	001 981 4112
Main shaft rear	*	000 981 1201
Main shaft rear	QJ 309 FM	000 981 2927
Counter shaft front	30308 F	001 981 3105
Counter shaft rear	30308 F	001 981 3105
Reverse shaft	*	022 981 4510
G3/55-6/8,5		
Main shaft	*	001 981 9412
Main shaft	*	012 981 4810
Main shaft	*	012 981 5010
Main shaft	*	014 981 0710
Main shaft	*	014 981 0710
Main shaft	F 17090 K	014 981 0610
Main shaft	*	012 981 5410
Main shaft rear (Up to Gearbox 048890)	F 19046	007 981 4701
Main shaft rear (From gearbox 048891)	*	006 981 6425
Counter shaft front	30308 F	001 981 3105
Counter shaft rear	30308 F	001 981 3105
Reverse shaft (Old Type)	*	001 981 8312
Reverse shaft (New type)	*	021 981 4210
G3-60,1 BUS		
Main shaft rear	*	001 981 9312
Main shaft	*	000 981 7212
Main shaft	*	327 981 0112
Main shaft	*	001 981 4612
Main shaft	*	001 981 4412
Main shaft	*	001 981 4012
Counter shaft front	30308 F	001 981 3105
Counter shaft rear	30308 F	001 981 3105
Main shaft front	QJ 309 FM	345 981 7127
Main shaft intermediate	F 19044	344 981 7001
Input shaft front	QJ 212 FM	345 981 7627
Input shaft rear	F 19011	345 981 8101
G3/60-5/7,5		
Input shaft front	*	No info
Input shaft front	NU 209 FMN	001 981 1701
Main shaft front	*	001 981 9412
Main shaft	*	327 981 0112
Main shaft	*	001 981 4612
Main shaft	*	001 981 4012
Main shaft	*	001 981 4112
Main shaft rear	*	000 981 1201
Main shaft rear	QJ 309 FM	000 981 2927
Counter shaft front	30308 F	001 981 3105
Counter shaft rear	30308 F	001 981 3105
Reverse shaft	*	022 981 4510

POSITION	Fersa	OEM
MERCEDES BENZ		
G3/61-5/6,1		
Input shaft	*	No info
Input shaft front	NU 209 FMN	001 981 1701
Main shaft front	*	001 981 9312
Main shaft	*	000 981 6712
Main shaft	*	327 981 0112
Main shaft	*	001 981 4612
Main shaft	*	001 981 4012
Main shaft	*	001 981 4112
Main shaft rear	*	000 981 1201
Main shaft rear	QJ 309 FM	000 981 2927
Counter shaft front	30308 F	001 981 3105
Counter shaft rear	30308 F	001 981 3105
Reverse shaft	*	022 981 4510
G3/65		
Input shaft front	*	008 981 9501
Main shaft front	*	001 981 9312
Main shaft	*	001 981 2512
Main shaft	*	000 981 6712
Reverse shaft	*	022 981 4510
Output shaft front	*	002 981 3725
Main shaft	*	001 981 4612
Main shaft	*	001 981 3412
Main shaft	*	001 981 4812
Main shaft rear	*	008 981 9501
Counter shaft front	30308 F	001 981 3105
Counter shaft rear	32210 F	001 981 8905
G3/90		
Input shaft front	*	008 981 9501
Main shaft front	*	001 981 9612
Main shaft	*	001 981 3512
Main shaft	*	001 981 2512
Reverse shaft	*	022 981 4510
Output shaft front	*	002 981 3725
Main shaft	*	001 981 4812
Main shaft	*	001 981 3412
Main shaft rear	*	008 981 9501
Counter shaft front	30308 F	001 981 3105
Counter shaft rear	30308 F	001 981 3105
G4/65-6/9,0		
Input shaft front (Up to gearbox 157730)	*	008 981 9501
Input shaft front (From gearbox 157731)	*	007 981 2001
Main shaft front	*	002 981 1412
Main shaft	*	007 981 2810
Main shaft	*	009 981 0210
Main shaft	F 17064 K	010 981 1210
Main shaft	F 17064 K	010 981 1210
Main shaft	*	009 981 0110
Main shaft	*	010 981 1710
Main shaft rear	*	004 981 5525
Counter shaft front	30308 F	001 981 3105
Counter shaft rear	30309 F	010 981 5905
Reverse shaft	*	010 981 5110

POSITION	Fersa	OEM
MERCEDES BENZ		
G6-60		
Input shaft case	6309 2RS	007 981 1625
Input shaft front	F 18042	007 981 1325
Main shaft front	F 19090	002 981 5912
Main shaft	F 17090 K	014 981 0610
Main shaft	F 17077 K	018 981 9510
Main shaft	F 17080 K	018 981 9610
Main shaft	F 17076 K	018 981 5310
Main shaft	*	018 981 5610
Main shaft rear	F 18042	007 981 1325
Counter shaft rear	*	002 981 7512
Reverse shaft	F 17078 K	018 981 5710
G32		
Counter shaft front	30308 F	001 981 3105
Counter shaft rear	30308 F	001 981 3105
Main shaft front	QJ 309 FM	345 981 7127
Main shaft rear	*	000 981 2612
Main shaft intermediate	F 19044	344 981 7001
Input shaft front	QJ 209 FM	345 981 7027
Input shaft rear	NU 209 FN	344 981 7101
G60-6 <i>Welded Cones</i>		
Input shaft front	F 18042	009 981 5825
Main shaft front	F 19090	976 981 0012
Main shaft	*	018 981 9710
Main shaft	F 17077 K	017 981 5610
Main shaft	F 17080 K	018 981 5810
Main shaft	F 17080 K	018 981 5810
Main shaft	F 17076 K	018 981 5310
Main shaft (Up to Gearbox 042297)	*	018 981 5610
Main shaft (From gearbox 042298)	F 17089 K	023 981 2910
Main shaft rear	F 18042	009 981 5825
Counter shaft front	6309 2RS	009 981 5725
Counter shaft rear	F 19069	010 981 4901
Reverse shaft	F 17078 K	018 981 5710
G60-6 <i>Weldless Cones</i>		
Input shaft front	F 18042	009 981 5825
Main shaft front	F 19090	976 981 0012
Main shaft	*	018 981 9710
Main shaft	F 17077 K	017 981 5610
Main shaft	F 17080 K	018 981 5810
Main shaft	F 17089 K	023 981 2910
Main shaft rear	F 18042	009 981 5825
Counter shaft front	6309 2RS	009 981 5725
Counter shaft rear	F 19069	010 981 4901
Reverse shaft	F 17078 K	018 981 5710
G85-6 <i>Weldless Cones</i>		
Input shaft front	F 18042	009 981 5825
Main shaft front	F 19090	976 981 0012
Main shaft	F 17079 K	018 981 3610
Main shaft	F 17077 K	017 981 5610
Main shaft	F 17080 K	018 981 5810

POSITION	Fersa	OEM
----------	-------	-----

MERCEDES BENZ

G85-6

Weldless Cones

Main shaft	F 17076 K	018 981 5310
Main shaft	F 17089 K	023 981 2910
Main shaft rear	F 18042	009 981 5825
Counter shaft front	6309 2RS	009 981 5725
Counter shaft rear	F 19069	010 981 4901
Reverse shaft	F 17078 K	018 981 5710

G85-6/6,7-0,73

Input shaft case	6309 2RS	007 981 1625
Input shaft front	F 18042	007 981 1325
Main shaft front	F 19090	002 981 5912
Main shaft	F 17079 K	018 981 3610
Main shaft	F 17077 K	018 981 9510
Main shaft	F 17080 K	018 981 9610
Main shaft	F 17076 K	018 981 5310
Main shaft rear	F 18042	007 981 1325
Counter shaft rear	F 19069	002 981 7512
Reverse shaft	F 17078 K	018 981 5710

G100-12

Input shaft front	F 15133	014 981 3905
Input shaft	*	018 981 0510
Main shaft front	CONE F 15110	012 981 2805
Main shaft intermediate	CONE F 15131	013 981 0305
Main shaft intermediate	CONE LM 503349	013 981 0405
Main shaft	*	018 981 7710
Main shaft	F 17032 K	009 981 1510
Main shaft	*	007 981 5510
Main shaft	*	007 981 5510
Main shaft	*	019 981 1510
Main shaft	F 17097 K	018 981 8110
Main shaft rear	CONE F 15134	002 981 4581
Main shaft rear	*	002 981 4581/001 981 9680
Counter shaft front	529/520 X1	014 981 1405
Counter shaft rear	CONE F 15132	002 981 4681
Counter shaft rear	*	002 981 4681/001 981 9780
Reverse shaft	*	019 981 4610

G125-16/14,0-1,0

Input shaft front	30216 F	009 981 6205
Input shaft (Up to gearbox 300439)	*	013 981 6410
Input shaft (From gearbox 300440)	*	016 981 0210
Main shaft front (New type)	*	017 981 3205
Main shaft front (Old Type)	*	009 981 0705
Main shaft intermediate	*	010 981 2405
Main shaft	*	014 981 3910
Main shaft	F 17035 K	018 981 6610
Main shaft (Up to gearbox 073829)	*	013 981 2510
Main shaft (From gearbox 073830)	*	014 981 4310
Main shaft	*	013 981 1710
Main shaft rear	*	008 981 8005
Counter shaft front	30309 F	010 981 5905
Counter shaft rear	*	010 981 5205
Reverse shaft	*	013 981 2210
Main shaft intermediate	32011 XF	011 981 7705

POSITION	Fersa	OEM
MERCEDES BENZ		
G125-16/14,0-1,0		
Output shaft front	16017/90 C3	008 981 1325
Output shaft rear	6217 C3	004 981 9325
Oil pump	6009 C3	004 981 9225
G131-9/14,0-1,0		
Input shaft front	30215 F	016 981 1405
Main shaft front	CONE 3382	016 981 1505
Main shaft	*	019 981 6010
Main shaft	*	021 981 6510
Main shaft	F 17031 K	008 981 8310
Main shaft	*	021 981 5710
Main shaft	*	021 981 6310
Main shaft rear	*	016 981 0105
Counter shaft front	529/520 X1	014 981 1405
Reverse shaft	*	021 981 5610
Counter shaft rear	32212 F	015 981 9705
Output shaft front	*	008 981 9525
Output shaft rear	*	009 981 0325
Oil pump	6003	008 981 5425
G135-16/11,9-0,88		
Input shaft front	30216 F	009 981 6205
Input shaft (Up to gearbox 300439)	*	013 981 6410
Input shaft (From gearbox 300440)	*	016 981 0210
Main shaft front (New type)	*	017 981 3205
Main shaft front (Old Type)	*	009 981 0705
Main shaft intermediate	*	010 981 2405
Main shaft	*	014 981 3910
Main shaft	F 17035 K	018 981 6610
Main shaft (Up to gearbox 073829)	*	013 981 2510
Main shaft (From gearbox 073830)	*	014 981 4310
Main shaft	*	013 981 1710
Main shaft rear	*	008 981 8005
Counter shaft front	30309 F	010 981 5905
Counter shaft rear	*	010 981 5205
Reverse shaft	*	013 981 2210
Main shaft intermediate	32011 XF	011 981 7705
Output shaft front	16017/90 C3	008 981 1325
Output shaft rear	6217 C3	004 981 9325
Oil pump	6009 C3	004 981 9225
G155-9/15,9-1,0		
Input shaft front	F 15190	011 981 1305
Main shaft front	HM 204043/10	008 981 2805
Main shaft	*	009 981 1410
Main shaft	F 17035 K	018 981 6610
Main shaft	F 17031 K	008 981 8310
Main shaft	*	013 981 5310
Main shaft	*	013 981 6510
Main shaft rear	F 15192	014 981 6105
Counter shaft front	529/520 X1	014 981 1405
Counter shaft rear	F 15245	016 981 1205
Reverse shaft	F 17033 K	012 981 8910
Output shaft front	16017/90 C3	008 981 1325
Output shaft rear	6217 C3	004 981 9325
Oil pump	6009 C3	004 981 9225

POSITION	Fersa	OEM
----------	-------	-----

MERCEDES BENZ

G155-16/11,9-0,88

Input shaft front	F 15190	011 981 1305
Input shaft	*	009 981 1610
Main shaft intermediate (Old Type)	33210 F	011 981 7605
Main shaft front	HM 204043/10	008 981 2805
Main shaft intermediate (New type)	*	015 981 7605/002 981 1680
Main shaft intermediate (Old Type)	32011 XF	011 981 7705
Main shaft intermediate (New type)	32011 XF	014 981 1605/002 981 1580
Main shaft	F 17035 K	018 981 6610
Main shaft	F 17032 K	009 981 1510
Main shaft rear	F 15192	014 981 6105
Counter shaft front	529/520 X1	014 981 1405
Counter shaft rear	F 15245	016 981 1205
Reverse shaft	F 17033 K	012 981 8910
Main shaft	F 17031 K	008 981 8310
Output shaft front	16017/90 C3	008 981 1325
Output shaft rear	6217 C3	004 981 9325
Oil pump	6009 C3	004 981 9225

G155-16/14,0-1,0

Input shaft front	F 15190	011 981 1305
Input shaft	*	009 981 1610
Main shaft intermediate (Old Type)	33210 F	011 981 7605
Main shaft front	HM 204043/10	008 981 2805
Main shaft intermediate (New type)	*	015 981 7605/002 981 1680
Main shaft intermediate (Old Type)	32011 XF	011 981 7705
Main shaft intermediate (New type)	32011 XF	014 981 1605/002 981 1580
Main shaft	F 17035 K	018 981 6610
Main shaft	F 17032 K	009 981 1510
Main shaft rear	F 15192	014 981 6105
Counter shaft front	529/520 X1	014 981 1405
Counter shaft rear	F 15245	016 981 1205
Reverse shaft	F 17033 K	012 981 8910
Main shaft	F 17031 K	008 981 8310
Output shaft front	16017/90 C3	008 981 1325
Output shaft rear	6217 C3	004 981 9325
Oil pump	6009 C3	004 981 9225

G180-16/11,9/EPS

Input shaft front	F 15190	011 981 1305
Input shaft	*	009 981 1610
Main shaft front	HM 204043/10	008 981 2805
Main shaft intermediate (Old Type)	33210 F	011 981 7605
Main shaft intermediate (New type)	*	015 981 7605/002 981 1680
Main shaft intermediate (Old Type)	32011 XF	011 981 7705
Main shaft intermediate (New type)	32011 XF	014 981 1605/002 981 1580
Main shaft	F 17035 K	018 981 6610
Main shaft	F 17032 K	009 981 1510
Main shaft rear	F 15192	014 981 6105
Main shaft	F 17031 K	008 981 8310
Oil pump	6009 C3	004 981 8625
Output shaft front	16017/90 C3	004 981 8825
Output shaft rear	6217 C3	004 981 8525
Counter shaft front	529/520 X1	014 981 1405
Counter shaft rear	F 15245	016 981 1205
Reverse shaft	F 17033 K	012 981 8910

POSITION	Fersa	OEM
MERCEDES BENZ		
G180-16/14,0/EPS		
Input shaft front	F 15190	011 981 1305
Input shaft	*	009 981 1610
Main shaft front	HM 204043/10	008 981 2805
Main shaft intermediate (Old Type)	33210 F	011 981 7605
Main shaft intermediate (New type)	*	015 981 7605/002 981 1680
Main shaft intermediate (Old Type)	32011 XF	011 981 7705
Main shaft intermediate (New type)	32011 XF	014 981 1605/002 981 1580
Main shaft	F 17035 K	018 981 6610
Main shaft	F 17032 K	009 981 1510
Main shaft rear	F 15192	014 981 6105
Main shaft	F 17031 K	008 981 8310
Oil pump	6009 C3	004 981 8625
Output shaft front	16017/90 C3	004 981 8825
Output shaft rear	6217 C3	004 981 8525
Counter shaft front	529/520 X1	014 981 1405
Counter shaft rear	F 15245	016 981 1205
Reverse shaft	F 17033 K	012 981 8910
G200-16/11,9/EPS		
Input shaft front	F 15190	011 981 1305
Input shaft	*	009 981 1610
Main shaft front	HM 204043/10	008 981 2805
Main shaft intermediate (Old Type)	33210 F	011 981 7605
Main shaft intermediate (New type)	*	015 981 7605/002 981 1680
Main shaft intermediate (Old Type)	32011 XF	011 981 7705
Main shaft intermediate (New type)	32011 XF	014 981 1605/002 981 1580
Main shaft	F 17035 K	018 981 6610
Main shaft	F 17032 K	009 981 1510
Main shaft rear	F 15192	014 981 6105
Main shaft	F 17031 K	008 981 8310
Oil pump	6009 C3	004 981 8625
Output shaft front	16017/90 C3	004 981 8825
Output shaft rear	6217 C3	004 981 8525
Counter shaft front	529/520 X1	014 981 1405
Counter shaft rear	F 15245	016 981 1205
Reverse shaft	F 17033 K	012 981 8910
G210-16/14,2-0,83		
Input shaft front	F 15190	011 981 1305
Input shaft	F 17034 K	016 981 0010
Main shaft front	CONE 4367 X	015 981 1605
Main shaft intermediate	HM 204043/10	008 981 2805
Main shaft intermediate (Old Type)	33210 F	011 981 7605
Main shaft intermediate (New Type. Up to gearbox 438701. With Gear 4th Speed 389 260 8908)	*	015 981 7605/002 981 1680
Main shaft intermediate (New Type. Up to gearbox 438701. With Gear 4th Speed 389 262 8610)	*	011 981 6005
Main shaft intermediate (New Type. From gearbox 438702. With Gear 4th Speed 945 262 0510.)	CONE F 15244	015 981 7605
Main shaft intermediate (Old Type)	32011 XF	011 981 7705
Main shaft intermediate (New type)	32011 XF	014 981 1605

POSITION	Fersa	OEM
----------	-------	-----

MERCEDES BENZ

G210-16/14,2-0,83

Main shaft	F 17035 K	018 981 6610
Main shaft	F 17032 K	009 981 1510
Main shaft (Old Type)	F 17031 K	008 981 8310
Main shaft (New type)	F 17097 K	018 981 8110
Main shaft rear	F 15192	014 981 6105
Counter shaft front	529/520 X1	014 981 1405
Counter shaft rear	F 15245	016 981 1205
Reverse shaft	F 17033 K	012 981 8910
Output shaft front	16017/90 C3	008 981 1325
Oil pump (With Oil pump shaft 389 269 1210)	6009 C3	004 981 9225
Oil pump (With Oil pump shafts 947 269 1010 & 947 269 1110)	6003	008 981 5425
Output shaft rear	6217/80 C3	008 981 3025
Output shaft rear (For Model with TELMA Retarder)	*	007 981 8201

G211-12

Input shaft front	F 15190	011 981 1305
Input shaft	*	022 981 2110
Main shaft front	CONE F 15249	014 981 1905
Main shaft intermediate	CONE F 15244	015 981 7605
Main shaft intermediate	CONE 4367 X	015 981 1605
Main shaft	F 17031 K	008 981 8310
Main shaft	*	021 981 5710
Main shaft	*	022 981 2310
Main shaft rear	*	016 981 7881
Counter shaft front	529/520 X1	014 981 1405
Counter shaft rear	*	002 981 7781
Reverse shaft	*	021 981 5610
Output shaft front	16017/90 C3	008 981 1325
Output shaft rear	*	009 981 3625
Oil pump	6003	008 981 5425

G211-16/17,3-1,00

Input shaft front	F 15190	011 981 1305
Input shaft	F 17096 K	018 981 6410
Main shaft front	CONE F 15249	014 981 1905
Main shaft intermediate	CONE F 15244	015 981 7605
Main shaft	F 17035 K	018 981 6610
Main shaft	F 17032 K	009 981 1510
Main shaft intermediate	32011 XF	014 981 1605
Main shaft (Old Type)	F 17031 K	008 981 8310
Main shaft (New type)	F 17097 K	018 981 8110
Main shaft rear	F 15192	014 981 6105
Counter shaft front	529/520 X1	014 981 1405
Counter shaft rear	F 15245	016 981 1205
Reverse shaft	F 17033 K	012 981 8910
Output shaft front	16017/90 C3	008 981 1325
Output shaft rear	6217/80 C3	008 981 3025
Output shaft rear (For Model with TELMA Retarder)	*	007 981 8201
Oil pump (With oil pump shaft 389 269 1210)	6009 C3	004 981 9225
Oil pump (With oil pump shaft 947 269 1010 & 947 269 1110)	6003	008 981 5425

POSITION	Fersa	OEM
MERCEDES BENZ		
G221-9/10,19-1,0		
Input shaft front	F 15190	011 981 1305
Main shaft front	CONE 4367 X	015 981 1605
Main shaft front	CONE F 15292	015 981 1705
Main shaft	*	009 981 4510
Main shaft	*	019 981 9210
Main shaft	*	021 981 1710
Main shaft	F 17034 K	016 981 0010
Main shaft rear	F 15192	014 981 6105
Counter shaft front	529/520 X1	014 981 1405
Counter shaft rear	F 15245	016 981 1205
Reverse shaft	F 17033 K	012 981 8910
Output shaft front	16017/90 C3	008 981 1325
Output shaft rear	6217/80 C3	008 981 3025
Output shaft rear (For Model with TELMA Retarder)	*	007 981 8201
Oil pump (With oil pump shaft 389 269 1210)	6009 C3	004 981 9225
Oil pump (With oil pump shaft 947 269 1010 & 947 269 1110)	6003	008 981 5425
G230-12		
Input shaft	*	002 981 5712
Input shaft front	F 15190	011 981 1305
Input shaft	*	022 981 2110
Main shaft front	CONE F 15249	017 981 1305
Main shaft intermediate	CONE F 15244	015 981 7605
Main shaft intermediate	32011 XF	011 981 7705
Main shaft	F 17031 K	019 981 4410
Main shaft	*	013 981 1210
Main shaft	*	022 981 2310
Main shaft rear	*	no info
Output shaft front	16017/90 C3	008 981 1325
Output shaft rear	F 18060	009 981 3325
Counter shaft front	529/520 X1	015 981 9005
Counter shaft rear	*	002 981 7781
Reverse shaft	*	021 981 5610
Oil pump	6003	008 981 5425
G230-16/14,2-0,83		
Input shaft front	F 15190	011 981 1305
Input shaft	F 17034 K	016 981 0010
Main shaft front	CONE 4367 X	015 981 1605
Main shaft intermediate	CONE F 15244	015 981 7605
Main shaft intermediate	32011 XF	014 981 1605
Main shaft	F 17035 K	018 981 6610
Main shaft	F 17032 K	009 981 1510
Main shaft rear	F 15192	014 981 6105
Counter shaft front	529/520 X1	014 981 1405
Counter shaft rear	F 15245	016 981 1205
Reverse shaft	F 17033 K	012 981 8910
Output shaft front	16017/90 C3	008 981 1325
Oil pump (With Oil pump shaft 389 269 1210)	6009 C3	004 981 9225
Oil pump (With Oil pump shafts 947 269 1010 & 947 269 1110)	6003	008 981 5425
Output shaft rear	6217/80 C3	008 981 3025
Output shaft rear (For Model with TELMA Retarder)	*	007 981 8201

POSITION	Fersa	OEM
----------	-------	-----

MERCEDES BENZ

G231-16

Input shaft front	F 15190	011 981 1305
Input shaft	F 17096 K	018 981 6410
Main shaft front	CONE F 15249	014 981 1905
Main shaft intermediate	CONE F 15244	015 981 7605
Main shaft	F 17035 K	018 981 6610
Main shaft	F 17032 K	009 981 1510
Main shaft rear	F 15192	014 981 6105
Main shaft intermediate	32011 XF	014 981 1605
Counter shaft front	529/520 X1	014 981 1405
Counter shaft rear	F 15245	016 981 1205
Reverse shaft	F 17033 K	012 981 8910
Main shaft (Old tipe with main shaft 945 262 3605)	F 17031 K	008 981 8310
Main shaft (New type with main shaft 945 262 4505)	F 17097 K	018 981 8110
Output shaft front	16017/90 C3	008 981 1325
Output shaft rear	6217/80 C3	008 981 3025
Output shaft rear (For Model with TELMA Retarder)	*	007 981 8201
Oil pump (With Oil pump shaft 389 269 1210)	6009 C3	004 981 9225
Oil pump (With Oil pump shafts 947 269 1010 & 947 269 1110)	6003	008 981 5425

G240-16/11,7-0,69

Input shaft front	F 15190	011 981 1305
Input shaft	F 17034 K	016 981 0010
Main shaft front	CONE 4367 X	015 981 1605
Main shaft intermediate	CONE F 15113	017 981 5105
Main shaft intermediate	CONE F 15111	015 981 6205
Main shaft	F 17035 K	018 981 6610
Main shaft (Old tipe with main shaft 945 262 3605)	F 17031 K	008 981 8310
Main shaft (New type with main shaft 945 262 4505)	F 17097 K	018 981 8110
Main shaft	F 17032 K	009 981 1510
Main shaft rear	F 15192	014 981 6105
Counter shaft front	529/520 X1	014 981 1405
Counter shaft rear	F 15245	016 981 1205
Reverse shaft	F 17033 K	012 981 8910
Output shaft front	16017/90 C3	008 981 1325
Oil pump (With Oil pump shaft 389 269 1210)	6009 C3	004 981 9225
Oil pump (With Oil pump shafts 947 269 1010 & 947 269 1110)	6003	008 981 5425
Output shaft rear (Old type (OT Planet carrier uses old bearing type))	6217 C3	004 981 9325
Output shaft rear (New type)	6217/80 C3	008 981 3025
Output shaft rear (For Model with TELMA Retarder)	*	007 981 8201

G241-16/17,03-1,00

Input shaft front	F 15190	011 981 1305
Input shaft	F 17096 K	018 981 6410
Main shaft front	CONE F 15249	014 981 1905
Main shaft intermediate	CONE F 15113	017 981 5105
Main shaft intermediate	CONE F 15111	015 981 6205

POSITION	Fersa	OEM
MERCEDES BENZ		
G241-16/17,03-1,00		
Main shaft	F 17035 K	018 981 6610
Main shaft	F 17035 K	018 981 6610
Main shaft	F 17097 K	018 981 8110
Main shaft	F 17032 K	009 981 1510
Main shaft rear	F 15192	014 981 6105
Counter shaft front	529/520 X1	014 981 1405
Counter shaft rear	F 15245	016 981 1205
Reverse shaft	F 17033 K	012 981 8910
Output shaft front	16017/90 C3	008 981 1325
Oil pump (With Oil pump shaft 389 269 1210)	6009 C3	004 981 9225
Oil pump (With Oil pump shafts 947 269 1010 & 947 269 1110)	6003	008 981 5425
Output shaft rear	6217/80 C3	008 981 3025
Output shaft rear (For Model with TELMA Retarder)	*	007 981 8201
G260-16/9,75-0,57		
Input shaft front	F 15190	011 981 1305
Input shaft	F 17034 K	016 981 0010
Main shaft front	CONE 4367 X	015 981 1605
Main shaft intermediate	CONE F 15113	017 981 5105
Main shaft intermediate	CONE F 15111	015 981 6205
Main shaft	F 17035 K	018 981 6610
Main shaft	F 17032 K	009 981 1510
Main shaft rear	F 15192	014 981 6105
Counter shaft front	529/520 X1	014 981 1405
Counter shaft rear	F 15245	016 981 1205
Reverse shaft	F 17033 K	012 981 8910
Main shaft (Old type with main shaft 945 262 3605)	F 17031 K	008 981 8310
Main shaft (New type with main shaft 945 262 4505)	F 17097 K	018 981 8110
Output shaft front	16017/90 C3	008 981 1325
Oil pump (With Oil pump shaft 389 269 1210)	6009 C3	004 981 9225
Oil pump (With Oil pump shafts 947 269 1010 & 947 269 1110)	6003	008 981 5425
Output shaft rear	6217/80 C3	008 981 3025
Output shaft rear (For Model with TELMA Retarder)	*	007 981 8201
G280-16/11,72-0,69		
Input shaft front	F 15190	011 981 1305
Input shaft	F 17096 K	018 981 6410
Main shaft front	CONE F 15249	014 981 1905
Main shaft intermediate	CONE F 15113	017 981 5105
Main shaft intermediate	CONE F 15111	015 981 6205
Main shaft	F 17035 K	018 981 6610
Main shaft	F 17035 K	018 981 6610
Main shaft	F 17097 K	018 981 8110
Main shaft	F 17032 K	009 981 1510
Main shaft rear	F 15192	014 981 6105
Counter shaft front	529/520 X1	014 981 1405
Counter shaft rear	F 15245	016 981 1205
Reverse shaft	F 17033 K	012 981 8910

POSITION	Fersa	OEM
----------	-------	-----

MERCEDES BENZ

G280-16/11,72-0,69

Output shaft front	16017/90 C3	008 981 1325
Oil pump (With Oil pump shaft 389 269 1210)	6009 C3	004 981 9225
Oil pump (With Oil pump shafts 947 269 1010 & 947 269 1110)	6003	008 981 5425
Output shaft rear	6217/80 C3	008 981 3025
Output shaft rear (For Model with TELMA Retarder)	*	007 981 8201

G281-12/14,93-1,00

Input shaft front	F 15190	011 981 1305
Input shaft	*	022 981 5310
Main shaft front	CONE F 15249	014 981 1905
Main shaft intermediate	CONE F 15113	017 981 5105
Main shaft intermediate	CEM F 15269	017 981 7105
Main shaft	*	022 981 5810
Main shaft	*	022 981 5910
Main shaft	*	022 981 5610
Main shaft rear	F 15298	018 981 6805
Counter shaft front	529/520 X1	015 981 9005
Reverse shaft	F 17033 K	012 981 8910
Counter shaft rear	F 15245	017 981 2605
Output shaft front	16017/90 C3	008 981 1325
Oil pump	6003	008 981 5425
Output shaft rear	6217/80 C3	008 981 3025

G330

Input shaft front	F 15190	011 981 1305
Main shaft front	CONE F 15249	014 981 1905
Main shaft intermediate	CONE F 15113	017 981 5105
Main shaft intermediate	CEM F 15269	017 981 7105
Main shaft	*	022 981 5810
Main shaft	*	022 981 5910
Main shaft	*	022 981 5610
Main shaft rear	F 15192	014 981 6105
Counter shaft front	529/520 X1	015 981 9005
Counter shaft rear	F 15245	017 981 2605
Reverse shaft	F 17033 K	012 981 8910
Input shaft	*	022 981 5310
Output shaft front	16017/90 C3	008 981 1325
Oil pump	6003	008 981 5425
Output shaft rear	6217/80 C3	008 981 3025

G330-12/11,63-0,77

Input shaft front	F 15190	011 981 1305
Input shaft	*	022 981 5310
Main shaft front	CONE F 15249	014 981 1905
Main shaft intermediate	CONE F 15113	017 981 5105
Main shaft intermediate	CEM F 15269	017 981 7105
Main shaft	*	022 981 5810
Main shaft	*	022 981 5910
Main shaft	*	022 981 5610
Main shaft rear	F 15192	014 981 6105
Counter shaft front	529/520 X1	015 981 9005
Reverse shaft	F 17033 K	012 981 8910
Counter shaft rear	F 15245	017 981 2605
Output shaft front	16017/90 C3	008 981 1325
Oil pump	6003	008 981 5425
Output shaft rear	6217/80 C3	008 981 3025

POSITION	Fersa	OEM
----------	-------	-----

MERCEDES BENZ

GO4/160-6/8,2

Input shaft front	F 15190	011 981 1305
Main shaft front	CONE 4367 X	015 981 1605
Main shaft	*	011 981 7610
Main shaft	F 17032 K	009 981 1510
Main shaft	*	007 981 5510
Main shaft	*	021 981 9410
Main shaft	*	021 981 9410
Main shaft rear (Up to gearbox 372851)	30313 F	009 981 8905
Main shaft rear (From gearbox 372852)	F 15265	012 981 3705
Counter shaft front	529/520 X1	014 981 1405
Reverse shaft	*	015 981 4110
Counter shaft rear	F 15161	012 981 3605

GO110-6

Input shaft front	F 18042	009 981 5825
Main shaft front	F 19090	976 981 0012
Main shaft	F 17079 K	018 981 3610
Main shaft	F 17077 K	017 981 5610
Main shaft	F 17080 K	018 981 5810
Main shaft	F 17080 K	018 981 5810
Main shaft	F 17076 K	018 981 5310
Main shaft	F 17089 K	023 981 2910
Main shaft rear	F 18042	009 981 5825
Counter shaft front	6309 2RS	009 981 5725
Counter shaft rear	F 19069	010 981 4901
Reverse shaft	F 17078 K	018 981 5710

GO170-6/8,2-1,0

Input shaft front	F 15190	011 981 1305
Main shaft front	CONE 4367 X	015 981 1605
Main shaft	*	019 981 6010
Main shaft	F 17032 K	009 981 1510
Main shaft	*	007 981 5510
Main shaft	*	007 981 5510
Main shaft	*	021 981 9410
Main shaft rear	F 15265	012 981 3705
Counter shaft front	529/520 X1	014 981 1405
Reverse shaft	*	015 981 4110
Counter shaft rear	F 15161	012 981 3605

GO190-6/8,2-1,0

Input shaft front	F 15190	011 981 1305
Main shaft front	CONE 4367 X	015 981 1605
Main shaft	*	019 981 6010
Main shaft	F 17032 K	009 981 1510
Main shaft	*	007 981 5510
Main shaft	*	007 981 5510
Main shaft	*	021 981 9410
Main shaft	*	021 981 9410
Main shaft rear	F 15265	012 981 3705
Counter shaft front	529/520 X1	014 981 1405
Counter shaft rear	F 15161	012 981 3605
Reverse shaft	*	015 981 4110

POSITION	Fersa	OEM
MERCEDES BENZ		
GO210-6/6,5-0,8		
Input shaft front	F 15190	011 981 1305
Main shaft front	CONE 4367 X	015 981 1605
Main shaft	*	019 981 6010
Main shaft	F 17032 K	009 981 1510
Main shaft	*	007 981 5510
Main shaft	*	007 981 5510
Main shaft	*	021 981 9410
Main shaft	*	021 981 9410
Main shaft rear	F 15265	012 981 3705
Counter shaft front	529/520 X1	014 981 1405
Counter shaft rear	F 15161	012 981 3605
Reverse shaft	*	015 981 4110

GO210-8/11,8-1,0		
Input shaft front	F 15190	011 981 1305
Main shaft front	33210 F	011 981 7605
Main shaft	*	009 981 1410
Main shaft	F 17035 K	018 981 6610
Main shaft	F 17031 K	008 981 8310
Main shaft	*	013 981 6510
Main shaft rear	F 15192	014 981 6105
Counter shaft front	529/520 X1	014 981 1405
Counter shaft rear	F 15245	016 981 1205
Reverse shaft	F 17033 K	012 981 8910
Output shaft front	16017/90 C3	008 981 1325
Output shaft rear	6217 C3	004 981 9325
Oil pump	6009 C3	004 981 9225

GO230-6/6,5-0,8		
Input shaft front	F 15190	011 981 1305
Main shaft front	CONE 4367 X	015 981 1605
Main shaft	*	019 981 6010
Main shaft	F 17032 K	009 981 1510
Main shaft	*	007 981 5510
Main shaft	*	007 981 5510
Main shaft	*	021 981 9410
Main shaft	*	021 981 9410
Main shaft rear	F 15265	012 981 3705
Counter shaft front	529/520 X1	014 981 1405
Counter shaft rear	F 15161	012 981 3605
Reverse shaft	*	015 981 4110

GO230-12/14,93-1,0		
Input shaft front	F 15190	011 981 1305
Input shaft	*	022 981 2010
Main shaft front	CONE F 15249	014 981 1905
Main shaft intermediate	CONE F 15244	015 981 7605
Main shaft intermediate	CONE 4367 X	015 981 1605
Main shaft	F 17031 K	008 981 8310
Main shaft	*	021 981 5710
Main shaft	*	022 981 2310
Main shaft rear	*	016 981 7881
Counter shaft front	529/520 X1	014 981 1405
Counter shaft rear	*	002 981 7781
Reverse shaft	*	021 981 5610

POSITION	Fersa	OEM
----------	-------	-----

MERCEDES BENZ

GO230-12/14,93-1,0

Output shaft front	16017/90 C3	008 981 1325
Output shaft rear	*	009 981 3625
Oil pump	6003	008 981 5425

GO240-6/6,5-0,8

Input shaft front	F 15190	011 981 1305
Main shaft front	CONE F 15292	015 981 1705
Main shaft intermediate	F 15244	015 981 7605
Main shaft	*	019 981 9210
Main shaft	*	022 981 8410
Main shaft	*	022 981 8510
Main shaft	*	022 981 8510
Main shaft rear	F 15265	012 981 3705
Counter shaft front	*	012 981 9605
Counter shaft rear	F 15161	012 981 3605
Reverse shaft	*	015 981 4110

GV4/65-6/12,0

Input shaft	*	010 981 1510
Input shaft front (Up to Gearbox 157730)	*	008 981 9501
Input shaft front (From Gearbox 157731)	*	007 981 2001
Main shaft front	*	001 981 9412
Main shaft intermediate	*	003 981 9125
Main shaft	*	010 981 4910
Main shaft	F 17064 K	010 981 1210
Main shaft	*	010 981 4410
Main shaft	*	019 981 1510
Main shaft	F 17064 K	010 981 1210
Main shaft	*	010 981 1710
Main shaft rear	*	004 981 5525
Counter shaft front	30309 F	010 981 5905
Counter shaft rear	30309 F	010 981 5905
Reverse shaft	*	010 981 5110
Main shaft	*	009 981 0110

ZF

4K-120 GP

Main shaft	*	0501 398 211
Main shaft	F 17064 K	0750 115 227
Main shaft	*	0735 320 379
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Main shaft front	NUP 311 FMNR/C3	0750 118 015
Main shaft rear	F 19019	0750 118 019
Case housing	6213 ZMNR/C3	0735 330 136
Input shaft front	F 19022	0750 118 129
Reverse shaft	F 17053 K	0735 320 493

4K-121 GP

Main shaft	*	0501 398 211
Main shaft	F 17064 K	0750 115 227
Main shaft	*	0735 320 379
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Main shaft front	NUP 311 FMNR/C3	0750 118 015

POSITION	Fersa	OEM
----------	-------	-----

ZF
4K-121 GP

Main shaft rear	F 19019	0750 118 019
Case housing	6213 ZMNR/C3	0735 330 136
Input shaft front	F 19022	0750 118 129
Reverse shaft	F 17053 K	0735 320 493

4S-120 GP
R.9,16-1,00

Input shaft case	32209 F	0635 373 021
Input shaft front	*	0750 117 381
Main shaft front	F 19019	0750 118 019
Main shaft	*	0735 320 379
Main shaft	F 17064 K	0750 115 227
Main shaft	F 17031 K	0735 320 378
Main shaft	F 17053 K	0735 320 493
Main shaft rear	NUP 311 FMNR/C3	0750 118 015
Output shaft rear	*	0735 340 080
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	F 17054 K	0750 115 011

5K-90 GP

Input shaft front	*	0735 370 033
Main shaft front	F 19019	0750 118 019
Main shaft	*	0735 320 731
Main shaft	*	0735 320 732
Main shaft	F 17064 K	0750 115 227
Main shaft	F 17104 K	0735 320 377
Main shaft	F 17102 K	0735 320 417
Main shaft rear	NUP 311 FMNR/C3	0750 118 015
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	F 17054 K	0750 115 011
Output shaft front	*	0735 340 080
Output shaft rear	*	0750 116 036
Selector mechanism	*	0635 303 053
Selector mechanism	*	0501 203 518

5K-91 GP

Input shaft front	*	0735 370 033
Main shaft front	F 19019	0750 118 019
Main shaft	*	0735 320 731
Main shaft	*	0735 320 732
Main shaft	F 17064 K	0750 115 227
Main shaft	F 17104 K	0735 320 377
Main shaft	F 17102 K	0735 320 417
Main shaft rear	NUP 311 FMNR/C3	0750 118 015
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	F 17054 K	0750 115 011
Output shaft front	*	0735 340 080
Output shaft rear	*	0750 116 036
Selector mechanism	*	0635 303 053
Selector mechanism	*	0501 203 518

POSITION	Fersa	OEM
ZF		
5S-90 GP		
Input shaft front	*	0735 370 033
Main shaft front	F 19019	0750 118 019
Main shaft	*	0735 320 731
Main shaft	*	0735 320 732
Main shaft	F 17064 K	0750 115 227
Main shaft	F 17104 K	0735 320 377
Main shaft	F 17102 K	0735 320 417
Main shaft rear	NUP 311 FMNR/C3	0750 118 015
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	F 17054 K	0750 115 011
Output shaft front	*	0735 340 080
Output shaft rear	*	0750 116 036
Selector mechanism	*	0635 303 053
Selector mechanism	*	0635 300 086
Selector mechanism	*	0501 203 518
5S-92 GP		
Input shaft front	*	0735 370 033
Main shaft front	F 19019	0750 118 019
Main shaft	*	0735 320 731
Main shaft	*	0735 320 732
Main shaft	F 17064 K	0750 115 227
Main shaft	F 17104 K	0735 320 377
Main shaft	F 17102 K	0735 320 417
Main shaft rear	NUP 311 FMNR/C3	0750 118 015
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	F 17054 K	0750 115 011
Output shaft front	*	0735 340 080
Output shaft rear	*	0750 116 036
Selector mechanism	*	0635 303 053
Selector mechanism	*	0635 300 086
Selector mechanism	*	0501 203 518
5K-90 GPA		
Input shaft front	*	0750 117 381
Input shaft case	32209 F	0635 373 021
Main shaft front	F 19019	0750 118 019
Main shaft	*	0735 320 731
Main shaft	*	0735 320 732
Main shaft	F 17064 K	0750 115 227
Main shaft	F 17104 K	0735 320 377
Main shaft	F 17102 K	0735 320 417
Main shaft rear	NUP 311 FMNR/C3	0750 118 015
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	F 17054 K	0750 115 011
Main shaft rear	*	0635 416 275
Output shaft front	*	0735 340 080
Output shaft rear	*	0750 116 036
GPA front	*	0735 330 025
GPA intermediate	*	0635 416 273
GPA intermediate	*	0635 416 243
GPA rear	*	0735 330 025
	32212 F	0635 373 008
Selector mechanism	*	0635 303 053
Selector mechanism	*	0501 203 518

POSITION	Fersa	OEM
----------	-------	-----

ZF
5K-91 GPA

Input shaft front	*	0750 117 381
Input shaft case	32209 F	0635 373 021
Main shaft front	F 19019	0750 118 019
Main shaft	*	0735 320 731
Main shaft	*	0735 320 732
Main shaft	F 17064 K	0750 115 227
Main shaft	F 17104 K	0735 320 377
Main shaft	F 17102 K	0735 320 417
Main shaft rear	NUP 311 FMNR/C3	0750 118 015
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	F 17054 K	0750 115 011
Main shaft rear	*	0635 416 275
Output shaft front	*	0735 340 080
Output shaft rear	*	0750 116 036
GPA front	*	0735 330 025
GPA intermediate	*	0635 416 273
GPA intermediate	*	0635 416 243
GPA rear	*	0735 330 025
	32212 F	0635 373 008
Selector mechanism	*	0635 303 053
Selector mechanism	*	0501 203 518

5S-90 GPA

Input shaft front	*	0750 117 381
Input shaft case	32209 F	0635 373 021
Main shaft front	F 19019	0750 118 019
Main shaft	*	0735 320 731
Main shaft	*	0735 320 732
Main shaft	F 17064 K	0750 115 227
Main shaft	F 17104 K	0735 320 377
Main shaft	F 17102 K	0735 320 417
Main shaft rear	NUP 311 FMNR/C3	0750 118 015
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	F 17054 K	0750 115 011
Main shaft rear	*	0635 416 275
Output shaft front	*	0735 340 080
Output shaft rear	*	0750 116 036
GPA front	*	0735 330 025
GPA intermediate	*	0635 416 273
GPA intermediate	*	0635 416 243
GPA rear	*	0735 330 025
	32212 F	0635 373 008
Selector mechanism	*	0635 303 053
Selector mechanism	*	0635 300 086
Selector mechanism	*	0501 203 518

AK6-80
R.6,70-0,82 + R.7,53-0,82

Input shaft front	NUP 314 FMNR/C3	0750 118 082
Main shaft front	*	0750 118 090
Main shaft	*	0735 320 314
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282

POSITION	Fersa	OEM
----------	-------	-----

ZF

AK6-80		R.6,70-0,82 + R.7,53-0,82
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear	6314 NR/C3	0635 333 049
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	F 17054 K	0750 115 011
Selector mechanism	*	0635 300 086
Selector mechanism	*	0635 303 053

AK6-80		R.6,70-0,73 + R.9,00-1,00
Input shaft front	NUP 314 FMNR/C3	0750 118 082
Input shaft front (Short type)	30217 F	0750 117 078
Input shaft case (Short type)	32209 F	0635 373 021
Main shaft front	*	0750 118 090
Main shaft	*	0735 320 314
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear	6314 NR/C3	0635 333 049
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	F 17054 K	0750 115 011
Selector mechanism	*	0635 300 086
Selector mechanism	*	0635 303 053

AK6-80+GV80		R.6,70-0,69 + R.7,67-0,78 + R.9,00-0,835
GV front	NUP 314 FMNR/C3	0750 118 081
GV	*	0750 115 089
Input shaft	*	0735 358 032
Input shaft front	NUP 314 FMNR/C3	0750 118 082
Splitter front	25590/25521	1246 203 011
Splitter rear	33889/33822	0750 117 083
Main shaft front	*	0750 118 090
Main shaft	*	0735 320 314
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear	6314 NR/C3	0635 333 049
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	F 17054 K	0750 115 011
Selector mechanism	*	0635 300 086
Selector mechanism	*	0635 303 053

AK6-90+GV90		R.7,03-0,58 + R.7,03-0,70 + R.7,03-0,82 + R.9,01-0,82
GV front	NUP 314 FMNR/C3	0750 118 081
GV	*	0750 115 089
Input shaft front	NUP 314 FMNR/C3	0750 118 082
Input shaft	*	0735 358 032
Splitter front	*	1269 298 951
Splitter rear	F 15047	0750 117 010

POSITION	Fersa	OEM
----------	-------	-----

ZF

AK6-90+GV90		<i>R.7,03-0,58 + R.7,03-0,70 + R.7,03-0,82 + R.9,01-0,82</i>
Main shaft front	*	0750 118 090
Main shaft	*	0735 320 314
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear (Bearing with ball)	6314 NR/C3	0635 333 049
Main shaft rear (Bearing with needle)	*	0635 410 167

AK6-90+GV90		<i>R.7,03-0,58 + R.7,03-0,70 + R.7,03-0,82 + R.9,01-0,82</i>
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	32309 F	0750 117 778
Reverse shaft	F 17054 K	0750 115 011
Selector mechanism	*	0635 300 086
Selector mechanism	*	0635 303 053
Selector mechanism	*	0635 303 062

AK6-90		<i>R.5,67-0,70 + R.6,37-0,74 + R.7,03-0,70 + R.7,03-1,00</i>
Input shaft front	NUP 314 FMNR/C3	0750 118 082
Main shaft front	*	0750 118 090
Main shaft	*	0735 320 314
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear	6314 NR/C3	0635 333 049
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	32309 F	0750 117 778
Reverse shaft	F 17054 K	0750 115 011
Selector mechanism	*	0635 300 086
Selector mechanism	*	0635 303 053
Selector mechanism	*	0635 303 062

GV 80		
GV front	NUP 314 FMNR/C3	0750 118 081
GV	*	0750 115 089
Input shaft front	NUP 314 FMNR/C3	0750 118 082
Input shaft	*	0735 358 032
Splitter	33889/33822	0750 117 083
Splitter	25590/25521	1246 203 011

GV 90		
GV front	NUP 314 FMNR/C3	0750 118 081
GV	*	0750 115 089
Input shaft front	NUP 314 FMNR/C3	0750 118 082
Input shaft	*	0735 358 032
Splitter	F 15047	0750 117 010
Splitter	*	0750 117 203

POSITION	Fersa	OEM
----------	-------	-----

ZF

5K-110 GPA		
GV front	30217 F	0750 117 078
GV case	32209 F	0635 373 021
Main shaft front	F 19019	0750 118 019
Main shaft	F 17052 K	0735 320 396
Main shaft	F 17053 K	0735 320 493
Main shaft	F 17051 K	0735 320 371
Main shaft	F 17051 K	0735 320 371
Main shaft	F 17051 K	0735 320 371
Main shaft rear	NUP 314 FMNR/C3	0750 118 081
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	F 15047	0750 117 010
Reverse shaft	F 17054 K	0750 115 011
Main shaft rear	NJ 1024 FM	0635 416 244
Output shaft front	*	0635 330 050
Output shaft rear	6314 NR/C3	0635 333 049
	*	1269 298 966
GPA front	*	0735 330 025
GPA intermediate	*	0635 332 132
GPA intermediate	*	0635 416 243
GPA rear	*	0735 330 025
Selector mechanism	*	0635 303 053
Selector mechanism	*	0501 203 518

5S-110 GPA		
GV front	30217 F	0750 117 078
GV case	32209 F	0635 373 021
Main shaft front	F 19019	0750 118 019
Main shaft	F 17052 K	0735 320 396
Main shaft	F 17053 K	0735 320 493
Main shaft	F 17051 K	0735 320 371
Main shaft	F 17051 K	0735 320 371
Main shaft	F 17051 K	0735 320 371
Main shaft rear	NUP 314 FMNR/C3	0750 118 081
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	F 15047	0750 117 010
Reverse shaft	F 17054 K	0750 115 011
Main shaft rear	NJ 1024 FM	0635 416 244
Output shaft front	*	0635 330 050
Output shaft rear	6314 NR/C3	0635 333 049
	*	1269 298 966
GPA front	*	0735 330 025
GPA intermediate	*	0635 332 132
GPA intermediate	*	0635 416 243
GPA rear	*	0735 330 025
Selector mechanism	*	0635 303 053
Selector mechanism	*	0501 203 518

5K-110 GP		
Input shaft front	F 19022	0750 118 129
Main shaft front	F 19019	0750 118 019
Main shaft	F 17052 K	0735 320 396
Main shaft	F 17053 K	0735 320 493
Main shaft	F 17051 K	0735 320 371
Main shaft	F 17051 K	0735 320 371
Main shaft	F 17051 K	0735 320 371
Main shaft rear	NUP 314 FMNR/C3	0750 118 081
Counter shaft front	F 15047	0750 117 010

POSITION	Fersa	OEM
----------	-------	-----

ZF

5K-110 GP

Counter shaft rear	F 15047	0750 117 010
Reverse shaft	F 17054 K	0750 115 011
Output shaft front	*	0635 330 050
Output shaft rear	6314 NR/C3	0635 333 049
Selector mechanism	*	0635 303 053
Selector mechanism	*	0501 203 518

5S-110 GP

Input shaft front	F 19022	0750 118 129
Main shaft front	F 19019	0750 118 019
Main shaft	F 17052 K	0735 320 396
Main shaft	F 17053 K	0735 320 493
Main shaft	F 17051 K	0735 320 371
Main shaft	F 17051 K	0735 320 371
Main shaft	F 17051 K	0735 320 371
Main shaft rear	NUP 314 FMNR/C3	0750 118 081
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	F 15047	0750 117 010
Reverse shaft	F 17054 K	0750 115 011
Output shaft front	*	0635 330 050
Output shaft rear	6314 NR/C3	0635 333 049
Selector mechanism	*	0635 303 053
Selector mechanism	*	0501 203 518

5K-110 GPA+GV90/1

GV front	30217 F	0750 117 078
GV case	32209 F	0635 373 021
GV	*	0750 115 089
Input shaft front	F 19022	0750 118 129
Input shaft	*	0735 358 032
Splitter front	*	1269 298 951
Splitter rear	F 15047	0750 117 010
Main shaft front	F 19019	0750 118 019
Main shaft	F 17052 K	0735 320 396
Main shaft	F 17053 K	0735 320 493
Main shaft	F 17051 K	0735 320 371
Main shaft	F 17051 K	0735 320 371
Main shaft	F 17051 K	0735 320 371
Main shaft rear	NUP 314 FMNR/C3	0750 118 081
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	F 15047	0750 117 010
Reverse shaft	F 17054 K	0750 115 011
Main shaft rear	NJ 1024 FM	0635 416 244
Output shaft front	*	0635 330 050
Output shaft rear	6314 NR/C3	0635 333 049
	*	1269 298 966
GPA front	*	0735 330 025
GPA intermediate	*	0635 332 132
GPA intermediate	*	0635 416 243
Splitter rear	*	0735 330 025
Selector mechanism	*	0635 303 053
Selector mechanism	*	0501 203 518

POSITION	Fersa	OEM
ZF		
5S-110 GPA+GV90/1		
GV front	30217 F	0750 117 078
GV case	32209 F	0635 373 021
GV	*	0750 115 089
Input shaft front	F 19022	0750 118 129
Input shaft	*	0735 358 032
Splitter front	*	1269 298 951
Splitter rear	F 15047	0750 117 010
Main shaft front	F 19019	0750 118 019
Main shaft	F 17052 K	0735 320 396
Main shaft	F 17053 K	0735 320 493
Main shaft	F 17051 K	0735 320 371
Main shaft	F 17051 K	0735 320 371
Main shaft	F 17051 K	0735 320 371
Main shaft rear	NUP 314 FMNR/C3	0750 118 081
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	F 15047	0750 117 010
Reverse shaft	F 17054 K	0750 115 011
Main shaft rear	NJ 1024 FM	0635 416 244
Output shaft front	*	0635 330 050
Output shaft rear	6314 NR/C3	0635 333 049
	*	1269 298 966
GPA front	*	0735 330 025
GPA intermediate	*	0635 332 132
GPA intermediate	*	0635 416 243
Splitter rear	*	0735 330 025
Selector mechanism	*	0635 303 053
Selector mechanism	*	0501 203 518

5K-110 GP+GV90/1		
GV	*	0750 115 089
GV front	F 19022	0750 118 129
Input shaft front	F 19022	0750 118 129
Input shaft	*	0735 358 032
Splitter front	*	1269 298 951
Splitter rear	F 15047	0750 117 010
Main shaft front	F 19019	0750 118 019
Main shaft	F 17052 K	0735 320 396
Main shaft	F 17053 K	0735 320 493
Main shaft	F 17051 K	0735 320 371
Main shaft	F 17051 K	0735 320 371
Main shaft	F 17051 K	0735 320 371
Main shaft rear	NUP 314 FMNR/C3	0750 118 081
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	F 15047	0750 117 010
Reverse shaft	F 17054 K	0750 115 011
Output shaft front	*	0635 330 050
Output shaft rear	6314 NR/C3	0635 333 049
Selector mechanism	*	0635 490 006
Selector mechanism	*	0635 303 053
Selector mechanism	*	0501 203 518

5S-90 GP		
Input shaft front	*	0735 370 033
Main shaft front	F 19019	0750 118 019
Main shaft	*	0735 320 731
Main shaft	*	0735 320 732
Main shaft	F 17064 K	0750 115 227

POSITION	Fersa	OEM
----------	-------	-----

ZF

5S-90 GP

Main shaft	F 17104 K	0735 320 377
Main shaft	F 17102 K	0735 320 417
Main shaft rear	NUP 311 FMNR/C3	0750 118 015
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	F 17054 K	0750 115 011
Output shaft front	*	0735 340 080
Output shaft rear	*	0750 116 036
Selector mechanism	*	0635 303 053
Selector mechanism	*	0635 300 086
Selector mechanism	*	0501 203 518

5S-92 GP

Input shaft front	*	0735 370 033
Main shaft front	F 19019	0750 118 019
Main shaft	*	0735 320 731
Main shaft	*	0735 320 732
Main shaft	F 17064 K	0750 115 227
Main shaft	F 17104 K	0735 320 377
Main shaft	F 17102 K	0735 320 417
Main shaft rear	NUP 311 FMNR/C3	0750 118 015
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	F 17054 K	0750 115 011
Output shaft front	*	0735 340 080
Output shaft rear	*	0750 116 036
Selector mechanism	*	0635 303 053
Selector mechanism	*	0635 300 086
Selector mechanism	*	0501 203 518

5S-90 GPA

Input shaft front	*	0750 117 381
Input shaft case	32209 F	0635 373 021
Main shaft front	F 19019	0750 118 019
Main shaft	*	0735 320 731
Main shaft	*	0735 320 732
Main shaft	F 17064 K	0750 115 227
Main shaft	F 17104 K	0735 320 377
Main shaft	F 17102 K	0735 320 417
Main shaft rear	NUP 311 FMNR/C3	0750 118 015
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	F 17054 K	0750 115 011
Main shaft rear	*	0635 416 275
Output shaft front	*	0735 340 080
Output shaft rear	*	0750 116 036
GPA front	*	0735 330 025
GPA intermediate	*	0635 416 273
GPA intermediate	*	0635 416 243
GPA rear	*	0735 330 025
	32212 F	0635 373 008
Selector mechanism	*	0635 303 053
Selector mechanism	*	0635 300 086
Selector mechanism	*	0501 203 518

POSITION	Fersa	OEM
----------	-------	-----

ZF

5S-110 GPA

GV front	30217 F	0750 117 078
GV case	32209 F	0635 373 021
Main shaft front	F 19019	0750 118 019
Main shaft	F 17052 K	0735 320 396
Main shaft	F 17053 K	0735 320 493
Main shaft	F 17051 K	0735 320 371
Main shaft	F 17051 K	0735 320 371
Main shaft	F 17051 K	0735 320 371
Main shaft rear	NUP 314 FMNR/C3	0750 118 081
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	F 15047	0750 117 010
Reverse shaft	F 17054 K	0750 115 011
Main shaft rear	NJ 1024 FM	0635 416 244
Output shaft front	*	0635 330 050
Output shaft rear	6314 NR/C3	0635 333 049
	*	1269 298 966
GPA front	*	0735 330 025
GPA intermediate	*	0635 332 132
GPA intermediate	*	0635 416 243
GPA rear	*	0735 330 025
Selector mechanism	*	0635 303 053
Selector mechanism	*	0501 203 518

5S-110 GP

Input shaft front	F 19022	0750 118 129
Main shaft front	F 19019	0750 118 019
Main shaft	F 17052 K	0735 320 396
Main shaft	F 17053 K	0735 320 493
Main shaft	F 17051 K	0735 320 371
Main shaft	F 17051 K	0735 320 371
Main shaft	F 17051 K	0735 320 371
Main shaft rear	NUP 314 FMNR/C3	0750 118 081
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	F 15047	0750 117 010
Reverse shaft	F 17054 K	0750 115 011
Output shaft front	*	0635 330 050
Output shaft rear	6314 NR/C3	0635 333 049
Selector mechanism	*	0635 303 053
Selector mechanism	*	0501 203 518

5S-110 GPA+GV90/1

GV front	30217 F	0750 117 078
GV case	32209 F	0635 373 021
GV	*	0750 115 089
Input shaft front	F 19022	0750 118 129
Input shaft	*	0735 358 032
Splitter front	*	1269 298 951
Splitter rear	F 15047	0750 117 010
Main shaft front	F 19019	0750 118 019
Main shaft	F 17052 K	0735 320 396
Main shaft	F 17053 K	0735 320 493
Main shaft	F 17051 K	0735 320 371
Main shaft	F 17051 K	0735 320 371
Main shaft	F 17051 K	0735 320 371

POSITION	Fersa	OEM
----------	-------	-----

ZF

5S-110 GPA+GV90/1

Main shaft rear	NUP 314 FMNR/C3	0750 118 081
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	F 15047	0750 117 010
Reverse shaft	F 17054 K	0750 115 011
Main shaft rear	NJ 1024 FM	0635 416 244
Output shaft front	*	0635 330 050
Output shaft rear	6314 NR/C3	0635 333 049
	*	1269 298 966
GPA front	*	0735 330 025
GPA intermediate	*	0635 332 132
GPA intermediate	*	0635 416 243
Splitter rear	*	0735 330 025
Selector mechanism	*	0635 303 053
Selector mechanism	*	0501 203 518

5S-110 GP+GV90/1

GV	*	0750 115 089
GV front	F 19022	0750 118 129
Input shaft front	F 19022	0750 118 129
Input shaft	*	0735 358 032
Splitter front	*	1269 298 951
Splitter rear	F 15047	0750 117 010
Main shaft front	F 19019	0750 118 019
Main shaft	F 17052 K	0735 320 396
Main shaft	F 17053 K	0735 320 493
Main shaft	F 17051 K	0735 320 371
Main shaft	F 17051 K	0735 320 371
Main shaft	F 17051 K	0735 320 371
Main shaft rear	NUP 314 FMNR/C3	0750 118 081
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	F 15047	0750 117 010
Reverse shaft	F 17054 K	0750 115 011
Output shaft front	*	0635 330 050
Output shaft rear	6314 NR/C3	0635 333 049
Selector mechanism	*	0635 490 006
Selector mechanism	*	0635 303 053
Selector mechanism	*	0501 203 518

5S-111 GP

Input shaft front	F 19022	0750 118 129
Main shaft front	F 19019	0750 118 019
Main shaft	F 17099 K	0735 320 499
Main shaft	F 17101 K	0735 320 465
Main shaft	F 17083 K	0735 320 418
Main shaft	F 17100 K	0735 320 466
Main shaft	F 17100 K	0735 320 466
Main shaft rear	NUP 314 FMNR/C3	0750 118 081
Output shaft front	*	0635 330 050
Output shaft rear	6314 NR/C3	0635 333 049
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	F 15047	0750 117 010
Reverse shaft	F 17054 K	0750 115 011

POSITION	Fersa	OEM
ZF		
5S-111 GPA		
Input shaft front	3021 F	0750 117 078
Input shaft case	32209 F	0635 373 021
Main shaft front	F 19019	0750 118 019
Main shaft	F 17099 K	0735 320 499
Main shaft	F 17101 K	0735 320 465
Main shaft	F 17083 K	0735 320 418
Main shaft	F 17100 K	0735 320 466
Main shaft	F 17100 K	0735 320 466
Main shaft rear	NUP 314 FMNR/C3	0750 118 081
Main shaft rear	NJ 1024 FM	0635 416 244
Output shaft front	*	0635 330 050
Output shaft rear	6314 NR/C3	0635 333 049
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	F 15047	0750 117 010
Reverse shaft	F 17054 K	0750 115 011
GPA front	*	0735 330 025
GPA intermediate	*	0635 332 132
GPA intermediate	*	0635 416 243
GPA rear	*	0735 330 025
	*	1269 298 966
5S-111 GP+GV90/1		
Input shaft front	F 19022	0750 118 129
GV	*	0750 115 089
GV front	F 19022	0750 118 129
Input shaft	*	0735 358 032
Splitter front	*	1269 298 951
Splitter rear	F 15047	0750 117 010
Main shaft front	F 19019	0750 118 019
Main shaft	F 17099 K	0735 320 499
Main shaft	F 17101 K	0735 320 465
Main shaft	F 17083 K	0735 320 418
Main shaft	F 17100 K	0735 320 466
Main shaft	F 17100 K	0735 320 466
Main shaft rear	NUP 314 FMNR/C3	0750 118 081
Output shaft front	*	0635 330 050
Output shaft rear	6314 NR/C3	0635 333 049
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	F 15047	0750 117 010
Reverse shaft	F 17054 K	0750 115 011
Selector mechanism	*	0635 300 086
Selector mechanism	*	0501 203 518
Selector mechanism	*	0635 303 053
6S-850		
Input shaft front	F 18054	0735 330 800
Main shaft front	*	0735 358 128
Main shaft	*	0735 321 527
Main shaft	*	0735 321 528
Main shaft	*	0735 321 529
Main shaft	*	0735 321 530
Main shaft	*	0735 321 531
Main shaft rear	6309 2RS	0750 116 373
Counter shaft front	344/332	0735 371 607
Counter shaft rear	2789/2729	0735 370 438
Reverse shaft	*	0635 300 110

POSITION	Fersa	OEM
----------	-------	-----

ZF

8S-1350

Main shaft	*	0501 398 211
Main shaft	F 17082 K	0735 320 496
Main shaft	*	0735 320 471
Counter shaft front	F 15047	0750 117 883
Counter shaft rear	32310 F	0750 117 008
Main shaft front	F 19009	0735 410 057
Main shaft rear	F 19075	0750 118 010
	*	0750 116 166
Case housing	6218 C3	0750 116 394
	*	0735 298 125
Input shaft front	F 19008	0750 118 130
Reverse shaft	F 17085 K	0750 115 059

9S-75

Input shaft front	45285 A/45221	0750 117 312
Main shaft front	2580/2520	1307 203 019
Main shaft	F 17059 K	0735 321 494
Main shaft	F 17059 K	0735 321 494
Main shaft	F 17058 K	0735 321 012
Main shaft	F 17057 K	0750 115 427
Main shaft	F 17056 K	0750 115 533
Main shaft rear	33885/33822	1246 203 008
Counter shaft front	3386/3325	0735 370 742
Counter shaft rear	2789/2729	0750 117 198
Reverse shaft	*	0735 358 192
Output shaft front	*	0635 338 090
Output shaft rear	*	0735 330 597

16S-112

R.11,46-0,85 + R.13,68-1,00

Input shaft front	F 19008	0750 118 131
Input shaft front (Only with R.13,68-1,00. With input shaft 1296 202 004)	*	0750 118 007
Input shaft front (Only with R.13,68-1,00)	*	0750 117 431
Input shaft	*	0735 320 799
Input shaft (Only with R.13,68-1,00. With input shaft 1296 202 004)	*	0735 358 155
Input shaft case (Only with R.13,68-1,00)	32210 F	0750 117 651
Main shaft front	F 19075	0750 118 010
Main shaft intermediate	*	0750 118 012
Main shaft	*	0735 320 460
Main shaft	*	0735 320 549
Main shaft	*	0735 320 548
Main shaft	F 17085 K	0750 115 059
Main shaft rear	F 19009	0750 118 153
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	4580/4535	0750 117 011
Reverse shaft	F 17054 K	0750 115 011
Output shaft front	*	0750 116 166
Output shaft rear	6218 C3	0750 116 002

POSITION	Fersa	OEM
----------	-------	-----

ZF

16K-130		R.11,46-0,85 + R.13,68-1,00
Input shaft front	F 19008	0750 118 131
Input shaft front (With input shaft 1295 202 036)	*	0750 117 431
Input shaft	F 17084 K	0735 320 786
Main shaft front	F 19075	0750 118 010
Main shaft intermediate	*	0750 118 017
Main shaft	*	0735 320 460
Main shaft	*	0735 320 461
Main shaft	F 17085 K	0750 115 059
Main shaft rear	F 19009	0750 118 153
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	4580/4535	0750 117 011
Reverse shaft	F 17054 K	0750 115 011
Output shaft front	*	0750 116 166
Output shaft rear	6218 C3	0750 116 002

16K-130		R.14,29-0,82
Input shaft front	F 19008	0750 118 131
Input shaft front (With input shaft 1295 202 036)	*	0750 117 431
Input shaft	F 17084 K	0735 320 786
Main shaft front	F 19075	0750 118 010
Main shaft intermediate	*	0750 118 017
Main shaft	*	0735 320 460
Main shaft	*	0735 320 461
Main shaft	F 17085 K	0750 115 059
Main shaft rear	*	0750 118 137
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	4580/4535	0750 117 011
Reverse shaft	F 17054 K	0750 115 011
Output shaft front	*	0750 116 166
Output shaft rear	6218 C3	0750 116 002

16K-160		R.11,46-0,85 + R.13,68-1,00
Input shaft front	F 19008	0750 118 131
Input shaft	F 17081 K	0735 320 896
Main shaft front	F 19037	0750 118 038
Main shaft intermediate	F 19016	0750 118 005
Main shaft	F 17083 K	0735 320 418
Main shaft	*	0735 320 568
Main shaft	F 17088 K	0735 320 486
Main shaft rear	F 19009	0750 118 153
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	32310 F	0750 117 008
Reverse shaft	F 17054 K	0750 115 011
Output shaft front	F 18052	0750 116 165
Output shaft rear	6218 C3	0750 116 002

16K-160		R.14,29-0,82
Input shaft front	F 19008	0750 118 131
Input shaft	F 17081 K	0735 320 896
Main shaft front	F 19037	0750 118 038
Main shaft intermediate	F 19016	0750 118 005
Main shaft	F 17083 K	0735 320 418

POSITION	Fersa	OEM
----------	-------	-----

ZF
16K-160
R.14,29-0,82

Main shaft	*	0735 320 568
Main shaft	F 17088 K	0735 320 486
Main shaft rear	*	0750 118 137
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	32310 F	0750 117 008
Reverse shaft	F 17054 K	0750 115 011
Output shaft front	F 18052	0750 116 165
Output shaft rear	6218 C3	0750 116 002

16K-190
R.11,46-0,85 + R.13,68-1,00

Input shaft front	F 19008	0750 118 131
Input shaft	F 17081 K	0735 320 896
Main shaft front	F 19037	0750 118 038
Main shaft intermediate	F 19016	0750 118 005
Main shaft	F 17083 K	0735 320 418
Main shaft	*	0735 320 568
Main shaft	F 17088 K	0735 320 486
Main shaft rear	F 19009	0750 118 153
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	32310 F	0750 117 008
Reverse shaft	F 17054 K	0750 115 011
Output shaft front	F 18052	0750 116 165
Output shaft rear	6218 C3	0750 116 002

16K-190
R.14,29-0,82

Input shaft front	F 19008	0750 118 131
Input shaft	F 17081 K	0735 320 896
Main shaft front	F 19037	0750 118 038
Main shaft intermediate	F 19016	0750 118 005
Main shaft	F 17083 K	0735 320 418
Main shaft	*	0735 320 568
Main shaft	F 17088 K	0735 320 486
Main shaft rear	*	0750 118 137
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	32310 F	0750 117 008
Reverse shaft	F 17054 K	0750 115 011
Output shaft front	F 18052	0750 116 165
Output shaft rear	6218 C3	0750 116 002

16S-130
R.10,14-0,72

Input shaft case	32210 F	0750 117 651
Input shaft front	F 19008	0750 118 131
Main shaft front	F 19075	0750 118 010
Main shaft intermediate	F 19016	0750 118 005
Main shaft	F 17083 K	0735 320 418
Main shaft	F 17098 K	0735 320 451
Main shaft	*	0735 320 548
Main shaft	F 17085 K	0750 115 059
Main shaft rear	F 19009	0750 118 153
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	32310 F	0750 117 008
Output shaft front	*	0750 116 166
Output shaft rear	6218 C3	0750 116 002

POSITION	Fersa	OEM
ZF		
16S-130		<i>R.11,46-0,85</i>
Input shaft case (With input shaft 1295 202 036)	32210 F	0750 117 651
Input shaft front	F 19008	0750 118 131
Input shaft front (With input shaft 1295 202 036)	*	0750 117 431
Main shaft front	F 19075	0750 118 010
Main shaft intermediate	F 19016	0750 118 005
Main shaft	F 17083 K	0735 320 418
Main shaft	F 17083 K	0735 320 418
Main shaft	F 17082 K	0735 320 496
Main shaft	F 17085 K	0750 115 059
Main shaft rear	F 19009	0750 118 153
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	32310 F	0750 117 008
Output shaft front	*	0750 116 166
Output shaft rear	6218 C3	0750 116 002
16S-130		<i>R.13,68-1,00</i>
Input shaft case (With input shaft 1295 202 036)	32210 F	0750 117 651
Input shaft front	F 19008	0750 118 131
Input shaft front (Old Type)	*	0750 118 007
Input shaft front (With input shaft 1295 202 036)	*	0750 117 431
Main shaft front	F 19075	0750 118 010
Main shaft intermediate	F 19016	0750 118 005
Main shaft	F 17083 K	0735 320 418
Main shaft	F 17083 K	0735 320 418
Main shaft	F 17082 K	0735 320 496
Main shaft	F 17085 K	0750 115 059
Main shaft rear	F 19009	0750 118 153
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	32310 F	0750 117 008
Output shaft front	*	0750 116 166
Output shaft rear	6218 C3	0750 116 002
16S-130		<i>R.14,29-0,82</i>
Input shaft case (With input shaft 1295 202 036)	32210 F	0750 117 651
Input shaft front	F 19008	0750 118 130
Input shaft front (With input shaft 1295 202 036)	*	0750 117 431
Main shaft front	F 19075	0750 118 010
Main shaft intermediate	F 19016	0750 118 005
Main shaft	F 17083 K	0735 320 418
Main shaft	F 17083 K	0735 320 418
Main shaft	F 17082 K	0735 320 496
Main shaft	F 17085 K	0750 115 059
Main shaft rear	*	0750 118 137
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	32310 F	0750 117 008
Output shaft front	F 18052	0750 116 165
Output shaft rear	6218 C3	0750 116 002

POSITION	Fersa	OEM
----------	-------	-----

ZF
16S-160
R.11,46-0,85

Input shaft front	F 19008	0750 118 130
Input shaft	F 17081 K	0735 320 896
Main shaft front	F 19037	0750 118 038
Main shaft intermediate	F 19038	0750 118 220
Main shaft	F 17098 K	0735 320 451
Main shaft	F 17087 K	0735 320 452
Main shaft	F 17086 K	0735 320 487
Main shaft	F 17088 K	0735 320 486
Main shaft rear	F 19010	0750 118 006
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	5395/5335	0750 117 009
Reverse shaft	F 17054 K	0750 115 011
Output shaft front	F 18052	0750 116 165
Output shaft rear	6218 C3	0750 116 002

16S-160
R.13,68-1,00

Input shaft front	F 19008	0750 118 130
Input shaft front	*	0750 118 007
Input shaft	F 17081 K	0735 320 896
Input shaft (Special MB version)	*	0735 358 155
Input shaft front	*	0750 117 431
Input shaft case	32210 F	0750 117 651
Main shaft front	F 19037	0750 118 038
Main shaft intermediate	F 19038	0750 118 220
Main shaft	F 17098 K	0735 320 451
Main shaft	F 17087 K	0735 320 452
Main shaft	F 17086 K	0735 320 487
Main shaft	F 17088 K	0735 320 486
Main shaft rear	F 19010	0750 118 006
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	5395/5335	0750 117 009
Reverse shaft	F 17054 K	0750 115 011
Output shaft front	F 18052	0750 116 165
Output shaft rear	6218 C3	0750 116 002

16S-160
R.14,29-0,82 + R.17,06-1,00

Input shaft front	F 19008	0750 118 130
Input shaft	F 17081 K	0735 320 896
Input shaft front	*	0750 117 431
Input shaft case	32210 F	0750 117 651
Main shaft front	F 19037	0750 118 038
Main shaft intermediate	F 19038	0750 118 220
Main shaft	F 17098 K	0735 320 451
Main shaft	F 17087 K	0735 320 452
Main shaft	F 17086 K	0735 320 487
Main shaft	F 17088 K	0735 320 486
Main shaft rear	F 19039	0750 118 180
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	5395/5335	0750 117 009
Reverse shaft	F 17054 K	0750 115 011
Output shaft front	F 18052	0750 116 165
Output shaft rear	6218 C3	0750 116 002

POSITION	Fersa	OEM
ZF		
16S-190		<i>R.11,46-0,85 + R.13,68-1,00</i>
Input shaft front	F 19008	0750 118 131
Input shaft	F 17081 K	0735 320 896
Main shaft front	F 19037	0750 118 038
Main shaft intermediate	F 19038	0750 118 220
Main shaft	F 17098 K	0735 320 451
Main shaft	F 17087 K	0735 320 452
Main shaft	F 17088 K	0735 320 486
Main shaft rear	F 19010	0750 118 006
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	5395/5335	0750 117 009
Reverse shaft	F 17054 K	0750 115 011
Output shaft front	F 18052	0750 116 165
Output shaft rear	6218 C3	0750 116 002
Output shaft front (New Reinforced Style)	*	0635 338 035
16S-190		<i>R.14,29-0,82 + R.17,06-1,00</i>
Input shaft front	F 19008	0750 118 131
Input shaft	F 17081 K	0735 320 896
Main shaft front	F 19037	0750 118 038
Main shaft intermediate	F 19038	0750 118 220
Main shaft	F 17098 K	0735 320 451
Main shaft	F 17087 K	0735 320 452
Main shaft	F 17088 K	0735 320 486
Main shaft rear	F 19039	0750 118 180
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	5395/5335	0750 117 009
Reverse shaft	F 17054 K	0750 115 011
Output shaft front	F 18052	0750 116 165
Output shaft rear	6218 C3	0750 116 002
Output shaft front (New Reinforced Style)	*	0635 338 035
16S-220		<i>R.10,14-0,72</i>
Input shaft front	F 19008	0750 118 131
Input shaft	*	0735 320 950
Main shaft front	CONE 4395	0750 117 232
Main shaft intermediate	F 19062	0750 118 258
Main shaft	F 17098 K	0735 320 451
Main shaft	*	0750 115 303
Main shaft	*	0750 115 304
Main shaft	*	0735 321 103
Main shaft rear	*	0750 117 233
Counter shaft front	5395/5335	0750 117 009
Counter shaft rear	5395/5335	0750 117 009
Reverse shaft	*	0750 115 255
Output shaft front	*	0635 338 035
Output shaft rear	6218 C3	0750 116 002
16S-220		<i>R.13,80-0,84 + R.16,47-1,00</i>
Input shaft front	F 19008	0750 118 131
Input shaft	*	0735 320 950
Input shaft front (short type)	*	0750 117 431
Input shaft case (short type)	45285 A/45221	0750 117 312
Main shaft front	CONE 4395	0750 117 232
Main shaft intermediate	F 19062	0750 118 258
Main shaft	*	0750 115 303
Main shaft	*	0750 115 303

POSITION	Fersa	OEM
----------	-------	-----

ZF

16S-220		<i>R. 13,80-0,84 + R. 16,47-1,00</i>
Main shaft	*	0750 115 327
Main shaft	*	0750 115 326
Main shaft rear	F 15191	0750 117 678
Counter shaft front	5395/5335	0750 117 009
Counter shaft rear	5395/5335	0750 117 009
Reverse shaft	*	0750 115 255
Output shaft front	*	0635 338 035
Output shaft rear	6218 C3	0750 116 002

16S-1300		
Input shaft front	F 19008	0750 118 131
Main shaft	F 17082 K	0735 320 496
Main shaft	*	0750 115 955
Main shaft intermediate	F 19016	0735 455 114
Case housing	*	0635 303 053
Main shaft	*	0501 398 351
Counter shaft front	F 15047	0750 117 883
Counter shaft rear	32310 F	0750 117 008
Main shaft front	F 19009	0735 410 057
Main shaft rear	F 19075	0750 118 010
	*	0735 298 125
	*	0750 116 166
Case housing	6218 C3	0750 116 394
Input shaft front	F 19008	0750 118 130
Reverse shaft	F 17085 K	0750 115 059

16S-1600		
Input shaft front	F 19008	0750 118 131
Main shaft	*	0750 115 956
Main shaft	*	0750 115 958
Main shaft	*	0750 115 955
Main shaft intermediate	F 19038	0750 118 220
	F 19010	0501 398 714
Counter shaft front	F 15047	0750 117 883
Counter shaft rear	5395/5335	0750 117 009
Reduction	F 18052	0750 116 422
Main shaft rear	F 19037	0750 118 038
	*	0735 298 125
	6218 C3	0750 116 394
Input shaft front	F 19008	0750 118 130
Reverse shaft	*	0750 115 957

16S-1650		
Input shaft front	F 19008	0750 118 131
Main shaft	*	0750 115 956
Main shaft	*	0750 115 955
Main shaft	*	0750 115 958
Main shaft intermediate	F 19016	0735 455 114
(Direct drive housing)	F 19010	0501 398 714
(Over drive housing)	F 19039	0750 118 471
Counter shaft front	F 15047	0750 117 883
Counter shaft rear (Before 02/96)	5395/5335	0750 117 009
Counter shaft rear (After 02/96)	32310 F	0750 117 008
Output shaft front	F 18052	0750 116 422

POSITION	Fersa	OEM
ZF		
16S-1650		
Main shaft rear	6218 C3	0750 116 394
Main shaft front	F 19037	0750 118 038
Input shaft front	F 19008	0750 118 130
Reverse shaft	*	0750 115 957
	*	0735 298 125
16S-1900		
Input shaft front	F 19008	0750 118 131
Main shaft	*	0750 115 956
Main shaft	*	0750 115 955
Main shaft	*	0750 115 958
Main shaft intermediate	F 19038	0750 118 220
	F 19010	0501 398 714
Counter shaft front	F 15047	0750 117 883
Counter shaft rear	5395/5335	0750 117 009
Reduction	F 18052	0750 116 422
	6218 C3	0750 116 394
Main shaft rear	F 19037	0750 118 038
Input shaft front	F 19008	0750 118 130
Reverse shaft	*	0750 115 957
	*	0735 298 125
AK6-80 <i>R.6,70-0,82 + R.7,53-0,82</i>		
Input shaft front	F 19008	0750 118 131
Main shaft front	*	0750 118 090
Main shaft	*	0735 320 314
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear	6314 NR/C3	0635 333 049
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	F 17054 K	0750 115 011
Selector mechanism	*	0635 300 086
Selector mechanism	*	0635 303 053
AK6-80 <i>R.6,70-0,73 + R.9,00-1,00</i>		
Input shaft front	F 19008	0750 118 131
Input shaft front	30217 F	0750 117 078
Input shaft case	32209 F	0635 373 021
Main shaft front	*	0750 118 090
Main shaft	*	0735 320 314
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear	6314 NR/C3	0635 333 049
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	F 17054 K	0750 115 011
Selector mechanism	*	0635 300 086
Selector mechanism	*	0635 303 053

POSITION	Fersa	OEM
----------	-------	-----

ZF

AK6-80+GV80		<i>R.6,70-0,69 + R.7,67-0,78 + R.9,00-0,835</i>
Input shaft front	F 19008	0750 118 131
GV	*	0750 115 089
Input shaft	*	0735 358 032
Input shaft front	NUP 314 FMNR/C3	0750 118 082
Splitter front	25590/25521	1246 203 011
Splitter rear	33889/33822	0750 117 083
Main shaft front	*	0750 118 090
Main shaft	*	0735 320 314
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear	6314 NR/C3	0635 333 049
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	F 17054 K	0750 115 011
Selector mechanism	*	0635 300 086
Selector mechanism	*	0635 303 053

AK6-90		<i>R.5,67-0,70 + R.6,37-0,74 + R.7,03-0,70 + R.7,03-1,00</i>
Input shaft front	F 19008	0750 118 131
Main shaft front	*	0750 118 090
Main shaft	*	0735 320 314
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear	6314 NR/C3	0635 333 049
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	32309 F	0750 117 778
Reverse shaft	F 17054 K	0750 115 011
Selector mechanism	*	0635 300 086
Selector mechanism	*	0635 303 053
Selector mechanism	*	0635 303 062

AK6-90+GV90		<i>R.7,03-0,58 + R.7,03-0,70 + R.7,03-0,82 + R.9,01-0,82</i>
Input shaft front	F 19008	0750 118 131
GV	*	0750 115 089
Input shaft front	NUP 314 FMNR/C3	0750 118 082
Input shaft	*	0735 358 032
Splitter front	*	1269 298 951
Splitter rear	F 15047	0750 117 010
Main shaft front	*	0750 118 090
Main shaft	*	0735 320 314
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear	6314 NR/C3	0635 333 049
Main shaft rear	*	0635 410 167
Counter shaft front	F 15047	0750 117 010

POSITION	Fersa	OEM
ZF		
AK6-90+GV90 <i>R.7,03-0,58 + R.7,03-0,70 + R.7,03-0,82 + R.9,01-0,82</i>		
Counter shaft rear	32309 F	0750 117 778
Reverse shaft	F 17054 K	0750 115 011
Selector mechanism	*	0635 300 086
Selector mechanism	*	0635 303 053
Selector mechanism	*	0635 303 062
AK6-90 <i>R.7,03-0,81 + R.9,01-1,00</i>		
Input shaft front	F 19008	0750 118 131
Input shaft front	30217 F	0750 117 078
Input shaft case	32209 F	0635 373 021
Main shaft front (Input shaft 1268 302 057)	*	0750 118 090
Main shaft front (Input shaft 1268 302 135)	*	0735 455 012
Main shaft (Input shaft 1268 302 057)	*	0735 320 314
Main shaft (Input shaft 1268 302 135)	F 17099 K	0735 320 499
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear	6314 NR/C3	0635 333 049
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	32309 F	0750 117 778
Reverse shaft	F 17054 K	0750 115 011
Selector mechanism	*	0635 300 086
Selector mechanism	*	0635 303 053
Selector mechanism	*	0635 303 062
GV 80		
Input shaft front	F 19008	0750 118 131
GV	*	0750 115 089
Input shaft front	NUP 314 FMNR/C3	0750 118 082
Input shaft	*	0735 358 032
Splitter	33889/33822	0750 117 083
Splitter	25590/25521	1246 203 011
S5-35/2 <i>R.5,64-1,00</i>		
Input shaft front	F 19008	0750 118 131
Input shaft rear	NUP 309 FN/C3	0735 410 029
Main shaft front	*	0735 358 014
Main shaft front (Input shaft 1238 302 132)	*	1203 302 110
Main shaft	*	0735 320 211
Main shaft	*	0735 320 210
Main shaft	*	0735 320 411
Main shaft rear	*	0735 410 034
Counter shaft front	30208 F	0750 117 664
Counter shaft rear	30208 F	0750 117 664
Reverse shaft	*	0735 320 114

POSITION	Fersa	OEM
----------	-------	-----

ZF

S5-35/2		<i>R.5,64-0,695 + R.5,64-0,756 + R.6,45-0,799 + R.6,75-1,00 + R.6,79-1,00 + R.8,02-1,00</i>
Input shaft front	F 19008	0750 118 131
Main shaft front	*	0735 358 014
Main shaft	*	0735 320 211
Main shaft	*	0735 320 210
Main shaft	*	0735 320 411
Main shaft rear	*	0735 410 034
Counter shaft front	30208 F	0750 117 664
Counter shaft rear	30208 F	0750 117 664
Reverse shaft	*	0735 320 114

S5-35/2		<i>R.7,65-1,00</i>
Input shaft front	F 19008	0750 118 131
Input shaft front	*	0635 421 210
Main shaft front	*	0735 358 014
Main shaft	*	0735 320 211
Main shaft	*	0735 320 210
Main shaft	*	0735 320 411
Main shaft rear	*	0735 410 034
Counter shaft front	30208 F	0750 117 664
Counter shaft rear	30208 F	0750 117 664
Reverse shaft	*	0735 320 114

S5-35/2		<i>R.6,45-0,744</i>
Input shaft front	F 19008	0750 118 131
Main shaft front	*	0735 358 014
Main shaft	*	0735 320 210
Main shaft	*	0735 320 411
Main shaft rear	*	0735 410 034
Counter shaft front	30208 F	0750 117 664
Counter shaft rear	30208 F	0750 117 664
Reverse shaft	*	0735 320 114

S5-420		
Input shaft front	F 19008	0750 118 131
Main shaft	*	0735 320 873
Main shaft	*	0735 320 871
Main shaft	*	0735 321 010
Counter shaft front	2580/2520	1307 203 019
Counter shaft rear	2580/2520	1307 203 019
Main shaft front	CONE F 15084	0735 371 372
Main shaft rear	F 15278	1307 204 275
Input shaft front	28580/28521	1307 202 116

S5-680		
Input shaft front	F 19008	0750 118 131
Main shaft	*	0735 320 501
Main shaft	*	0635 300 237
Main shaft	F 17085 K	0750 115 059
Main shaft	*	0735 320 837
Counter shaft front	3382/3320	0501 398 246
Counter shaft rear	2789/2720	0501 398 247
Main shaft front	NUP 310 FM/C3	0501 398 245
Main shaft rear (Old Type)	*	0735 358 128
Main shaft rear (New Type)	*	0501 398 233
Input shaft front	F 19042	0501 398 244
	*	0735 298 125

POSITION	Fersa	OEM
----------	-------	-----

ZF

S5-820		<i>series 131 1 095 004/005</i>
Input shaft front	F 19008	0750 118 131
Main shaft front	CONE F 15101	0735 371 591
Main shaft	*	0501 398 230
Main shaft	*	0735 321 106
Main shaft	F 17083 K	0735 320 418
Main shaft	*	0735 321 108
Main shaft	*	0735 321 383
Main shaft rear	476/472	0735 370 730
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	*	0735 320 941

S5-820		<i>serie 131 1 095 014</i>
Input shaft front	F 19008	0750 118 131
Main shaft front	*	0501 398 239
Main shaft	*	0501 398 230
Main shaft	*	0735 321 106
Main shaft	F 17083 K	0735 320 418
Main shaft	*	0735 321 108
Main shaft	*	0735 321 383
Main shaft rear	476/472	0735 370 730
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	*	0735 320 941

S6-80		<i>R.7,41-1,0</i>
Input shaft front	F 19008	0750 118 131
Main shaft front	*	0750 118 090
Main shaft	*	0735 320 314
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear (Bearing with ball)	6314 NR/C3	0635 333 049
Main shaft rear (Bearing with needle)	NUP 314 FMNR/C3	0750 118 082
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	F 17054 K	0750 115 011
Selector mechanism	*	0635 300 086
Selector mechanism	*	0635 303 053

S6-80		<i>R.5,66-0,69 + R.6,10-0,66 + R.6,69-0,82 + R.7,53-0,82</i>
Input shaft front	F 19008	0750 118 131
Main shaft front	*	0750 118 090
Main shaft	*	0735 320 314
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear	6314 NR/C3	0635 333 049
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008

POSITION	Fersa	OEM
----------	-------	-----

ZF
S6-80 *R.5,66-0,69 + R.6,10-0,66 + R.6,69-0,82 + R.7,53-0,82*

Reverse shaft	F 17054 K	0750 115 011
Selector mechanism	*	0635 300 086
Selector mechanism	*	0635 303 053

S6-80 *R.6,70-0,73*

Input shaft front	F 19008	0750 118 131
Input shaft front (short type)	30217 F	0750 117 078
Input shaft case (short type)	32209 F	0635 373 021
Main shaft front	*	0750 118 090
Main shaft	*	0735 320 314
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear	6314 NR/C3	0635 333 049
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	F 17054 K	0750 115 011
Selector mechanism	*	0635 300 086
Selector mechanism	*	0635 303 053

S6-80 *R.6,70-0,78 + R.6,70-0,82*

Input shaft front	F 19008	0750 118 131
Main shaft front	*	0750 118 090
Main shaft	*	0735 320 314
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear	6314 NR/C3	0635 333 049
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	F 17054 K	0750 115 011
Selector mechanism	*	0635 300 086
Selector mechanism	*	0635 303 053

S6-80+GV80 *R.7,65-0,71 + R.7,67-0,78 + R.8,90-0,84 + R.9,00-0,835*

Input shaft front	F 19008	0750 118 131
GV	*	0750 115 089
Input shaft front	NUP 314 FMNR/C3	0750 118 082
Input shaft	*	0735 358 032
Splitter front	25590/25521	1246 203 011
Splitter rear	33889/33822	0750 117 083
Main shaft front	*	0750 118 090
Main shaft	*	0735 320 314
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear	6314 NR/C3	0635 333 049
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	F 17054 K	0750 115 011

POSITION	Fersa	OEM
ZF		
S6-80+GV80 <i>R.6,70-0,57 + R.6,70-0,60 + R.6,70-0,69 + R.7,41-0,84</i>		
Input shaft front	F 19008	0750 118 131
GV	*	0750 115 089
Input shaft front	NUP 314 FMNR/C3	0750 118 082
Input shaft	*	0735 358 032
Splitter front	25590/25521	1246 203 011
Splitter rear	33889/33822	0750 117 083
Main shaft front	*	0750 118 090
Main shaft	*	0735 320 314
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear	6314 NR/C3	0635 333 049
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	F 17054 K	0750 115 011
Selector mechanism	*	0635 300 086
Selector mechanism	*	0635 303 053
S6-85 <i>R.6,75-0,83 + R.7,72-1,00</i>		
Input shaft front	JM 612949/JM 612910	0750 117 347
Main shaft front	CONE F 15101	0750 117 562
Main shaft front (With input shaft 1310 302 007, 1310 302 014, 1310 302 015)	*	0735 370 987
Main shaft	*	0735 321 543
Main shaft	F 17053 K	0735 320 493
Main shaft	*	0735 321 106
Main shaft	*	0735 321 106
Main shaft	*	0735 321 108
Main shaft	*	0735 298 255
Main shaft (With input shaft 1310 302 007, 1310 302 014, 1310 302 015)	*	0735 321 027
Main shaft rear	476/472	0735 370 730
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	*	0750 115 233
S6-90 <i>R.9,08-1,00</i>		
Input shaft front	NUP 314 FMNR/C3	0750 118 082
Main shaft front	*	0750 118 090
Main shaft	*	0735 320 314
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear (Bearing with needle)	NUP 314 FMNR/C3	0750 118 082
Main shaft rear (Bearing with ball)	6314 NR/C3	0635 333 049
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	32309 F	0750 117 778
Reverse shaft	F 17054 K	0750 115 011
Selector mechanism	*	0635 300 086
Selector mechanism	*	0635 303 062
Selector mechanism	*	0635 303 053

POSITION	Fersa	OEM
----------	-------	-----

ZF

S6-90		<i>R.6,37-1,00 + R.7,03-1,00</i>
Input shaft front	30217 F	0750 117 078
Input shaft case	32209 F	0635 373 021
Main shaft front	*	0750 118 090
Main shaft	*	0735 320 314
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear (Bearing with needle)	NUP 314 FMNR/C3	0750 118 082
Main shaft rear (Bearing with ball)	6314 NR/C3	0635 333 049
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	32309 F	0750 117 778
Reverse shaft	F 17054 K	0750 115 011
Selector mechanism	*	0635 300 086
Selector mechanism	*	0635 303 062
Selector mechanism	*	0635 303 053

S6-90		<i>R.5,67-0,70 + R.6,37-0,74 + R.6,37-0,82 + R.6,98-1,00 + R.7,03-0,58 + R.7,03-0,70 + R.7,03-0,81</i>
Input shaft front	NUP 314 FMNR/C3	0750 118 082
Main shaft front	*	0735 455 012
Main shaft front	*	0750 118 090
Main shaft	F 17099 K	0735 320 499
Main shaft	*	0735 320 314
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear (Bearing with ball)	6314 NR/C3	0635 333 049
Main shaft rear (Bearing with needle)	NUP 314 FMNR/C3	0750 118 082
Main shaft rear (Bearing with needle)	*	0635 410 167
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	32309 F	0750 117 778
Reverse shaft	F 17054 K	0750 115 011
Selector mechanism	*	0635 300 086
Selector mechanism	*	0635 303 062
Selector mechanism	*	0635 303 053

S6-90		<i>R.6,37-1,00 + R.7,03-1,00 + R.9,01-1,00</i>
Input shaft front	NUP 314 FMNR/C3	0750 118 082
Input shaft front (short type)	30217 F	0750 117 078
Input shaft case (short type)	32209 F	0635 373 021
Main shaft front	*	0735 455 012
Main shaft front	*	0750 118 090
Main shaft	F 17099 K	0735 320 499
Main shaft	*	0735 320 314
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear (Bearing with ball)	6314 NR/C3	0635 333 049
Main shaft rear (Bearing with needle)	NUP 314 FMNR/C3	0750 118 082

POSITION	Fersa	OEM
ZF		
S6-90 <i>R.6,37-1,00 + R.7,03-1,00 + R.9,01-1,00</i>		
Main shaft rear (Bearing with needle)	*	0635 410 167
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	32309 F	0750 117 778
Reverse shaft	F 17054 K	0750 115 011
Selector mechanism	*	0635 300 086
Selector mechanism	*	0635 303 062
Selector mechanism	*	0635 303 053
S6-90+GV90 <i>R.6,98-0,82</i>		
GV front	NUP 314 FMNR/C3	0750 118 081
GV	*	0750 115 089
Input shaft front	NUP 314 FMNR/C3	0750 118 082
Input shaft	*	0735 358 032
Splitter front	*	1269 298 951
Splitter rear	F 15047	0750 117 010
Main shaft front	*	0735 455 012
Main shaft	F 17099 K	0735 320 499
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear (Bearing with needle)	NUP 314 FMNR/C3	0750 118 082
Main shaft rear (Bearing with ball)	6314 NR/C3	0635 333 049
Main shaft rear (Bearing with needle)	*	0635 410 167
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	32309 F	0750 117 778
Reverse shaft	F 17054 K	0750 115 011
Selector mechanism	*	0635 300 086
Selector mechanism	*	0635 303 062
Selector mechanism	*	0635 303 053
S6-90+GV90 <i>R.7,03-0,58 + R.7,03-0,70 + R.9,01-0,82</i>		
GV front	NUP 314 FMNR/C3	0750 118 081
GV	*	0750 115 089
Input shaft front	NUP 314 FMNR/C3	0750 118 082
Input shaft	*	0735 358 032
Splitter front	*	1269 298 951
Splitter rear	F 15047	0750 117 010
Main shaft front	*	0750 118 090
Main shaft	*	0735 320 314
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear (Bearing with needle)	NUP 314 FMNR/C3	0750 118 082
Main shaft rear (Bearing with ball)	6314 NR/C3	0635 333 049
Main shaft rear (Bearing with needle)	*	0635 410 167
Counter shaft front	F 15047	0750 117 010
Counter shaft rear	32309 F	0750 117 778
Reverse shaft	F 17054 K	0750 115 011
Selector mechanism	*	0635 300 086
Selector mechanism	*	0635 303 062
Selector mechanism	*	0635 303 053

POSITION	Fersa	OEM
----------	-------	-----

ZF
S6-680

Reverse shaft	*	0635 300 110
Main shaft	*	0735 320 501
Main shaft	*	0635 300 237
Main shaft	*	0735 320 837
Main shaft	F 17099 K	0735 320 499
Main shaft	*	0735 321 028
Case housing	*	0635 303 053
Counter shaft front	3382/3320	0501 398 246
Counter shaft rear	2789/2720	0501 398 247
Main shaft front	NUP 310 FM/C3	0501 398 245
Main shaft rear (Old Type)	*	0735 358 128
Main shaft rear (New Type)	*	0501 398 233
Input shaft front	F 19042	0501 398 244
	*	0735 298 125

S680+GV

Main shaft front	*	0750 118 090
Main shaft	*	0735 320 314
Main shaft	*	0750 115 284
Main shaft	*	0750 115 134
Main shaft	*	0750 115 282
Main shaft	*	0750 115 283
Main shaft	*	0735 320 154
Main shaft rear	NUP 314 FMNR/C3	0750 118 082
Counter shaft front	33889/33822	0750 117 083
Counter shaft rear	33885/33822	1246 203 008
Reverse shaft	F 17054 K	0750 115 011

S6-1550

Reverse shaft	*	0501 398 211
Main shaft	*	0735 320 471
Main shaft	*	0501 398 351
Main shaft	*	0735 320 407
Main shaft	F 17099 K	0735 320 499
Main shaft	*	0735 320 837
Case housing	*	0635 303 053
Counter shaft front	F 15047	0750 117 883
Counter shaft rear	32309 F	0635 374 019
Input shaft front	NUP 314 FMNR/C3	0750 118 082
Main shaft rear	*	0735 455 012
Main shaft front	*	0735 320 154



.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....



.....

.....

.....

3 \

OEM Cross References



3 \ OEM Cross References

OEM	Fersa
EATON	
OEM CROSS REFERENCES	FERSA
001 981 8080/012 981 0705	39590/39520
001 981 8180/013 981 0105	45285 A/45220
001 981 8280/012 981 0805	25590/25522
001 981 8380	3782/3720
003 981 0618	*
003 981 0818	*
003 981 0918	*
009 981 4525	*
012 981 0605	31594/31520
016 981 8305/002 981 3180	M 802048/11
016 981 8505/002 981 3380	25581/25520
016 981 8605	2689/2631
016 981 8705/002 981 3480	25877/25821
017 981 3510	F 17043 K
017 981 3610	F 17044 K
017 981 3710	F 17045 K
017 981 3810	F 17046 K
017 981 3910	*

MERCEDES BENZ	
000 980 0101	344/332
000 980 0201	3382/3320
000 980 1902	LM 806649/LM 806610
000 980 3402	33885/33822
000 980 4202	LM 300849/LM 300811
000 980 4610	*
000 980 7202	47490/47420
000 980 7402	47490/47420
000 980 7502	33111 F
000 980 7902	JM 714249/JM 714210
000 980 8202	LM 503349 A/LM 503310
000 980 9002	32011 XF
000 980 9602	33019 F
000 980 9702	33021 F
000 981 0005	31311 F
000 981 0027	*
000 981 0205	30216 F
000 981 0505	30312 F
000 981 0525	6309 2RS
000 981 1001	2789/2720
000 981 1201	*
000 981 2105	32219 F
000 981 2205	32217 F
000 981 2612	*
000 981 2920	6218 C3
000 981 2927	QJ 309 FM
000 981 3120	F 18052
000 981 3605	32210 F
000 981 4005	HM 911244/HM 911216
000 981 4118	32313 BF
000 981 4218	33115 F
000 981 4301	*
000 981 4312	*
000 981 4605	*
000 981 5605	580/572

OEM	Fersa
000 981 6005	HM 803146/HM 803110
000 981 6105	497/492 A
000 981 6712	*
000 981 7205	32216 F
000 981 7212	*
000 981 7405	32215 F
000 981 7605	HM 911244/HM 911216
000 981 7905	580/572
000 981 8302	33111 F
000 981 8405	32215 F
000 981 8520	6309 2RS
000 981 8605	*
000 981 8905	30312 F
000 981 9020	6309 2RS
000 981 9025	6314 NR/C3
000 981 9405	32216 F
000 981 9505	32306 F
000 981 9701	F 19015
000000 000759	6216 C4
000625 006203	6203
000625 036009	6009 C3
000625 036014	6014 2RS/C3
000625 036211	6211 2RS/C3
000625 036212	6212 C3
000625 036216	6216 C3
000625 036313	6313 C3
000625 920066	6313 C4
000625 920067	*
0006250 36312	6312 C3
000720 030309	30309 F
000720 030313	30313 F
000720 032014	32014 XF
000720 032016	32016 XF
000720 032019	32019 XF
000720 032206	32206 F
000720 032306	32306 F
000720 032310	32310 F
000720 033214	33214 F
001 980 0502	31313 F
001 980 0902	33213 F
001 980 1402	F 15047
001 980 2602	32019 XF
001 980 2702	33215 F
001 980 6202	LM 501349/LM 501310
001 980 6302	LM 501349/LM 501310
001 980 6602	33020 F
001 980 6702	33117 F
001 980 6802	*
001 980 6902	HM 803146/HM 803110
001 980 7802	F 15047
001 980 7902	F 19009
001 980 8002	4580/4535
001 980 8102	F 15047
001 980 8202	32310 F
001 980 8302	F 19010
001 980 8402	5395/5335
001 980 8902	*

OEM	Fersa
001 980 9002	F 19009
001 980 9502	33889/33822
001 980 9602	33885/33822
001 980 9802	NUP 314 FMNR/C3
001 981 0001	F 19015
001 981 0005	HM 803146/HM 803110
001 981 0301	*
001 981 0405	3984/3920
001 981 0712	*
001 981 1405	497/492 A
001 981 1427	*
001 981 1701	NU 209 FMN
001 981 2418	NUP 309 FN/C3
001 981 2502	F 15272
001 981 2512	*
001 981 2905	32310 F
001 981 3105	30308 F
001 981 3412	*
001 981 3512	*
001 981 3705	30309 F
001 981 3905	3984/3920
001 981 4012	*
001 981 4112	*
001 981 4210	F 17054 K
001 981 4412	*
001 981 4505	580/572
001 981 4605	30309 F
001 981 4612	*
001 981 4805	32215 F
001 981 4812	*
001 981 4905	*
001 981 5105	30309 F
001 981 5512	F 17101 K
001 981 6005	28985/28920
001 981 6101	*
001 981 6105	32206 F
001 981 6405	32020 XF
001 981 7105	*
001 981 7205	32020 XF
001 981 7405	32310 F
001 981 7505	30314 F
001 981 7605	32310 F
001 981 7705	30314 F
001 981 8005	32214 F
001 981 8080/012 981 0705	39590/39520
001 981 8180/013 981 0105	45285 A/45220
001 981 8205	*
001 981 8280/012 981 0805	25590/25522
001 981 8305	32306 F
001 981 8312	*
001 981 8380	3782/3720
001 981 8405	32211 F
001 981 8505	30216 F
001 981 8705	32306 F
001 981 8905	32210 F
001 981 8912	*
001 981 9005	32304 F

OEM	Fersa
001 981 9312	*
001 981 9405	*
001 981 9412	*
001 981 9502	33889/33822
001 981 9512	*
001 981 9605	497/492 A
001 981 9612	*
001 981 9805	HM 911244/HM 911216
001 981 9905	F 15082
001 981 9912	F 19075
001 9810505	33895/33822
002 980 1002	F 19009
002 980 1602	F 19062
002 980 7202	F 15125
002 980 7402	F 19039
002 980 7502	F 19010
002 981 0005	580/572
002 981 0205	30312 F
002 981 0505	33895/33820
002 981 0605	3984/3920
002 981 1105	HM 911244/HM 911216
002 981 1305	32011 XF
002 981 1312	*
002 981 1412	*
002 981 1580	32011 XF
002 981 1605	47487/47420
002 981 1705	32217 F
002 981 1805	32217 F
002 981 1905	32210 F
002 981 2205	32210 F
002 981 2605	47487/47420
002 981 3681	CONE F 15101
002 981 3725	*
002 981 4505	31313 F
002 981 4581	CONE F 15134
002 981 4581/001 981 9680	*
002 981 4605	32024 XF
002 981 4681	CONE F 15132
002 981 4681/001 981 9780	*
002 981 5005	32022 XF
002 981 5405	32019 XF
002 981 5505	32214 F
002 981 5605	32214 F
002 981 5712	*
002 981 5912	F 19090
002 981 6012	F 19090
002 981 6112	F 17076 K
002 981 6312	F 19090
002 981 6605	32011 XF
002 981 6812	F 17053 K
002 981 7201	F 19022
002 981 7512	*
002 981 7781	*
002 981 7905	33210 F
002 981 8005	F 15258
002 981 8125	6211 C3
002 981 8205	33111 F

3 \ OEM Cross References

OEM	Fersa
MERCEDES BENZ	
002 981 8605	33215 F
002 981 8705	F 15280
002 981 8805	F 15280
002 981 8905	33215 F
002 981 8925	62305 2RS/C3
002 981 9005	33019 F
002 981 9118	NUP 213 FPNR/C3
002 981 9202	47490/47420
002 981 9305	33011 F
002 981 9405	*
002 981 9501	F 19043
002 981 9505	33015 F
002 981 9705	33114 F
003 981 0005	33015 F
003 981 0605	31313 F
003 981 0905	33114 F
003 981 1005	33205 F
003 981 1105	33109 F
003 981 1205	F 15083
003 981 1405	598/593 X
003 981 1505	33205 F
003 981 1605	33109 F
003 981 1701	F 19015
003 981 1905	F 15083
003 981 2418	*
003 981 2505	32021 XF
003 981 2605	33021 F
003 981 2705	32021 XF
003 981 2801	*
003 981 2805	33021 F
003 981 2901	*
003 981 2905	32314 BF
003 981 3005	33115 F
003 981 3105	32314 BF
003 981 3205	33115 F
003 981 3705	33213 F
003 981 3905	33208 F
003 981 4105	33113 F
003 981 4305	33011 F
003 981 4505	33220 F
003 981 4705	JM 714249/JM 714210
003 981 4805	JM 714249/JM 714210
003 981 4825	*
003 981 4905	F 15258
003 981 4925	6214 2RS/C3
003 981 5105	32019 XF
003 981 5205	33214 F
003 981 5305	33209 F
003 981 5605	33214 F
003 981 5705	33209 F
003 981 6605	33114 F
003 981 6805	F 15076
003 981 6905	32313 BF
003 981 7005	32313 BF
003 981 7205	33208 F
003 981 7405	33213 F

OEM	Fersa
003 981 7805	32311 F
003 981 8005	32311 F
003 981 8305	33210 F
003 981 8605	33019 F
003 981 8805	HM 807048/HM 807010
003 981 8905	HM 807048/HM 807010
003 981 9001	F 19013
003 981 9005	HM 807048/HM 807010
003 981 9125	*
003 981 9505	33205 F
003 981 9605	33109 F
004 981 0605	F 15076
004 981 0705	33022 F
004 981 0905	33022 F
004 981 1005	33220 F
004 981 1305	32309 F
004 981 1705	32018 XF
004 981 1810	F 17053 K
004 981 1905	F 15272
004 981 1910	F 17052 K
004 981 2005	F 15272
004 981 2105	30220 F
004 981 2125	62305 2RS/C3
004 981 2905	*
004 981 3601	*
004 981 3905	F 15051 R
004 981 4205	33210 F
004 981 4305	32018 XF
004 981 4605	580/572
004 981 4705	580/572
004 981 4805	580/572
004 981 4905	30220 F
004 981 5525	*
004 981 5801	F 19019
004 981 6405	33211 F
004 981 6505	33211 F
004 981 6705	33211 F
004 981 6805	33208 F
004 981 7205	33209 F
004 981 7305	33214 F
004 981 7405	32020 XF
004 981 7801	F 19016
004 981 7901	F 19038
004 981 8001	F 19037
004 981 8225	6213 ZMNR/C3
004 981 8525	6217 C3
004 981 8625	6009 C3
004 981 8725	16017/90 C3
004 981 8825	16017/90 C3
004 981 8925	6217 C3
004 981 9025	6009 C3
004 981 9225	6009 C3
004 981 9325	6217 C3
004 981 9425	16017/90 C3
004 981 9805	32314 F
004 981 9905	32314 F
005 981 0005	32314 F

OEM	Fersa
005 981 0505	32313 BF
005 981 0705	33207 F
005 981 1405	32017 XF
005 981 1505	32017 XF
005 981 1605	32017 XF
005 981 2105	33022 F
005 981 2405	HM 803146/HM 803110
005 981 2505	HM 803146/HM 803110
005 981 3005	F 15051 C
005 981 3105	F 15051 C
005 981 3110	*
005 981 3605	32313 BF
005 981 4005	33210 F
005 981 4105	33209 F
005 981 4405	33011 F
005 981 4605	HM 807048/HM 807010
005 981 4805	32313 BF
005 981 4905	33021 F
005 981 5201	NUP 311 FMNR/C3
005 981 5305	32210 F
005 981 5605	32018 XF
005 981 5925	6212 C3
005 981 6605	32014 XF
005 981 6805	32014 XF
005 981 6905	*
005 981 7910	*
005 981 8305	33117 F
005 981 84 05	33020 F
005 981 8405	33020 F
005 981 8501	NUP 314 FMNR/C3
005 981 8505	33020 F
005 981 8605	33117 F
005 981 8701	NUP 314 FMNR/C3
005 981 8710	F 17051 K
005 981 8805	F 15051 C
005 981 8901	F 19037
005 981 9005	32022 XF
005 981 9505	32014 XF
005 981 9725	16014
005 981 9905	33117 F
005 981 9910	F 17064 K
006 981 0005	32018 XF
006 981 0105	33020 F
006 981 0405	32020 XF
006 981 0605	32216 F
006 981 08 05	32311 F
006 981 0805	32311 F
006 981 1705	F 15183
006 981 1805	*
006 981 1901	F 19015
006 981 3505	F 15159
006 981 4205	30309 F
006 981 4705	32019 XF
006 981 5205	33214 F
006 981 5605	32011 XF
006 981 5705	33109 F
006 981 5805	33205 F

OEM	Fersa
006 981 5905	32306 F
006 981 6005	33211 F
006 981 6205	33208 F
006 981 6305	33213 F
006 981 6425	*
006 981 6505	30312 F
006 981 6805	32014 XF
006 981 69 05	32311 F
006 981 6905	32311 F
006 981 7025	*
006 981 74 05	32311 F
006 981 7405	32311 F
006 981 7605	*
006 981 8205	33111 F
006 981 8225	6009 C3
006 981 8705	33017 F
006 981 9002	32011 XF
006 981 9705	33017 F
006 981 9905	32310 F
007 981 0005	30220 F
007 981 0201	NJ 1014 FM
007 981 0301	F 19022
007 981 0305	F 15076
007 981 0405	32011 XF
007 981 0725	6309 2RS
007 981 1125	6309 2RS
007 981 1325	F 18042
007 981 1425	6309 2RS
007 981 1625	6309 2RS
007 981 1801	F 19008
007 981 2001	*
007 981 2105	32012 XF
007 981 2110	*
007 981 2501	F 19047
007 981 2505	33015 F
007 981 2801	F 19008
007 981 2810	*
007 981 2925	6309 2RS
007 981 3325	6217/80 C3
007 981 3725	6217/80 C3
007 981 4005	*
007 981 4025	6217/80 C3
007 981 4210	F 17031 K
007 981 4701	F 19046
007 981 4805	F 15273
007 981 4905	33017 F
007 981 5305	M 88043/M 88010
007 981 5505	32210 F
007 981 5510	*
007 981 5705	33011 F
007 981 6305	F 15273
007 981 6405	F 15273
007 981 6905	*
007 981 70 05	33217 F
007 981 7005	33217 F
007 981 7125	6217/80 C3
007 981 7425	6217/80 C3

3 \ OEM Cross References

OEM	Fersa
MERCEDES BENZ	
007 981 7801	F 19013
007 981 7901	F 19013
007 981 8201	*
007 981 8905	F 15158
007 981 9005	32016 XF
007 981 9305	32016 XF
007 981 9405	32016 XF
008 981 0005	33213 F
008 981 0105	33208 F
008 981 0910	F 17053 K
008 981 1010	F 17052 K
008 981 1325	16017/90 C3
008 981 1425	6217/80 C3
008 981 1505	*
008 981 1525	16017/90 C3
008 981 1605	*
008 981 1910	F 17054 K
008 981 2205	529/520 X1
008 981 2605	F 15190
008 981 2705	F 15192
008 981 2710	F 17051 K
008 981 2805	HM 204043/HM 204010
008 981 2905	529/520 X1
008 981 3005	F 15192
008 981 3025	6217/80 C3
008 981 3205	F 15190
008 981 3225	6009 C3
008 981 3305	529/520 X1
008 981 3405	33220 F
008 981 3505	33022 F
008 981 3605	33111 F
008 981 4005	HM 204043/HM 204010
008 981 4105	F 15192
008 981 4605	F 15190
008 981 5105	33015 F
008 981 5201	*
008 981 5225	6217/80 C3
008 981 5301	*
008 981 5305	JM 714249/JM 714210
008 981 5325	16017/90 C3
008 981 5425	6003
008 981 5705	LM 503349 A/LM 503310
008 981 5805	LM 300849/LM 300811
008 981 6901	F 19038
008 981 7505	33208 F
008 981 8005	*
008 981 8305	*
008 981 8310	F 17031 K
008 981 8605	F 15190
008 981 8610	*
008 981 8705	F 15192
008 981 8810	F 17064 K
008 981 9310	F 17032 K
008 981 9405	F 15258
008 981 9501	*

OEM	Fersa
008 981 9525	*
008 981 9710	*
008 981 9910	*
009 981 0110	*
009 981 0201	CONE 4395
009 981 0210	*
009 981 0305	30309 F
009 981 0310	F 17064 K
009 981 0325	*
009 981 0510	*
009 981 0605	30216 F
009 981 0705	*
009 981 0805	F 15193
009 981 1005	30216 F
009 981 1410	*
009 981 1510	F 17032 K
009 981 1610	*
009 981 1701	F 19016
009 981 1710	*
009 981 1810	*
009 981 2001	476/472
009 981 2301	45285 A/45221
009 981 2401	2580/2520
009 981 2601	2580/2520
009 981 3105	*
009 981 3301	33889/33822
009 981 3325	F 18060
009 981 3401	JF 4049/JF 4010
009 981 3625	*
009 981 4105	32010 XF
009 981 4305	F 15208
009 981 4501	28580/28521
009 981 4505	32011 XF
009 981 4510	*
009 981 4705	30216 F
009 981 4805	32011 XF
009 981 5125	6218 C3
009 981 5225	6309 2RS
009 981 5525	F 18042
009 981 5725	6309 2RS
009 981 5825	F 18042
009 981 6105	32011 XF
009 981 6205	30216 F
009 981 6381	CONE F 15084
009 981 6405	F 15193
009 981 7005	32011 XF
009 981 7905	32028 XF
009 981 8305	30313 F
009 981 8905	30313 F
009 981 9005	30313 F
009 981 9010	F 17099 K
009 981 92 10	F 17100 K
009 981 9305	33011 F
009 981 9310	F 17101 K
009 981 9401	32021 XF
009 981 9805	30313 F
010 981 1010	F 17054 K

OEM	Fersa
010 981 1210	F 17064 K
010 981 1501	30217 F
010 981 1510	*
010 981 1710	*
010 981 2405	*
010 981 35 10	F 17083 K
010 981 3610	F 17082 K
010 981 3801	JM 822049/JM 822010
010 981 4410	*
010 981 4801	F 19042
010 981 4901	F 19069
010 981 4910	*
010 981 5110	*
010 981 5205	*
010 981 5210	*
010 981 5310	F 17035 K
010 981 5905	30309 F
010 981 6410	F 17035 K
010 981 9305	32311 F
010 981 9710	*
011 981 0105	32313 BF
011 981 0605	32214 F
011 981 08 05	33217 F
011 981 0805	33217 F
011 981 1305	F 15190
011 981 1405	F 15190
011 981 1505	F 15190
011 981 1605	F 15190
011 981 1905	CONE F 15111
011 981 2305	F 15208
011 981 3305	*
011 981 3405	*
011 981 3605	F 15208
011 981 5205	CONE 4367 X
011 981 6005	*
011 981 6805	32312 F
011 981 6905	32312 F
011 981 7605	33210 F
011 981 7610	*
011 981 7705	32011 XF
011 981 8105	CONE F 15244
011 981 9705	CONE 4367 X
011 981 9905	CONE 4367 X
012 981 0405	F 15192
012 981 0605	31594/31520
012 981 2805	CONE F 15110
012 981 3205	32314 F
012 981 3605	F 15161
012 981 3705	F 15265
012 981 3905	F 15192
012 981 40 05	33116 F
012 981 4005	33116 F
012 981 41 05	33116 F
012 981 4105	33116 F
012 981 4710	*
012 981 4810	*
012 981 5010	*

OEM	Fersa
012 981 5110	*
012 981 5310	*
012 981 5410	*
012 981 6210	*
012 981 6810	*
012 981 7205	529/520 X1
012 981 8005	32028 XF
012 981 8105	CONE 4367 X
012 981 8205	CONE 4367 X
012 981 8805	F 15245
012 981 8905	F 15192
012 981 8910	F 17033 K
012 981 9010	F 17033 K
012 981 9110	F 17032 K
012 981 9205	F 15245
012 981 9210	F 17031 K
012 981 9305	F 15192
012 981 9310	F 17035 K
012 981 9405	F 15245
012 981 9605	*
013 981 0005	CONE F 15111
013 981 0210	F 17033 K
013 981 0305	CONE F 15131
013 981 0405	CONE LM 503349
013 981 0505	CONE 4367 X
013 981 0605	529/520 X1
013 981 0805	CONE F 15244
013 981 0905	CONE F 15113
013 981 1105	CONE 4367 X
013 981 1210	*
013 981 1405	F 15271
013 981 1505	CONE F 15249
013 981 1710	*
013 981 2205	F 15125
013 981 2210	*
013 981 2305	F 15125
013 981 2405	F 15270
013 981 2510	*
013 981 2705	CONE F 15249
013 981 3205	CONE F 15249
013 981 3905	F 15271
013 981 4205	F 15193
013 981 4305	F 15193
013 981 5105	F 15270
013 981 5310	*
013 981 5405	F 15270
013 981 6205	31313 F
013 981 6410	*
013 981 6510	*
013 981 6905	CONE F 15244
013 981 8405	F 15245
013 981 9805	F 15125
014 981 0205	CONE F 15244
014 981 0605	33207 F
014 981 0610	F 17090 K
014 981 0705	CONE F 15244
014 981 0710	*

3 \ OEM Cross References

OEM	Fersa
MERCEDES BENZ	
014 981 1405	529/520 X1
014 981 1505	CONE F 15244
014 981 1605	32011 XF
014 981 1605/002 981 1580	32011 XF
014 981 1905	CONE F 15249
014 981 2005	F 15253
014 981 2105	F 15253
014 981 2205	F 15257
014 981 2605	CONE F 15113
014 981 3005	CONE F 15244
014 981 32 05	33020 F
014 981 3205	33020 F
014 981 3410	F 17064 K
014 981 3905	F 15133
014 981 3910	*
014 981 4005	F 15190
014 981 4310	*
014 981 4405	32024 XF
014 981 4905	F 15254
014 981 5005	F 15254
014 981 51 05	F 15100
014 981 5105	F 15100
014 981 5405	32024 XF
014 981 6105	F 15192
014 981 6605	32014 XF
014 981 7505	F 15192
014 981 7605	F 15270
014 981 7805	F 15255
014 981 7905	F 15256
014 981 8905	F 15190
014 981 9005	F 15190
014 981 93 05	F 15100
014 981 9305	F 15100
014 981 99 05	F 15100
014 981 9905	F 15100
015 981 0005	32017 XF
015 981 0805	32017 XF
015 981 1605	CONE 4367 X
015 981 1705	CONE F 15292
015 981 1905	F 15120
015 981 2005	CONE F 15244
015 981 4005	F 15265
015 981 4105	F 15161
015 981 4110	*
015 981 4705	F 15267
015 981 4805	F 15267
015 981 6105	CONE F 15113
015 981 6205	CONE F 15111
015 981 7505	32312 F
015 981 7605	F 15244
015 981 7605/002 981 1680	*
015 981 7705	32011 XF
015 981 8405	F 15190
015 981 8505	CONE F 15249
015 981 9005	529/520 X1

OEM	Fersa
015 981 9505	CONE F 15113
015 981 9705	32212 F
015 981 9810	F 17034 K
016 981 0010	F 17034 K
016 981 0105	*
016 981 0210	*
016 981 0405	CONE 3382
016 981 0505	CONE 3382
016 981 0605	CONE 3382
016 981 0705	CONE 3382
016 981 1205	F 15245
016 981 1305	F 15192
016 981 1405	30215 F
016 981 1505	CONE 3382
016 981 2805	F 15100
016 981 4405	F 15332
016 981 7105	*
016 981 7205	*
016 981 7305	*
016 981 7881	*
016 981 8305/002 981 3180	M 802048/M 802011
016 981 8505/002 981 3380	25581/25520
016 981 8605	2689/2631
016 981 8705/002 981 3480	25877/25821
016 981 9610	F 17035 K
017 981 0210	F 17031 K
017 981 1305	CONE F 15249
017 981 1510	F 17035 K
017 981 2205	CONE F 15111
017 981 2305	CONE F 15113
017 981 2605	F 15245
017 981 3205	*
017 981 3510	F 17043 K
017 981 3610	F 17044 K
017 981 3710	F 17045 K
017 981 3805	*
017 981 3810	F 17046 K
017 981 4905	33116 F
017 981 5005	F 15100
017 981 5010	F 17076 K
017 981 5105	CONE F 15113
017 981 5110	F 17076 K
017 981 5510	F 17077 K
017 981 5610	F 17077 K
017 981 5705	32011 XF
017 981 5710	F 17077 K
017 981 6010	F 17078 K
017 981 6110	F 17078 K
017 981 6210	F 17076 K
017 981 7105	CONE F 15269
017 981 7810	F 17032 K
017 981 7905	32020 XF
017 981 8005	32014 XF
017 981 8205	32017 XF
017 981 8305	CONE F 15333
018 981 0110	F 17079 K
018 981 0510	*

OEM	Fersa
018 981 1710	F 17056 K
018 981 3010	F 17079 K
018 981 3610	F 17079 K
018 981 5310	F 17076 K
018 981 5610	*
018 981 5710	F 17078 K
018 981 5810	F 17080 K
018 981 6410	F 17096 K
018 981 6510	F 17096 K
018 981 6610	F 17035 K
018 981 6705	F 15265
018 981 6805	F 15298
018 981 7105	33022 F
018 981 7610	F 17097 K
018 981 7710	*
018 981 8110	F 17097 K
018 981 8210	F 17096 K
018 981 8610	F 17034 K
018 981 8710	F 17034 K
018 981 9205	31313 F
018 981 9310	F 17035 K
018 981 9510	F 17077 K
018 981 9610	F 17080 K
018 981 9710	*
019 981 0910	F 17031 K
019 981 1310	F 17033 K
019 981 1510	*
019 981 4410	F 17031 K
019 981 4610	*
019 981 4910	F 17035 K
019 981 5110	F 17034 K
019 981 5210	F 17035 K
019 981 5310	F 17089 K
019 981 5710	F 17089 K
019 981 6010	*
019 981 6105	F 15334
019 981 9210	*
021 981 1610	F 17035 K
021 981 1710	*
021 981 3910	*
021 981 4210	*
021 981 5610	*
021 981 5710	*
021 981 6310	*
021 981 6510	*
021 981 9210	NUP 310 FM/C3
021 981 9410	*
022 981 2010	*
022 981 2110	*
022 981 2310	*
022 981 4010	*
022 981 4110	*
022 981 4210	*
022 981 4510	*
022 981 5310	*
022 981 5610	*
022 981 5810	*

OEM	Fersa
022 981 5910	*
022 981 7610	*
022 981 8410	*
022 981 8510	*
023 981 2910	F 17089 K
220 981 1710	*
312 981 0001	32214 F
312 981 0501	32306 F
312 981 0601	*
319 981 0005	32207 F
319 981 0405	32210 F
320 250 0015	F 15357
324 981 0001	*
327 981 0112	*
327 981 0305	32215 F
327 981 0405	32217 F
327 981 2205	32217 F
344 981 7001	F 19044
344 981 7101	NU 209 FN
344 981 7205	33114 F
345 981 0012	*
345 981 7012	*
345 981 7027	QJ 209 FM
345 981 7127	QJ 309 FM
345 981 7212	*
345 981 7301	F 19012
345 981 7312	*
345 981 7501	F 19015
345 981 7627	QJ 212 FM
345 981 8101	F 19011
345 981 8201	F 19044
386 981 7505	HM 911244/HM 911216
631 981 0605	30306 F
906 981 0325	6205 2RS
942 981 0205	XUA 32215 F
942 981 0405	31313 F
942 981 0505	32313 BF
944 350 0049	30215 F
944 350 0149	32311 F
944 981 0025	*
976 981 0012	F 19090

ZF	
0501 203 518	*
0501 398 211	*
0501 398 230	*
0501 398 233	*
0501 398 239	*
0501 398 244	F 19042
0501 398 245	NUP 310 FM/C3
0501 398 246	3382/3320
0501 398 247	2789/2720
0501 398 351	F 17084 K
0501 398 714	F 19010
0635 300 086	*
0635 300 110	*
0635 300 237	*

3 \ OEM Cross References

OEM	Fersa
ZF	
0635 303 053	*
0635 303 062	*
0635 330 050	*
0635 332 132	*
0635 333 049	6314 NR/C3
0635 338 035	*
0635 338 090	*
0635 373 008	32212 F
0635 373 021	32209 F
0635 374 019	32309 F
0635 410 167	*
0635 416 243	*
0635 416 244	NJ 1024 FM
0635 416 273	*
0635 416 275	*
0635 421 210	*
0635 490 006	*
0735 298 125	*
0735 298 255	*
0735 320 114	*
0735 320 154	*
0735 320 210	*
0735 320 211	*
0735 320 314	*
0735 320 371	F 17051 K
0735 320 377	*
0735 320 378	F 17031 K
0735 320 379	*
0735 320 396	F 17052 K
0735 320 407	*
0735 320 411	*
0735 320 417	F 17102 K
0735 320 418	F 17083 K
0735 320 451	F 17098 K
0735 320 452	F 17087 K
0735 320 460	*
0735 320 461	*
0735 320 465	F 17101 K
0735 320 466	*
0735 320 471	*
0735 320 486	F 17088 K
0735 320 487	F 17086 K
0735 320 493	F 17053 K
0735 320 496	F 17082 K
0735 320 499	F 17099 K
0735 320 501	*
0735 320 548	*
0735 320 549	*
0735 320 568	*
0735 320 731	*
0735 320 732	*
0735 320 786	F 17084 K
0735 320 799	*
0735 320 837	*
0735 320 871	*
0735 320 873	*
0735 320 896	F 17081 K
0735 320 941	*

OEM	Fersa
0735 320 950	*
0735 321 010	*
0735 321 012	F 17058 K
0735 321 027	*
0735 321 028	*
0735 321 103	*
0735 321 106	*
0735 321 108	*
0735 321 383	*
0735 321 494	F 17059 K
0735 321 527	*
0735 321 528	*
0735 321 529	*
0735 321 530	*
0735 321 531	*
0735 321 543	*
0735 330 025	*
0735 330 136	6213 ZMNR/C3
0735 330 597	6213 2RS/C3
0735 330 800	F 18054
0735 340 080	*
0735 358 014	*
0735 358 032	*
0735 358 128	*
0735 358 155	*
0735 358 192	*
0735 370 033	*
0735 370 438	2789/2729
0735 370 728	JM 612949/10
0735 370 730	476/472
0735 370 742	3386/3325
0735 370 987	*
0735 371 372	CEM F 15084
0735 371 591	CEM F 15101
0735 371 607	344/332
0735 410 029	NUP 309 FN/C3
0735 410 034	*
0735 410 057	F 19009
0735 455 012	*
0735 455 114	F 19016
0750 115 011	F 17054 K
0750 115 059	F 17085 K
0750 115 089	*
0750 115 134	*
0750 115 227	F 17064 K
0750 115 233	*
0750 115 255	*
0750 115 282	*
0750 115 283	*
0750 115 284	*
0750 115 303	*
0750 115 304	*
0750 115 326	*
0750 115 327	*
0750 115 427	F 17057 K
0750 115 533	F 17056 K
0750 115 955	*
0750 115 956	*
0750 115 957	*
0750 115 958	*



OEM	Fersa
0750 116 002	6218 C3
0750 116 036	*
0750 116 133	*
0750 116 165	F 18052
0750 116 166	*
0750 116 373	6309 2RS
0750 116 394	6218 C3
0750 116 422	F 18052
0750 117 008	32310 F
0750 117 009	5395/5335
0750 117 010	F 15047
0750 117 011	4580/4535
0750 117 078	30217 F
0750 117 083	33889/33822
0750 117 198	2789/2729
0750 117 203	*
0750 117 232	CEM 4395
0750 117 233	*
0750 117 312	45285 A/45221
0750 117 347	JM 612949/10
0750 117 381	*
0750 117 431	*
0750 117 562	CEM F 15101
0750 117 651	32210 F
0750 117 664	30208 F
0750 117 678	F 15191
0750 117 778	32309 F
0750 117 883	F 15047
0750 118 005	F 19016
0750 118 006	F 19010
0750 118 007	*
0750 118 010	F 19075
0750 118 012	*
0750 118 015	NUP 311 FMNR/C3
0750 118 017	*
0750 118 019	F 19019
0750 118 038	F 19037
0750 118 081	NUP 314 FMNR/C3
0750 118 082	NUP 314 FMNR/C3
0750 118 090	*
0750 118 129	F 19022
0750 118 130	F 19008
0750 118 131	F 19008
0750 118 137	*
0750 118 153	F 19009
0750 118 180	F 19039
0750 118 220	F 19038
0750 118 258	F 19062
0750 118 471	F 19039
1203 302 110	*
1246 203 008	33885/22
1246 203 011	25590/25521
1269 298 951	*
1269 298 966	*
1307 202 116	28580/28521
1307 203 019	2580/2520
1307 204 275	F 15278

EXPERTS IN BEARING SOLUTIONS

INNOVATIVE SPIRIT

2016

EUROPE Spain \ Zaragoza

Headquarters
Tlf: +34 976 333 850
fersa@fersa.com

Regional branch
Tlf: +34 876 269 571
fersaiberia@fersa.com

NORTH AMERICA U.S.A \ Ohio

Tlf: +1 419-279-5331
fersa.usa@fersa.com

ASIA China \ Jiaxing

Tlf: +86 (0) 573 8271 6335
fersa.cn@fersa.com

SOUTH AMERICA Brazil

Pinhais - PR
Tlf: +41 3132 5100
São Bernardo do Campo - SP
Tlf: +41 3132 5100
fersa.brasil@fersa.com



www.fersa.com



FSMBDG-V3-07-16
FERSA SOLUTIONS \ MERCEDES BENZ